




Installation and operation manual

Split system air conditioners



FDA200AXVEB
FDA250AXVEB

Installation and operation manual
Split system air conditioners

English

CE - DECLARATION OF CONFORMITY
CE - KONFORMITÄTSSERKLÄRUNG
CE - DICHLARAZIÓ-DE-CONFORMITÁ
CE - ДИХЛАЗІЯ ДІЯМОУФІСІ
CE - DECLARACIÓN-DE-CONFORMIDAD
CE - ЗАЯВЛЕНІЕ О СОТВѢТСТВІИ
CE - OVERENSTEMMELSESERKLARING
CE - FÖRSÄKRAN OM ÖVERENSTEMMELSE

CE - ERKLÄRUNG ÜB. SÄMVISAR
CE - LIKUTIUS YHDENMUKAISUDESTA
CE - PROHLÁŠENÍ SHODY
CE - DECLARAȚIE DE CONFORMITATE

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARACIJA
CE - ДЕКЛАРАЦІЯ ПРО СООТВѢСТВИЕ
CE - УПОВНУЛКОВАНІЯ

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARACIJA
CE - ДЕКЛАРАЦІЯ ПРО СООТВѢСТВИЕ
CE - УПОВНУЛКОВАНІЯ

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARACIJA
CE - ДЕКЛАРАЦІЯ ПРО СООТВѢСТВИЕ
CE - УПОВНУЛКОВАНІЯ

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARACIJA
CE - ДЕКЛАРАЦІЯ ПРО СООТВѢСТВИЕ
CE - УПОВНУЛКОВАНІЯ

Daikin Europe N.V.

- 01 declares under its sole responsibility that the air conditioning models to which this declaration relates
02 erklärt auf seine alleinige Verantwortung, daß die Modelle der Klimaanlage für die diese Erklärung bestimmt ist:
03 déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration:
04 verklaart hierbij op eigen exclusieve verantwoordelijkheid dat de airconditioning units waarop deze verklaring betrekking heeft:
05 declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
06 dichiara sotto sua responsabilità che i condizionatori modelli a cui è riferita questa dichiarazione:
07 объявляет на свое ответственности что кондиционеры моделей к которым относится настоящая декларация:
08 declara sub sua exclusiva responsabilidade que os modelos de ar condicionado a que esta declaração se refere.

- 09 заявляет, исключительно под свою ответственность, что модели кондиционеров воздуха, к которым относится настоящее заявление:
10 erklærer under eneansvar, at klimaanlægsmødelerne, som denne deklaration vedrører:
11 deklarerer i egenansvar, att luftkonditioneringsmodellerna som berörs av denna deklaration innehåller att:
12 erklærer et tilsvarende ansvar for at de luftkonditioneringsmodeller som berøres af denne deklaration, indeholder at:
13 ilmoittaa yksinomaan omalla vastuullaan, että ilmajärjestelmien laitteiden mallit, joihin tämä julistus liittyy, sisältävät sen, mitä tässä julistetaan:
14 prohlasuje ve své plné odpovědnosti, že modely klimatizací, k nimu se tato prohlášení vztahují:
15 izjavljuje pod svojimi vladnimi odgovornostmi da su modeli klima uređaja na koje se ova izjava odnosi:
16 teľjes teľisetsьgь, isključivo na svoji odgovornosti, toľy a klima uređajev modeler, nelyetkьe e tyakozkozat vorakozak:

- 17 deklarije na vlastiti odgovornost, da modeler klimatizatorov, k tьhori odnosi n^nejsza deklaracija:
18 deklaře je proprie d^nsuritate c^a aparatele de aer condiționat la care se refer^ această declarație:
19 k svo odgovornosti izjavlja, da so modeli klimatskih naprav, na katere se izjava nanaša:
20 kinita oma j^ksku vastuusse, et k^sellede deklaratsioni alla kuuluvad k^lmsed n^eelsed mudelid:
21 peapõhja on oma vastutusest, et koľetamine k^lmatika seadustajad, za kormi se omakse t^m deklarasioon:
22 vastab savo asotsionnoľstvennoľ, kad k^lno konditsionirovani pređavni modeler, kurem ja deklarsia s^ deklaratsia:
23 izjavlja na vlasti odgovornost, da se model klimatizatsionnoľ uređajev konformiraj, iz kurem alaeas s^ deklaratsia:
24 yavnae na vlasti odgovornost, da se model klimatizatsionnoľ uređajev konformiraj, iz kurem alaeas s^ deklaratsia:
25 yavnae na vlasti odgovornost, da se model klimatizatsionnoľ uređajev konformiraj, iz kurem alaeas s^ deklaratsia:

FDA20AXVB, FDA250AXVB,

- 01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
02 deriden følgende Norm(en) eller anden anden Normdokument eller -dokumenter enskriftsværtskriften, under der V^r^nssetning, d^s de g^n^s
03 unserer Anweisung(en) eingetsetzt werden:
04 sont conformes ^ la(s) norme(s) ou autre(s) document(s) normatif(s), pour autant qu'ils soient utilis^s conform^ment ^ nos instructions:
05 conform de volgente norm(en) of d^n of meer andere b^vende documenten zijn, op voorwaarde dat ze worden gebuikt overeenkomstig onze
06 instructies:
07 est^n en conformidat con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras
08 instrucciones:
09 sono conformi al(al) seguente(i) standard(i) o al(al)ro(i) document(i) a carattere normativo, a patto che vengano usati in conformit^ alle nostre istruzioni:
10 oľpovuje na toľo oľsobnoľoľ t^povnoťoť (i) d^mo t^povnoťoľ (i) konformnoť, ut^o t^m t^povnoťoľ (i) konformnoťoť
oľpovnoťu je, t^ oľn^sje, p^s:
11 under egteľseľe at bestemmelse(r) i:
12 enligt villkoren i:
13 qđil i henhold til bestemmelse(r) i:
14 nouđl^sten na d^řev^s:
15 za d^řev^sni ustanovljeni p^dpuis:
16 prema odredbama:
17 koreli a d^:
18 zgodne z postanovljenami D^rsklivi:
19 d^o upoľevanju doľb:
20 vastavutv^rke:
21 oľpovnoťu t^ oľn^sje, p^s:
22 oľpovnoťu t^ oľn^sje, p^s:
23 oľpovnoťu t^ oľn^sje, p^s:
24 oľpovnoťu t^ oľn^sje, p^s:
25 oľpovnoťu t^ oľn^sje, p^s:

EN60335-2-40,

- 01 Note* following the provisions of:
02 Hiwaľs* conform^ment aux stipulations de:
03 overenkomstig de bepalingen van:
04 secondo le disposizioni de:
05 secondo le prescrizioni per:
06 t^ t^povnoťu t^ oľn^sje, p^s:
07 t^ t^povnoťu t^ oľn^sje, p^s:
08 t^ t^povnoťu t^ oľn^sje, p^s:
09 t^ t^povnoťu t^ oľn^sje, p^s:

Machinery 2006/42/EC
Electromagnetic Compatibility 2014/30/EU
Low Voltage 2014/35/EU

- 01 Directives as amended:
02 Direktiven, gem^kt, ^nd^rter,
03 Richtlijnen, met wijzigingen,
04 Richtlinien, teľes que modifi^s,
05 Richtlinien, teľes que modifi^s,
06 Richtlinien, teľes que modifi^s,
07 Richtlinien, teľes que modifi^s,
08 Richtlinien, teľes que modifi^s,
09 Richtlinien, teľes que modifi^s,
10 Richtlinien, teľes que modifi^s,
11 Richtlinien, teľes que modifi^s,
12 Richtlinien, teľes que modifi^s,
13 Richtlinien, teľes que modifi^s,
14 Richtlinien, teľes que modifi^s,
15 Richtlinien, teľes que modifi^s,
16 Richtlinien, teľes que modifi^s,
17 Richtlinien, teľes que modifi^s,
18 Richtlinien, teľes que modifi^s,
19 Richtlinien, teľes que modifi^s,
20 Richtlinien, teľes que modifi^s,
21 Richtlinien, teľes que modifi^s,
22 Richtlinien, teľes que modifi^s,
23 Richtlinien, teľes que modifi^s,
24 Richtlinien, teľes que modifi^s,
25 Richtlinien, teľes que modifi^s:

- 16 meľetelneľe az alábbi szabv^ny (k)nak vagy egyeb t^rnyv^ny dokumentum (i)k)nak, az azok^k el^rt^s szerinti haszn^l^s:
17 sp^lunij u normativnoľ nasleduju^ci normi (i) dokumenti normativnoľ, pod uslovjem da se uzwane u zupn^e s nasznij instrukcijam:
18 sp^lunij u normativnoľ uimabrui (uimabr^e standard e) sau altele (documente) normative (i), cu condiția ca acestea s^ fie utilizate în conformitate cu
instrucțiunile noastre:
19 skladni s naslednjimi standardi in drugi normativi, pod pogojem, da se uporabljajo skladu s našimi navodili:
20 on vastavusese j^rme (i)le standardite (i) ga v^i teiste normativse dokumentide, ku ned asutakse vastavalt meie juhenditele:
21 oľpovnoťu na oľn^sje, p^s:
22 oľpovnoťu na oľn^sje, p^s:
23 oľpovnoťu na oľn^sje, p^s:
24 oľpovnoťu na oľn^sje, p^s:
25 oľpovnoťu na oľn^sje, p^s:

- 08 est^o em conformidade com a(s) seguinte(s) norma(s) ou outro(s) documento(s) normativo(s), desde que estes sejam utilizados de
acordo com as nossas instruções:
09 oľpovnoťu t^ oľn^sje, p^s:
10 oľpovnoťu t^ oľn^sje, p^s:
11 oľpovnoťu t^ oľn^sje, p^s:
12 oľpovnoťu t^ oľn^sje, p^s:
13 oľpovnoťu t^ oľn^sje, p^s:
14 oľpovnoťu t^ oľn^sje, p^s:
15 oľpovnoťu t^ oľn^sje, p^s:

- 11 Information* enligt och g^n^kants av enligt
Certifikat <C>:
12 Merk* som det finns i nummer <A> och g^n^kants av enligt
Certifikat <C>:
13 Huon* som det finns i nummer <A> och g^n^kants av enligt
Certifikat <C>:
14 Poznamka* som det finns i nummer <A> och g^n^kants av enligt
Certifikat <C>:
15 Napomena* som det finns i nummer <A> och g^n^kants av enligt
Certifikat <C>:
16 Megjegyz^s* a(z) <A> alapján, a(z) igazolva a megfelele, a(z) 21 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 22 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 23 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 24 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 25 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 26 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 27 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 28 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 29 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 30 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 31 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 32 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 33 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 34 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 35 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 36 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 37 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 38 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 39 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 40 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 41 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 42 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 43 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 44 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 45 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 46 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 47 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 48 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 49 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 50 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 51 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 52 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 53 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 54 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 55 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 56 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 57 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 58 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 59 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 60 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 61 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 62 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 63 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 64 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 65 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 66 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 67 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 68 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 69 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 70 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 71 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 72 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 73 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 74 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 75 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 76 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 77 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 78 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 79 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 80 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 81 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 82 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 83 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 84 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 85 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 86 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 87 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 88 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 89 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 90 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 91 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 92 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 93 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 94 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 95 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 96 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 97 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 98 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 99 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 100 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 101 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 102 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 103 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 104 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 105 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 106 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 107 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 108 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 109 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 110 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 111 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 112 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 113 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 114 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 115 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 116 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 117 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 118 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 119 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 120 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 121 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 122 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 123 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 124 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 125 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 126 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 127 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 128 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 129 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 130 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 131 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 132 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 133 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 134 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 135 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 136 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 137 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 138 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 139 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 140 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 141 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 142 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 143 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 144 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 145 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 146 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 147 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 148 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 149 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 150 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 151 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 152 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 153 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 154 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 155 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 156 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 157 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 158 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 159 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 160 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 161 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 162 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 163 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 164 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 165 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 166 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 167 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 168 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 169 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 170 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 171 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 172 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 173 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 174 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 175 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 176 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 177 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 178 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 179 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 180 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 181 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 182 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 183 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 184 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 185 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 186 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 187 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 188 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 189 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 190 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 191 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 192 Pastaba*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 193 P^zmes*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 194 Poznamka*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 195 Not*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 196 Z^b^rnek*
k^rto e k^rto e a <A> v^i k^rto e a megfelele, a(z) 197 Pastaba*
k^

Table of Contents

1 About the documentation	3
1.1 About this document.....	3
For the installer	4
2 About the box	4
2.1 Indoor unit	4
2.1.1 To remove the accessories from the indoor unit.....	4
3 About the units and options	4
3.1 System layout.....	4
4 Preparation	4
4.1 Preparing the installation site	4
4.1.1 Installation site requirements of the indoor unit	4
5 Installation	5
5.1 Mounting the indoor unit.....	5
5.1.1 Guidelines when installing the indoor unit.....	5
5.1.2 Guidelines when installing the drain piping.....	5
5.1.3 Guidelines when installing the ducting.....	6
5.2 Connecting the refrigerant piping	7
5.2.1 To connect the refrigerant piping to the indoor unit	7
5.3 Connecting the electrical wiring.....	7
5.3.1 Specifications of standard wiring components.....	8
5.3.2 To connect the electrical wiring on the indoor unit.....	8
6 Commissioning	9
6.1 Checklist before commissioning	9
6.2 To perform a test run.....	9
7 Configuration	9
7.1 Field setting	9
8 Disposal	10
9 Technical data	10
9.1 Wiring diagram	10
9.1.1 Unified wiring diagram legend.....	10
For the user	11
10 About the system	11
10.1 Components	12
11 User interface	12
12 Operation	12
12.1 Operation range	12
12.2 Operation procedure	12
13 Maintenance and service	12
13.1 Overview: Maintenance and service	12
13.2 Cleaning the air filter and air outlet.....	13
13.2.1 To clean the air outlet	13
13.2.2 To clean the air filter	13
13.3 Maintenance before a long stop period	13
13.4 Maintenance after a long stop period	13
13.5 About the refrigerant.....	14
14 Troubleshooting	14
14.1 Symptoms that are NOT system malfunctions	15
14.1.1 Symptom: The system does not operate	15
14.1.2 Symptom: White mist comes out of a unit (Indoor unit).....	15

14.1.3 Symptom: Noise of air conditioners (indoor unit).....	15
14.1.4 Symptom: Dust comes out of the unit	15
14.1.5 Symptom: The units can give off odours.....	15
14.1.6 Symptom: The display shows "88".....	15
14.1.7 Symptom: The operation stopped suddenly (Operation lamp is on)	15
14.1.8 Symptom: The outdoor fan rotates while the air conditioner is not in operation	15
14.1.9 Symptom: The heating operation stops suddenly and a flowing sound is heard	15

15 Disposal 16

1 About the documentation

1.1 About this document



INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

Target audience

Authorised installers + end users



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.



WARNING

Make sure installation, servicing, maintenance, repair and applied materials follow the instructions from Daikin and, in addition, comply with applicable legislation and are performed by qualified persons only. In Europe and areas where IEC standards apply, EN/IEC 60335-2-40 is the applicable standard.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you must read before installing
 - Format: Paper (in the box of the indoor unit)
- **Indoor unit installation and operation manual:**
 - Installation and operation instructions
 - Format: Paper (in the box of the indoor unit)
- **Installer and user reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Detailed step-by-step instructions and background information for basic and advanced usage
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

2 About the box

For the installer

2 About the box

Following special symbols may appear on the indoor unit packing case. For general symbols, refer to the General safety precaution.

Symbol	Meaning
	Be careful when handling the unit. Indoor unit contains rotating parts.

2.1 Indoor unit



INFORMATION


The following figures are just examples and may NOT completely match your system layout.




WARNING: FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.

2.1.1 To remove the accessories from the indoor unit



- a Installation and operation manual
- b General safety precautions
- c Washers for hanger bracket
- d Screws for duct flanges (M5×12)
- e Hexagon head bolt (M10×40)
- f Attached piping with sealing
- g Tie wrap
- h Spring washer



- a Indoor unit
- b Outdoor unit
- c User interface
- d Suction air
- e Discharge air
- f Refrigerant piping + interconnection cable
- g Drain pipe
- h Earth wiring

4 Preparation

4.1 Preparing the installation site

- Provide sufficient space around the unit for servicing and air circulation.
- Choose the installation location with sufficient space for carrying the unit in and out of the site.



WARNING

Do NOT install the air conditioner at any place where flammable gas may leak out. If the gas leaks out and stays around the air conditioner, a fire may break out.

4.1.1 Installation site requirements of the indoor unit



INFORMATION

The sound pressure level is less than 70 dBA.

- Use **suspension bolts** for installation.
- **Spacing.** Mind the following requirements:



3 About the units and options

3.1 System layout




INFORMATION

The following figures are just examples and may NOT completely match your system layout.




Installation example:



Install the unit temporarily.

- 1 Attach the hanger bracket to the suspension bolt.
- 2 Fix it securely.

- **Level.** Make sure the unit is level at all four corners using a level or a water-filled vinyl tube.



- 3 Tighten the upper nut.



NOTICE

Do NOT install the unit tilted. **Possible consequence:** If the unit is tilted against the direction of the condensate flow (the drain piping side is raised), water may drip.

5.1.2 Guidelines when installing the drain piping

Make sure condensation water can be evacuated properly. This involves:

- General guidelines

5 Installation



WARNING

Installation shall be done by an installer, the choice of materials and installation shall comply with the applicable legislation. In Europe, EN378 is the applicable standard.

5.1 Mounting the indoor unit

5.1.1 Guidelines when installing the indoor unit



INFORMATION

Optional equipment. When installing optional equipment, also read the installation manual of the optional equipment. Depending on the field conditions, it might be easier to install the optional equipment first.


- **Ceiling strength.** Check whether the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit.
- **Suspension bolts.** Use M10 suspension bolts for installation. Attach the hanger bracket to the suspension bolt. Fix it securely using a nut and washer from the upper and lower sides of the hanger bracket.
- **Ceiling opening size.** Make sure the ceiling opening is within the following limits:

5 Installation


- Connecting the drain piping to the indoor unit
- Checking for water leaks

General guidelines

- Pipe length.** Keep drain piping as short as possible.
- Pipe size.** Keep the pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter).
- Slope.** Make sure the drain piping slopes down (at least 1/100) to prevent air from being trapped in the piping. Use hanging bars as shown.



- Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.
- Combining drain pipes.** You can combine drain pipes. Make sure to use drain pipes and T-joints with the correct gauge for the operating capacity of the units.




To connect the drain piping to the indoor unit



NOTICE


Incorrect connection of the drain hose might cause leaks, and damage the installation space and surroundings.

- Pull out the drain plug.
- Install the adapter for the drain hose (field supply).
- Push the drain hose as far as possible over the adapter for the drain hose.
- Tighten the metal clamp until the screw head is less than 4 mm from the metal clamp part.
- Check for water leaks (see ["To check for water leaks" on page 6](#)).
- Install the insulation piece (drain pipe).



To check for water leaks

Gradually pour approximately 1 l of water in the drain pan, and check for water leaks.



5.1.3 Guidelines when installing the ducting



WARNING

If one or more rooms are connected to the unit using a duct system, make sure:

- there are no operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in case the floor area is less than A_{min} specified in the General safety precautions;
- no auxiliary devices, which may be a potential ignition source, are installed in the duct work (example: hot surfaces with a temperature exceeding 700°C and electric switching device);
- only auxiliary devices approved by the manufacturer are used in the duct work;
- an air inlet or outlet is connected directly with a room by ducting. Do NOT use spaces such as a false ceiling as a duct for the air inlet or outlet.



WARNING

Do NOT install operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) in the duct work.




CAUTION

- Make sure the installation of the duct does NOT exceed the setting range of the external static pressure for the unit. Refer to the technical datasheet of your model for the setting range.
- Make sure to install the canvas duct so vibrations are NOT transmitted to the duct or ceiling. Use a sound-absorbing material (insulation material) for the lining of the duct and apply vibration insulation rubber to the hanging bolts.
- When welding, make sure NOT to spatter onto the drain pan or the air filter.
- If the metal duct passes through a metal lath, wire lath or metal plate of the wooden structure, separate the duct and wall electrically.
- Install the outlet grille in a position where the airflow will not come into direct contact with people.
- Do NOT use booster fans in the duct. Use the function to adjust the fan rate setting automatically (see ["7.1 Field setting" on page 9](#)).

The ducting is to be field supplied.

- Attach the flange (located on the unit) using 45 screws for duct flanges (accessory).
- Connect the canvas duct to the inside of the flange.
- Connect the duct to the canvas duct.
- Wind aluminium tape around the flange and duct connection. Make sure there are no air leaks at any other connection.

- 5 Insulate the duct to prevent condensation from forming. Use glass wool or polyethylene foam 25 mm thick.



- **Filter.** Be sure to attach an air filter inside the air passage on the intake side. Use an air filter with dust collecting efficiency $\geq 50\%$ (gravimetric method). The included filter is not used when the intake duct is attached.

5.2 Connecting the refrigerant piping



DANGER: RISK OF BURNING



INFORMATION

- For **liquid piping**, use a flare connection.
- For **gas piping**, use the attached piping (accessory) and fix it with the hexagon head bolts and spring washers (accessory)

5.2.1 To connect the refrigerant piping to the indoor unit



CAUTION

Install the refrigerant piping or components in a position where they are unlikely to be exposed to any substance which may corrode components containing refrigerant, unless the components are constructed of materials that are inherently resistant to corrosion or are suitably protected against corrosion.




WARNING: FLAMMABLE MATERIAL


The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.

- **Pipe length.** Keep refrigerant piping as short as possible.

- 1 Connect the **liquid piping** to the unit using the flare connections.



- 2 Connect the **gas piping** using the attached piping (accessory). Fix it to the unit using hexagon head bolts (M10×40) (accessory) and spring washers (accessory). Place sealing (on the attached piping) between the connection.



NOTICE


- Join the attached piping (accessory) and the field refrigerant piping (field supply) by brazing before fixing the attached piping to the unit.
- Do NOT braze the refrigerant piping directly to the indoor unit.



CAUTION

Do NOT reuse sealing (on the attached piping). Always use new sealing to prevent refrigerant gas leaks.

- 3 Insulate the refrigerant piping on the indoor unit as follows:



- a Insulation material (field supply)
b Cable tie (field supply)
c Attached piping (accessory)
d Hexagon head bolt and spring washer (accessory)
e Refrigerant pipe connection (attached to the unit)
f Unit



NOTICE

Make sure to insulate all refrigerant piping. Any exposed piping might cause condensation.

5.3 Connecting the electrical wiring



DANGER: RISK OF ELECTROCUTION



WARNING

ALWAYS use multicore cable for power supply cables.



WARNING

Use an all-pole disconnection type breaker with at least 3 mm between the contact point gaps that provide full disconnection under overvoltage category III.



WARNING

If the supply cord is damaged, it MUST be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.



WARNING

Prevent hazards due to inadvertent resetting of the thermal cut-out: power to this appliance MUST NOT be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly turned ON and OFF by the utility.

5 Installation

5.3.1 Specifications of standard wiring components

Component		FDA200	FDA250
Power supply cable	MCA ^(a)	4 A	4.3 A
	Voltage	220~240 V	
	Phase	1~	
	Frequency	50/60 Hz	
	Wire sizes	Must comply with applicable legislation	
Interconnection cable (indoor↔outdoor)		4-core cable 1.5 mm ² ~2.5 mm ² and applicable for 220~240 V H07RN-F (60245 IEC 66)	
User interface cable		Vinyl cord with 0.75 to 1.25 mm ² sheath or cables (2 core wires) Maximum 500 m H03VV-F (60227 IEC 52)	
Recommended circuit breaker		6 A	
Earth leakage circuit breaker		Must comply with applicable legislation	

(a) MCA=Minimum circuit ampacity. Stated values are maximum values (see electrical data of combination with indoor units for exact values).

Electrical equipment must comply with EN/IEC 61000-3-12, the European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase.

5.3.2 To connect the electrical wiring on the indoor unit



NOTICE

- Follow the wiring diagram (delivered with the unit, located on the switch box cover).
- Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.



It is important to keep the power supply and the transmission wiring separated from each other. In order to avoid any electrical interference the distance between both wirings should ALWAYS be at least 50 mm.



NOTICE

Be sure to keep the power line and transmission line apart from each other. Transmission wiring and power supply wiring may cross, but may NOT run parallel.

- 1 Remove the service cover.





- a Interconnection cable
- b Power supply cable
- c Circuit breaker
- d Earth leakage circuit breaker
- e Power supply
- f Earth


- User interface cable:** Route the cable through the frame, connect the cable to the terminal block, and fix the cable with a cable tie.
- Interconnection cable (indoor↔outdoor):** Route the cable through the frame, connect the cable to the terminal block (make sure the numbers match with the numbers on the outdoor unit, and connect the earth wire), and fix the cable with a cable tie.
- Power supply cable:** The unit MUST be connected to a separate power supply in addition to the interconnection cable to ensure correct function. When servicing the unit interrupt all power supply.

When using 1 user interface with 1 indoor unit.

When using 2 user interfaces



When using group control



- a Power supply
- b Main switch
- c Fuse
- d User interface
- e Separate power supply

- 5 Wrap the sealing (field supply) around the cables to prevent water from entering the unit. Seal all gaps to prevent small animals from entering the system.

**WARNING**

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.

6 Reattach the service cover.

- **Master unit:** Be sure to connect the wiring when combining with a simultaneously operating multi-type in group control.

**INFORMATION**

In case of group control it is not necessary to assign an address to the indoor unit. The address is automatically set when the power is activated.

6 Commissioning

**NOTICE**

NEVER operate the unit without thermistors and/or pressure sensors/switches. Burning of the compressor might result.

6.1 Checklist before commissioning

After the installation of the unit, first check the following items. Once all below checks are fulfilled, the unit **MUST** be closed, **ONLY** then can the unit be powered up.

<input type="checkbox"/>	You read the complete installation and operation instructions, as described in the installer and user reference guide .
<input type="checkbox"/>	The indoor unit is properly mounted.
<input type="checkbox"/>	The outdoor unit is properly mounted.
<input type="checkbox"/>	Make sure drain piping is properly installed, insulated and drainage flows smoothly. Check for water leaks. Possible consequence: Condensate water might drip.
<input type="checkbox"/>	The ducting is properly installed and insulated.
<input type="checkbox"/>	The refrigerant pipes (gas and liquid) are installed correctly and thermally insulated.
<input type="checkbox"/>	There are NO refrigerant leaks .
<input type="checkbox"/>	There are NO missing phases or reversed phases .
<input type="checkbox"/>	The system is properly earthed and the earth terminals are tightened.
<input type="checkbox"/>	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
<input type="checkbox"/>	The power supply voltage matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are NO loose connections or damaged electrical components in the switch box.
<input type="checkbox"/>	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
<input type="checkbox"/>	The stop valves (gas and liquid) on the outdoor unit are fully open.

6.2 To perform a test run

**INFORMATION**

For the test run procedure, see the reference guide or the service manual of the used user interface.

**NOTICE**

Do not interrupt the test run.

7 Configuration

7.1 Field setting

Make the following field settings so that they correspond with the actual installation setup and with the needs of the user:

- External static pressure setting using:
 - Airflow automatic adjustment setting
 - User interface
- Time to clean air filter

To set airflow automatic adjustment

- When the air conditioning unit is running in fan operation mode:

- 1 Stop the air conditioning unit.
- 2 Set value number (—) to 03.

Setting content:	Then ¹		
	M	SW	—
Airflow adjustment is OFF	11(21)	7	01
Press ON/OFF to return to normal operating mode.			03
Possible consequence: The operation lamp will light up and the unit will start the fan operation for airflow automatic adjustment.			
Operation stops after 1 to 8 minutes.			02
Possible consequence: Setting is finished and the operation lamp will be off.			

If there is no change after airflow adjustment, perform the setting again.

**INFORMATION**

- The fan speed of the indoor unit is preset to ensure the standard external static pressure.
- To set a higher or lower external static pressure, reset the initial setting with the user interface.

User interface

Check the indoor unit setting: the value number (—) of mode 11(21) must be set to 01.

Change the value number (—) in accordance with the external static pressure of the duct to be connected as in the table below.

⁽¹⁾ Field settings are defined as follows:

- **M:** Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- **SW:** Setting number
- **—:** Value number
- **■:** Default

8 Disposal

Setting ¹			External static pressure
M	SW	—	
13(23)	6	01	62
		02	70
		03	80
		04	90
		05	100
		06	115
		07	130
		08	145
		09	160
		10	175
		11	190
		12	205
		13	220
		14	235
		15	250

Time to clean air filter

This setting must correspond with the air contamination in the room. It determines the interval at which the **TIME TO CLEAN AIR FILTER** notification is displayed on the user interface. When using a wireless user interface, you must also set the address (see the installation manual of the user interface).

If you want an interval of... (air contamination)	Then ¹		
	M	SW	—
±2500 h (light)	10(20)	0	01
±1250 h (heavy)			02
No notification		3	02

- **2 user interfaces:** When using 2 user interfaces, one must be set to "MAIN" and the other to "SUB".

8 Disposal



NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

9 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

9.1 Wiring diagram

9.1.1 Unified wiring diagram legend

For applied parts and numbering, refer to the wiring diagram on the unit. Part numbering is by Arabic numbers in ascending order for each part and is represented in the overview below by "*" in the part code.

Symbol	Meaning	Symbol	Meaning
	Circuit breaker		Protective earth
	Connection		Protective earth (screw)
	Connector		Rectifier
	Earth		Relay connector
	Field wiring		Short-circuit connector
	Fuse		Terminal
	Indoor unit		Terminal strip
	Outdoor unit		Wire clamp

Symbol	Colour	Symbol	Colour
BLK	Black	ORG	Orange
BLU	Blue	PNK	Pink
BRN	Brown	PRP, PPL	Purple
GRN	Green	RED	Red
GRY	Grey	WHT	White
		YLW	Yellow

Symbol	Meaning
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*C	Buzzer
C*	Capacitor
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*	Connection, connector
D*, V*D	Diode
DB*	Diode bridge
DS*	DIP switch
E*H	Heater
FU*, F*U, (for characteristics, refer to PCB inside your unit)	Fuse
FG*	Connector (frame ground)
H*	Harness
H*P, LED*, V*L	Pilot lamp, light emitting diode
HAP	Light emitting diode (service monitor green)
HIGH VOLTAGE	High voltage
IES	Intelligent eye sensor
IPM*	Intelligent power module
K*R, KCR, KFR, KHuR, K*M	Magnetic relay
L	Live

⁽¹⁾ Field settings are defined as follows:

- **M:** Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- **SW:** Setting number
- **—:** Value number
- : Default

Symbol	Meaning
L*	Coil
L*R	Reactor
M*	Stepper motor
M*C	Compressor motor
M*F	Fan motor
M*P	Drain pump motor
M*S	Swing motor
MR*, MRCW*, MRM*, MRN*	Magnetic relay
N	Neutral
n=*, N=*	Number of passes through ferrite core
PAM	Pulse-amplitude modulation
PCB*	Printed circuit board
PM*	Power module
PS	Switching power supply
PTC*	PTC thermistor
Q*	Insulated gate bipolar transistor (IGBT)
Q*DI	Earth leak circuit breaker
Q*L	Overload protector
Q*M	Thermo switch
R*	Resistor
R*T	Thermistor
RC	Receiver
S*C	Limit switch
S*L	Float switch
S*NPH	Pressure sensor (high)
S*NPL	Pressure sensor (low)

Symbol	Meaning
S*PH, HPS*	Pressure switch (high)
S*PL	Pressure switch (low)
S*T	Thermostat
S*RH	Humidity sensor
S*W, SW*	Operation switch
SA*, F1S	Surge arrester
SR*, WLU	Signal receiver
SS*	Selector switch
SHEET METAL	Terminal strip fixed plate
T*R	Transformer
TC, TRC	Transmitter
V*, R*V	Varistor
V*R	Diode bridge
WRC	Wireless remote controller
X*	Terminal
X*M	Terminal strip (block)
Y*E	Electronic expansion valve coil
Y*R, Y*S	Reversing solenoid valve coil
Z*C	Ferrite core
ZF, Z*F	Noise filter
A*P	Printed circuit board
BS*	Pushbutton ON/OFF, operation switch
BZ, H*C	Buzzer
C*	Capacitor
AC*, CN*, E*, HA*, HE*, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A, K*R_*	Connection, connector

For the user

10 About the system



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.



INFORMATION

The sound pressure level is less than 70 dBA.



WARNING: FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.



WARNING

- Do NOT modify, disassemble, remove, reinstall or repair the unit yourself as incorrect dismantling or installation may cause an electric shock or fire. Contact your dealer.
- In case of accidental refrigerant leaks, make sure there are no naked flames. The refrigerant itself is entirely safe and non-toxic. R410A is a non-combustible refrigerant, and R32 is a mildly flammable refrigerant, but they will generate a toxic gas when they accidentally leak into a room where combustible air from fan heaters, gas cookers, etc. is present. Always have qualified service personnel confirm that the point of leakage has been repaired or corrected before resuming operation.



NOTICE

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Only use accessories, optional equipment and spare parts made or approved by Daikin.


11 User interface

10.1 Components



INFORMATION

The following illustration is an example and might NOT match your system layout.



CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.

11 User interface



CAUTION

- NEVER touch the internal parts of the controller.
- Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.



NOTICE

Do NOT wipe the controller operation panel with benzene, thinner, chemical dust cloth, etc. The panel may get discoloured or the coating peeled off. If it is heavily dirty, soak a cloth in water-diluted neutral detergent, squeeze it well and wipe the panel clean. Wipe it with another dry cloth.



NOTICE

NEVER press the button of the user interface with a hard, pointed object. The user interface may be damaged.



NOTICE

NEVER pull or twist the electric wire of the user interface. It may cause the unit to malfunction.

This operation manual offers a non-exhaustive overview of the main functions of the system.

For more information about the user interface, see the operation manual of the installed user interface.

12 Operation

12.1 Operation range

For combination with R410A outdoor unit, refer to the following table:

Outdoor units		Cooling	Heating
RZQ200+250	Outdoor temperature	-5~46°C DB	-15~15°C WB
	Indoor temperature	14~28°C WB	10~27°C DB
Indoor humidity		≤80% ^(a)	

For combination with R32 outdoor unit, refer to the following table:

Outdoor units		Cooling	Heating
RZA200+250	Outdoor temperature	-15~46°C DB	-15~15°C WB
	Indoor temperature	14~28°C WB	10~27°C DB
Indoor humidity		≤80% ^(a)	

(a) To avoid condensation and water dripping out of the unit. If the temperature or the humidity is beyond these conditions, safety devices may be activated and the air conditioner may not operate.

DB: Dry bulb

WB: Wet bulb

12.2 Operation procedure

- Turn on the power at least 6 hours before operating the unit in order to ensure smoother operation. As soon as the power is turned on, the user interface display appears.
- If there was a power failure during operation, the system automatically restarts immediately after the power supply is recovered.
- The setting temperature range of the user interface is described in chapter "Operation range".
- Read the documentation carefully before operating the user interface to ensure the best possible performance.

13 Maintenance and service

13.1 Overview: Maintenance and service



NOTICE

Maintenance MUST be done by an authorized installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



NOTICE

Never inspect or service the unit by yourself. Ask a qualified service person to perform this work. However, as end user, you may clean the air filter, suction grille, air outlet and outside panels.



CAUTION

Before accessing terminal devices, make sure to interrupt all power supply.



DANGER: RISK OF ELECTROCUTION

To clean the air conditioner or air filter, be sure to stop operation and turn all power supplies off. Otherwise, an electric shock and injury may result.



WARNING

To prevent electric shocks or fire:

- Do NOT rinse the unit.
- Do NOT operate the unit with wet hands.
- Do NOT place any objects containing water on the unit.



CAUTION

After a long use, check the unit stand and fitting for damage. If damaged, the unit may fall and result in injury.



CAUTION

Do NOT touch the heat exchanger fins. These fins are sharp and could result in cutting injuries.



WARNING

Be careful with ladders when working in high places.

13.2 Cleaning the air filter and air outlet

13.2.1 To clean the air outlet



WARNING

Do NOT let the indoor unit get wet. **Possible consequence:** Electric shock or fire.



NOTICE

- Do NOT use gasoline, benzene, thinner polishing powder or liquid insecticide. **Possible consequence:** Discoloration and deformation.
- Do NOT use water or air of 50°C or higher. **Possible consequence:** Discoloration and deformation.

Clean with a soft cloth. If it is difficult to remove stains, use water or a neutral detergent.


13.2.2 To clean the air filter

When to clean the air filter:


- Rule of thumb: Clean every 6 months. If the air in the room is extremely contaminated, increase the cleaning frequency.
- Depending on the settings, the user interface can display the "Time to clean filter" notification. Clean the air filter when the notification is displayed.
- If the dirt becomes impossible to clean, change the air filter.

How to clean the air filter:


- 1 Remove the screws on the filter cover using screwdriver.



- 2 Slowly pull out the air filter (composed of 3 equal parts).



- 3 Clean the air filter. Use a vacuum cleaner or wash with water. If the air filter is very dirty, use a soft brush and neutral detergent.



- 4 Dry the air filter in the shadow.
- 5 Re-attach the air filter. Partially re-insert the first part of the air filter, align the middle part of the air filter with first part and push the 2 clips in place to lock the filter parts together. Repeat the procedure for the last part of the filter.
- 6 Place the filter cover back. Fix the filter cover with screws.
- 7 Turn ON the power.
- 8 To remove warning screens, see the reference guide of the user interface.

13.3 Maintenance before a long stop period

E.g., at the end of the season.

- Let the indoor units run in fan only operation for about half a day in order to dry the interior of the units.
- Turn off the power. The user interface display disappears. When the main power is turned on, the air conditioner will use some power, even if it is not operating.
- Clean the air filter and the casing of the indoor unit (see "13.2 Cleaning the air filter and air outlet" on page 13). Make sure to install cleaned air filters back in the same position.
- Remove the batteries from the user interface (if applicable).

13.4 Maintenance after a long stop period

E.g., at the beginning of the season.

- Check and remove everything that might be blocking inlet and outlet vents of indoor units and outdoor units.
- Check if the earth is connected properly.

14 Troubleshooting

- Check if there is somewhere a broken wire. Contact your dealer in case of problems.
- Clean the air filter and the casing of the indoor unit (see ["13.2 Cleaning the air filter and air outlet" on page 13](#)). Make sure to install cleaned air filters back in the same position.
- Turn on the power at least 6 hours before operating the unit in order to ensure smoother operation. As soon as the power is turned on, the user interface display appears.
- Insert batteries in the user interface (if applicable).

13.5 About the refrigerant

This product contains fluorinated greenhouse gases. Do NOT vent gases into the atmosphere.

Refrigerant type: R32

Global warming potential (GWP) value: 675

Refrigerant type: R410A

Global warming potential (GWP) value: 2087.5



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

Please contact your installer for more information.



WARNING: FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable. Refer to the outdoor unit specifications for the type of refrigerant to be used.



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use cleaning materials or means to accelerate the defrosting process other than those recommended by the manufacturer.
- Be aware that the refrigerant inside the system is odourless.



WARNING

R410A is a non-combustible refrigerant, and R32 is a mildly flammable refrigerant; they normally don't leak. If the refrigerant leaks in the room and comes into contact with fire from a burner, a heater, or a cooker, this may result in a fire (in case of R32), or the formation of a harmful gas.

Turn off any combustible heating devices, ventilate the room, and contact the dealer from where you purchased the unit.

Do not use the unit until a service person confirms that the part from which the refrigerant leaked has been repaired.

14 Troubleshooting

If one of the following malfunctions occur, take the measures shown below and contact your dealer.



WARNING

Stop operation and shut off the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electric shock or fire. Contact your dealer.

The system MUST be repaired by a qualified service person.

Malfunction	Measure
If a safety device such as a fuse, a breaker or an earth leakage breaker frequently actuates or the ON/OFF switch does NOT function properly.	Turn OFF all main power supply switches to the unit.
If water leaks from the unit.	Stop operation.
The operation switch does NOT function properly.	Turn OFF the power supply.
If the user interface displays	Notify your installer and report the error code. To display an error code see the reference guide of the user interface.

If the system does NOT operate properly except for the above mentioned cases and none of the above mentioned malfunctions is evident, investigate the system according to the following procedures.

Malfunction	Measure
If the system does not operate at all.	<ul style="list-style-type: none"> Check if there is no power failure. Wait until power is restored. If a power failure occurs during operation, the system automatically restarts immediately after power is restored. Check if no fuse has blown or breaker is activated. Change the fuse or reset the breaker if necessary.
The system stops immediately after starting operation.	<ul style="list-style-type: none"> Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles. Remove any obstacles and make sure the air can flow freely. Check if the air filter is clogged (see "13.2.2 To clean the air filter" on page 13).
The system operates but cooling or heating is insufficient.	<ul style="list-style-type: none"> Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles. Remove any obstacles and make sure the air can flow freely. Check if the air filter is clogged (see "13.2.2 To clean the air filter" on page 13). Check the temperature setting. Refer to the manual of the user interface. Check if the fan speed setting is set to low speed. Refer to the manual of the user interface. Check if the air flow angle is proper. Refer to the manual of the user interface. Check for open doors or windows. Close doors and windows to prevent wind from coming in. Check if direct sunlight enters the room. Use curtains or blinds. Check if there are too many occupants in the room during cooling operation. Check if the heat source of the room is excessive. If the heat source of the room is excessive (when cooling). Cooling effect decreases if heat gain of the room is too large.

Malfunction	Measure
Operation stops suddenly. (Operation lamp blinks.)	<ul style="list-style-type: none"> Check if the air filter is clogged (see "13.2.2 To clean the air filter" on page 13). Check if air inlet or outlet of outdoor or indoor unit is not blocked by obstacles. Remove any obstacles, turn the breaker OFF and back ON. If the lamp still blinks, contact your dealer. Check if all indoor units connected to outdoor unit in the multi-system are operating in the same mode.
An abnormal function happens during operation.	<ul style="list-style-type: none"> The air conditioner may malfunction because of lightning or radio waves. Turn the breaker OFF and back ON.

If after checking all above items, it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date (possibly listed on the warranty card).

14.1 Symptoms that are NOT system malfunctions

The following symptoms are NOT system malfunctions:

14.1.1 Symptom: The system does not operate

- The air conditioner does not start immediately after the ON/OFF button on the user interface is pressed. If the operation lamp lights, the air conditioner is in normal condition. It does not restart immediately because one of its safety devices actuates to prevent the air conditioner from being overloaded. The air conditioner will turn on again automatically after 3 minutes.
- The air conditioner does not start immediately after the power supply is turned on. Wait 1 minute until the microcomputer is prepared for operation.
- The air conditioner does not restart immediately when the temperature setting button is returned to its former position after pushing. It does not restart immediately because one of its safety devices actuates to prevent the air conditioner from being overloaded. The air conditioner will turn on again automatically after 3 minutes.
- The outdoor unit has stopped. This is because the room temperature has reached the set temperature. The unit switches to fan operation. "❄️" (external control icon) is displayed on the user interface and the actual operation is different from the user interface setting. For multi-split models, the microcomputer executes the following control depending on the operation mode of other indoor units.
- The fan speed is different from the setting. Pressing the fan speed control button does not change the fan speed. When the room temperature reaches the set temperature in heating mode or the unit's maximum capacity is reached, the outdoor unit will stop operation and the indoor unit will operate in fan only mode (low fan speed). In case of multi-split, the indoor unit alternately operates in fan stop mode and fan only mode (LL= low fan speed). This is to prevent the cool air from being blown directly onto anyone present in the room.

14.1.2 Symptom: White mist comes out of a unit (Indoor unit)

- When humidity is high during cooling operation (in oily and dusty places). If the interior of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is

necessary to clean the interior of the indoor unit. Ask your dealer for details on cleaning the unit. This operation requires a qualified service person.

- When the air conditioner is changed over to heating operation after defrost operation. Moisture generated by defrost becomes steam and exits.

14.1.3 Symptom: Noise of air conditioners (indoor unit)

- A "ringing" sound is heard after the unit is started. This sound is generated by the temperature regulator working. It will quiet down after about a minute.
- A continuous low "hissing" sound is heard when the system is in cooling or defrost operation. This is the sound of refrigerant gas flowing through both indoor and outdoor units.
- A hissing sound which is heard at the start or immediately after stopping operation or defrost operation. This is the noise of refrigerant caused by flow stop or flow change.
- A "squeaking" sound is heard when the system is in operation or after the stop of operation. Expansion and contraction of plastic parts caused by temperature change makes this noise.

14.1.4 Symptom: Dust comes out of the unit

When the unit is used for the first time in a long time. This is because dust has gotten into the unit.

14.1.5 Symptom: The units can give off odours

The unit can absorb the smell of rooms, furniture, cigarettes, etc., and then emit it again.

14.1.6 Symptom: The display shows "88"

This is the case immediately after the main power supply switch is turned on and means that the user interface is in normal condition. This continues for 1 minute.

14.1.7 Symptom: The operation stopped suddenly (Operation lamp is on)

The air conditioner may stop for system protection due to large voltage fluctuation. It automatically resumes operation after about 3 minutes.

14.1.8 Symptom: The outdoor fan rotates while the air conditioner is not in operation

- After operation has stopped.** The outdoor fan continues to rotate for another 30 seconds for system protection.
- While the air conditioner is not in operation.** When the outdoor temperature is very high, the outdoor fan starts to rotate for system protection.

14.1.9 Symptom: The heating operation stops suddenly and a flowing sound is heard



The system is removing frost on the outdoor unit. You should wait for about 3 to 8 minutes.



15 Disposal




NOTICE

Do NOT try to dismantle the system yourself: dismantling of the system, treatment of the refrigerant, oil and other parts **MUST** comply with applicable legislation. Units **MUST** be treated at a specialised treatment facility for reuse, recycling and recovery.







ERC

Copyright 2019 Daikin

DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

3P580564-1 2019.04