




### 1. Pipe Cutting and Flaring


- Use a pipe cutter to cut the pipe and remove burr.



#### CAUTION


- Remove burr**  
If burr is not removed, it may cause leakage.
- Point the side to be trimmed downwards during trimming to prevent copper chips from entering the pipe.**

- Before flaring, please put on the flare nut.



### 2. Pipe Connection

- Remove the flare nut from the pipe of the indoor unit by removing the flare nut (female side) with a spanner while holding down the half union (male side) with a spanner.
- Do not crush the pipe while bending it.
- Apply refrigerant oil on the connection part. After carrying out the center alignment and manual tightening of the flare nut, tighten the flare nut securely with a torque wrench (spanner).



\* Tightening torque must be as shown in the table below.

| Outer Diameter (ø) | A (mm) Rigid Flaring Tool |              | Torque N·m (kgf·cm) |
|--------------------|---------------------------|--------------|---------------------|
|                    | For R410A tool            | For R22 tool |                     |
| 6.35 (1/4")        | 0-0.5                     | 1.0          | 13.7-18.6 (140-190) |
| 12.7 (1/2")        | 0-0.5                     | 1.0          | 44.1-53.9 (450-550) |


#### CAUTION

- When removing flare nut of the indoor unit, first remove the nut of small diameter side. Otherwise the nut of big diameter side will fly out.
- Prevent water from entering into the piping when connecting.
- Be sure to tighten the flare nut to the specified torque with a torque wrench.
- If the flare nut is over-tightened, it may split after sometime and may cause refrigerant leak.
- When using a control valve, make sure that the packing is not deteriorated and avoid excessive tightening of the handle. Otherwise, gas may leak from the service valve.


### 3. Remove of Air from the Pipe and Gas Leakage Inspection

From the viewpoint of global environment protection, air purge type should be vacuum pump method.

- Fully tighten the "H" shuttle of the manifold valve and completely unscrew the "Lo" shuttle. Run the vacuum pump. (Adapter is switched on)
- After pumping for about 10-15 minutes, completely loosen the "Lo" shuttle and switch off the vacuum pump. (Adapter is switched off)




- Remove the valve head cap of the service valve.
- Remove the cap of valve core and connect the charge hose.
- Connect the vacuum pump adapter to the vacuum pump and connect the charge hose to the adapter.
- Loosen the spindle of the service valve with small diameter by 1/4 turn and tighten the spindle immediately after 5 to 6 seconds.
- Remove the charging hose from the service valve.
- Unscrew the spindle of both the service valves in anticlockwise direction to allow the flow of refrigerant (unscrew halfway).
- Tighten the cap of valve head. Check and make sure that there is no gas leakage.



### Gas Leakage Inspection


Please use gas leakage detector to check if leakage occurs at connection of Flare nut as shown on the right.  
If gas leakage occurs, further tighten the connection to stop leakage. (Be sure to use R410A detector.)




### Works to be done when transferring or removing air conditioner

- From the viewpoint of global environment protection, refrigerant should be recovered (pumped down) when the air conditioner is transferred or removed.
- Perform force-cooling operation (refer to "Force-cooling operation" on page 12) for about 5 minutes as a preliminary operation.
- Tighten the spindle of the service valve at small diameter side in clockwise direction.
- Continue the force-cooling operation for another 1-2 minutes, and then tighten the spindle of the service valve at large diameter side in clockwise direction.
- Stop the force-cooling operation.

### Procedures of Wiring



### Detail of Cutting the Connecting Cord




#### WARNING

- If the supply cord is damaged, it must be replaced by a special cord (Maker's service parts) available from the manufacturer or its service agent.
- The naked part of the wire core should be 10mm fix it to the terminal tightly. Then try to pull the individual wire to check if the contact is tight. Improper insertion may burn the terminal.
- Be sure to use only wire specified for the use of air-conditioner.
- Be sure to use only power cables approved from the authorities in your country. For example in Germany: Cable type: NYM 3x1.5mm<sup>2</sup>. (Fuse = 25A time delay)
- Please refer to the manual for wire connection, the wiring technique should meet the standard of the electrical installation.
- Leave some space in the connecting cord for maintenance purpose and be sure to secure it with the cord band.
- Secure the connecting cord along the coated part of the wire using the cord band. Do not exert pressure on the wire as this may cause overheating or fire.
- There is a AC voltage of 220-230V between the L and N terminals. Therefore, before servicing, be sure to remove the plug from the AC outlet.

#### Wiring of the Indoor Unit

- Remove the front panel. (Refer to "Removing and Attaching the Front Panel" on page 13)
- Remove the terminal cover and screw, hold the upper part when removing.
- Bring the connecting cord from the rear surface to the front surface through the cable guide.
- The connecting cord should be fix with the terminal. Tightening torque reference value: 1.2-1.6N·m (12-16kgf·cm) Excessive tightening may damage the terminal.
- Connect the connecting cord and fix with cord band.
- Hook onto the claw at the lower part of the terminal cover and fix with screw.




### Wiring of the Outdoor Unit

Please remove the side cover and terminal cover for wiring connection.

#### WARNING

- When the fuse (F5 or F6) has been blown out by the improper connection of power cable, it can be restored by the attached reserve fuse. Please exchange the blown-out fuse after making sure the right connection.
- The connecting cord must be fix with cord band  
Otherwise rain water may enter and cause short circuit. Besides, an external force may apply to the connection part of the connecting cord and could result in heat and fire.
- The terminal cover and side cover must be installed after work is done.




| IMPORTANT           |                    |
|---------------------|--------------------|
| Fuse Capacity       |                    |
| 25A time-delay fuse |                    |
| Wire length         | Wire cross-section |
| up to 6m            | 1.5mm <sup>2</sup> |
| up to 15m           | 2.5mm <sup>2</sup> |
| up to 20m           | 4.0mm <sup>2</sup> |

- Outdoor supply cords shall not be lighter than polychloroprene sheathed flexible cord with code designation 60245 IEC 57.

#### CAUTION

### 1. Heat Insulation and Finishing of Piping

- Cover the pipe connection with the auxiliary insulation sheet, wrap the tape without any gap.
- If there is gap or over-tightened, it may cause condensation.
- Please wrap the pipe and power cord together with vinyl tape as shown in the figure of the installation of indoor and outdoor units on page 2.
- To enhance the heat insulation and to prevent water condensation, please cover the outdoor part of the drain hose and pipe with insulation sheet.
- When using an exit cover, do not attach a bush for pipe.
- When an exit cover is not used, seal the gap of the hole on the wall, bush and pipe completely with putty. If an exit cover is used, seal the gap of the hole on the wall and pipe completely with putty. In the case of embedded piping, seal the gap of the pipe completely with putty. Incomplete sealing could cause entering of high humidity air into the wall or indoor unit, which could result in dripping of dew. It could also cause smell or odor present outdoor and inside the wall spreading into the room.




#### CAUTION

- Completely seal any gap with putty  
High humidity air inside the wall or the outdoor may go in to the room and could result in dripping of dew. It could also cause smell or odor present outdoor and inside the wall spreading into the room.

### 2. Affixing the Remote Controller and Installing the Anti-mold Wasabi Cassette


- Procedures to fix the holder of remote control.
- Drill holes on wall. Push plug into the holes. (As shown below)



The remote controller must be slide in the remote controller holder, in the direction as shown in the figure, until it hooks at the lower end of the remote controller holder.


#### Installation Of Remote Controller

- The remote controller can be placed in its holder which is fixed on wall or beam.
- To operate the remote controller at its holder, please ensure that the unit can receive signal transmitted from the controller at the place where the holder is to be when signal is received from the remote controller. The signal transmission is weakened by the fluorescent light. Therefore, during the installation of the remote control holder, please switch on the light, even during day time, to determine the mounting location of the holder.





### 3. Remove the Protection Sheet

- Remove the protection sheet on the display panel.



#### Operation test

- Please ensure that the air conditioner is in normal operating condition during the operation test.
- Explain to your customer about the proper operation procedures as described in the operation manual.
- If the indoor unit won't operate, check the cable for correct connection.
- Force-cooling operation  
When the temporary switch of the indoor unit is pressed for more than 5 seconds, the force-cooling operation starts. Use this mode when performing the failure diagnosis or collecting refrigerant into the outdoor unit.  
The Timer lamp flashes when force-cooling is in operation.  
Press the temporary switch again or use the remote controller to stop the force-cooling operation once this operation is completed.



#### CAUTION


- Do not operate the unit for more than 5 minutes while the spindle of the service valve is closed.

### Removing and Attaching the Front Panel

- Be sure to hold the front panel with both hands to detach and attach it.


Please refer to the operation manual on how to open and close the front panel.

#### Removing



- Push the end of the right-side arm outward to release the tab.
- Move the left-side arm outward to release the left tab, and then pull the panel towards you.

#### Attaching




- Insert the shaft of the left arm along the step on the unit into the hole.
- Securely insert the shaft of the right arm along the step on the unit into the hole.
- Make sure that the front panel is securely attached, and then close the front panel.

#### CAUTION

- When being installed or removed, the panel is likely to slide off.
- When lifting to open the panel, do not apply too much force. Otherwise, the panel may come off or malfunction may be caused.


### How to remove the panel frame

- Remove the front panel and the storage box.
- Unscrew screws of the terminal block cover, and remove the terminal block.
- Remove the screw cover below the panel frame, and unscrew the 7 screws from the panel frame.
- Insert the screw driver into the hole on the right upper part of the panel frame, and loosen the jaw.
- Hold the panel frame and pull it along the direction indicated by the arrow to remove it.



### Attaching the Front Cover

- Make sure that the dew receiving pan and the cleaning unit are securely attached.
- After attaching the left and right sides of the front cover onto the unit, ensure that the top tabs (2 places) have been fixed on.
- Tighten the 7 screws in the panel.
- Install the terminal block cover, and tighten the screws.
- Install the screw cover.
- Install the storage box and the panel.



#### How to connect the optional parts

- For cable connection to control P.W.B., you need to remove front cover and electrical box cover. Each connecting location is as below.
- Dry contact CN6
- H-LINK-CN7
- Wired Remote Controller : CN21
- Please check and confirm manuals attached to each optional parts for more connection details.
- You can refer to this installation manual how to remove and re-attach the front cover.
- Please be careful not to damage lead wires by edge of plate when connecting the optional parts.

