


Service

Manual

Heat Recovery Ventilation



[Applied Models]

VAM 150FJVE

VAM 250FJVE

VAM 350FJVE

VAM 500FJVE

VAM 650FJVE

VAM 800FJVE

VAM1000FJVE

VAM1500FJVE VAM2000FJVE

Heat Recovery Ventilation



VAM 150FJVE VAM 250FJVE VAM 350FJVE VAM 500FJVE VAM 650FJVE VAM 800FJVE VAM1000FJVE VAM1500FJVE VAM2000FJVE

Table of Contents

	Introduction 1.1 Safety Cautions	
Part 1	General Constructions	1
	General Constructions 1.1 Explanation	
Part 2	Product Specification	5
	Product Specification 1.1 Specification	6 6
Part 3	Operation	9
	Operation	10
	for Air Conditioning Operation HRV Units. (BRC301B61)	
Part 4	Maintenance	15
	1. Maintenance	
	1.1 Maintenance for The Air Filter	
	1.2 Maintenance for The Heat Exchange Element	19
Part 5	Control Functions	21
	1. Control Functions	22
	1.1 List of Control Functions	22
	1.2 Explanation of Individual Functions	
	1.3 Layout of switches on Printed Circuit Board	28
Part 6	Circuit Operations	29
	1. Circuit Operations	30
	1.1 Circuit Configuration	
	1.2 Circuit Functions	31
Part 7	Troubleshooting	33
	1. Troubleshooting	
	1.1 Error Code Indication	
	1.2 Overall Alarm	
	1.3 Overall Malfunction	
	1.4 Indoor Air Thermistor Error	
	1.6 Damper System Error (Alarm)	
	1.7 Damper System Error (Alarm)	
	1.8 Dedicated LCD Remote Controller	
	1.9 Data Transmission Error	
	(Between LCD Remote Controller and Main Unit)	
	1.10 Data Transmission Error (LCD Remote Controller)	43

	1.11 Data Transmission Error (Between LCD Master Remote Controller	
	and Slave Remote Controller)	44
	1.12 Field Setting Error	45
	1.13 Overlapping Central Control Address	46
	1.14 Main Unit PCB Assembly	47
	1.15 Dedicated LCD Remote Controller	48
	1.16 How to Check	49
	1.17 Thermistor	50
	1.18 Power Transformer	
	1.19 Damper Motor	
Part 8	Supplementary Explanation	.53
	Supplementary Explanation	54
	1.1 Field Setting, Service Mode Operation	
Dowt O	Ammondia	GE
Part 9	Appendix	.03
	1. Appendix	66
	1.1 Wiring Diagram	
		_
Index		I
Drawir	ngs & Flow Charts	V

iv Table of Contents

SiE00-01 Introduction

1. Introduction

1.1 Safety Cautions

Cautions and Warnings

Be sure to read the following safety cautions before conducting repair work.

■ The caution items are classified into " ★ Warning" and " ★ Caution". The " ★ Warning" items are especially important since they can lead to death or serious injury if they are not followed closely. The " ★ Caution" items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.

■ About the pictograms

This symbol indicates an item for which caution must be exercised. The pictogram shows the item to which attention must be paid.

This symbol indicates a prohibited action.

The prohibited item or action is shown inside or near the symbol.

- This symbol indicates an action that must be taken, or an instruction. The instruction is shown inside or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer

Introduction SiE00-01

1.1.1 Cautions in Operation and Maintenance

A WARNING

A WARNING

Never inspect or service the unit by yourself.


Ask a qualified service person to perform this work.

(The qualified service person)


WARNING: Before obtaining access to terminal devices(\triangle), all power suppy circuit must be interrupted.

A WARNING

Do not change operations suddenly . It can result not only in malfunction but also fallure of switches or relays in the body.




Electric shock may result. Before servicing the unit, always shut off power.



WARNING

Always use the air filter.

If the air filter is not used, heat exchange elements will be clogged, possibly causing poor performance and subsequent failure.




SiE00-01 Introduction

A WARNING


A WARNING Do not use a HRV or an air suction/discahrge grille in the following places.


 Place such as machinery plant and chemical plant where gas, which contains noxius gas or corrosive components of materials such as acid,alkali,organic solvent and paint, is generated.
 Place where combustible gas leakage is likely.

Such gas can cause fire.




Avoid a place where the temperature near the HRV unit and the air suction/discharge air grille exceeds 50°C If the unit is used at high temperature, deformed air filter and heat exchange element or burned motor result.






Place such as bathroom subjected to moisture.

Electric leak or electric shock and other failure can be caused.



•Place subjected to much carbon black.

Carbon black attaches to air filter and heat exchange element, marking them unable to use.



Introduction SiE00-01

1.1.2 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.1.3 Using Icons List

Icon	Type of Information	Description
Note:	Note	A "note" provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
A Caution	Caution	A "caution" is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, get an unexpected result or has to restart (part of) a procedure.
Warning	Warning	A "warning" is used when there is danger of personal injury.
G	Reference	A "reference" guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1 General Constructions


1.	Gen	neral Constructions	2
	1.1	Explanation	2

General Constructions SiE00-01

1. General Constructions

1.1 Explanation


VAM150FJVE VAM250FJVE VAM350FJVE VAM500FJVE VAM650FJVE VAM800FJVE VAM1000FJVE



1	Ceiling Hock	2	Duct Connection Flange
3	Exhaust Fan	4	Air Filter (Long Life Filter)
5	Damper	6	Switch Box
7	Maintenance Cover	8	Heat Exchange Elements
9	Name Plate	10	Air Supply Fan
11	Remote Controller (Option Parts)	12	Damper Motor
13	EA (Exhaust Air) [Exhaust Air to Outdoor]	14	OA (Outdoor Air) [Fresh Air from Outdoor]
15	Maintenance Space for The Air Filters, Heat Exchange Elements and Switch Box	16	RA (Return Air) [Exhaust Air from Room]
17	SA (Supply Air) [Feed Air to Room]		

SiE00-01 General Constructions

VAM1500FJVE VAM2000FJVE



1	Ceiling Hock	2	Duct Connection Flange
3	Exhaust Fan	4	Air Filter (Long Life Filter)
5	Damper	6	Switch Box
7	Maintenance Cover	8	Heat Exchange Elements
9	Name Plate	10	Air Supply Fan
11	Remote Controller (Option Parts)	12	Damper Motor
13	EA (Exhaust Air) [Exhaust Air to Outdoor]	14	OA (Outdoor Air) [Fresh Air from Outdoor]
15	Maintenance Space for The Air Filters, Heat Exchange Elements and Switch Box	16	RA (Return Air) [Exhaust Air from Room]
17	SA (Supply Air) [Feed Air to Room]		

General Constructions SiE00-01

Part 2 Product Specification

1.	Prod	duct Specification	6
	1.1	Specification	6

Product Specification SiE00-01

1. Product Specification

1.1 Specification

(50 / 60Hz)

Model Name				VAM150FJVE	VAM250FJVE	VAM350FJVE	
Power Supply				Siı	ngle Phase 220 – 240 V / 220 V, 50 / 60	Hz	
Temperature	Exchanging	Ultra-High	%	74 / 74	72 / 72	75 / 75	
Efficiency		High	%	74 / 74	72 / 72	75 / 75	
		Low	%	79 / 80	77 / 77	80 / 81	
Enthalpy	Cooling	Ultra-High	%	58 / 58	58 / 58	61 / 61	
Exchange Efficiency		High	%	58 / 58	58 / 58	61 / 61	
Linciency		Low	%	64 / 66	62 / 63	67 / 68	
	Heating	Ultra-High	%	64 / 64	64 / 64	65 / 65	
		High	%	64 / 64	64 / 64	65 / 65	
		Low	%	69 / 71	68 / 69	70 / 71	
Casing					Galvanized Steel Plate	•	
Insulating Mat	erial				Self-extinguishable Urethane Foam		
Dimensions		HxWxD	mm	269 x 760 x 509	269 x 760 x 509	285 x 812 x 800	
Heat Exchang	ing System				Flow Total Heat (Sensible Heat + Latent	, 0	
Heat Exchang	ing Element			Specially Processed Nonflammable Paper			
Air Filter				Multidirectional Fibrous Fleeces			
Fan	Туре			Sirroco Fan			
	Fan	Ultra-High	m³/h	150 / 150	250 / 250	350 / 350	
	Speed	High	m³/h	150 / 150	250 / 250	350 / 350	
		Low	m³/h	110 / 110	155 / 145	230 / 210	
	External	Ultra-High	Pa	69 / 98	64 / 98	98 / 142	
	Static Pressure	High	Pa	39 / 54	39 / 54	70 / 85	
	i lessure	Low	Pa	20 / 24	20 / 20	25 / 15	
Fan Motor			Type	Open Type Capa	acitor Permanent Split-phase Induction M	lotor, 4 Poles x 2	
Motor Output			kW	0.030 x 2	0.030 x 2	0.090 x 2	
Operating	Heat	Ultra-High	dBA	27 - 28.5 / 28.52	28 - 29 / 29.5	32 - 34 / 34.5	
Sound	Exchange Mode	High	dBA	26 - 27.5 / 26.5	26 - 27 / 26	31.5 - 33 / 32	
	Wode	Low	dBA	20.5 - 21.5 / 19	21 - 22 / 19.5	23.5 - 26 / 22	
	Byapss	Ultra-High	dBA	27 - 28.5 / 28	28 - 29 / 29	32 - 34 / 34.5	
	Mode	High	dBA	26.5 - 27.5 / 27	27 – 28 / 27	31 - 32.5 / 33	
		Low	dBA	20.5 - 21.5 / 20	21 - 22 / 20.5	24.5 - 26.5 / 22	
Operation Range (Ambient)					- 10°C to 50°CDB (80% RH or Less)	-	
Connection D	uct Diameter		mm	φ 100	φ 150	φ 150	
Weight			kg	24	24	33	
Drawing Num	ber			4D020371A	4D020372A	4D020373A	

Test conditions are as follows

On all the	Indoo	or unit	Outdoor unit		
Condition	°CDB	R.H (%)	°CDB	R.H (%)	
Cooling condition	27	50	35	60	
Heating condition	20	40	7	70	

Notes:

- 1. Operation sound is measured at 1.5 m below the center the body.
- 2. Fan speed can be changed over to Low mode or High mode.
- Operating sound is measured in an anechoic chamber.
 Operating sound level generally become greater than this value depending on the operating conditions, reflected sound, and peripheral noise.
- 4. The sound level at the air discharge port is about 8 dB higher than the unit's operating sound.

SiE00-01 Product Specification

(50 / 60Hz)

Model Name)			VAM500FJVE	VAM650FJVE	VAM800FJVE	
Power Suppl	у			Siı	ngle Phase 220 – 240 V / 220 V, 50 / 60	Hz	
Temperature	Exchanging	Ultra-High	%	74 / 74	74 / 74	74 / 74	
Efficiency		High	%	74 / 74	74 / 74	74 / 74	
		Low	%	77 / 78.5	77 / 78	76 / 76	
Enthalpy	Cooling	Ultra-High	%	58 / 58	58 / 58	60 / 60	
Exchange Efficiency		High	%	58 / 58	58 / 58	60 / 60	
Efficiency		Low	%	63 / 65.5	63 / 65	62 / 63	
	Heating	Ultra-High	%	62 / 62	63 / 63	65 / 65	
		High	%	62 / 62	63 / 63	65 / 65	
		Low	%	67 / 68.5	66 / 68	67 / 68	
Casing	•	•	•		Galvanized Steel Plate		
Insulating Ma	nterial				Self-extinguishable Urethane Foam		
Dimensions		HxWxD	mm	285 x 812 x 800	348 x 988 x 852	348 x 988 x 852	
Heat Exchan	ging System	•	•	Air to Air Cross Flow Total Heat (Sensible Heat + Latent Heat) Exchange			
Heat Exchan	ging Element			Specially Processed Nonflammable Paper			
Air Filter				Multidirectional Fibrous Fleeces			
Fan	Туре			Sirroco Fan			
	Fan	Ultra-High	m³/h	500 / 500	650 / 650	800 / 800	
	Speed	High	m³/h	500 / 500	650 / 650	800 / 800	
		Low	m³/h	350 / 300	500 / 440	670 / 660	
	External	Ultra-High	Pa	98 / 147	93 / 162	137 / 225	
	Static Pressure	High	Pa	54 / 54	39 / 69	98 / 118	
	T TC33GTC	Low	Pa	25 / 20	25 / 34	49 / 69	
Fan Motor			Type	Open Type Capa	acitor Permanent Split-phase Induction M	lotor, 4 Poles x 2	
Motor Output			kW	0.090 ∞ 2	0.140 ∞ 2	0.230 ∞ 2	
Operating	Heat	Ultra-High	dBA	33 - 34.5 / 34	34.5 - 35.5 / 36	36 - 37 / 37	
Sound	Exchange Mode	High	dBA	31.5 - 33 / 31	33 - 34 / 33	34.5 - 36 / 35	
	Wiode	Low	dBA	24.5 - 26.5 / 24	27 - 28 / 27	31 - 32 / 30	
	Byapss	Ultra-High	dBA	33.5 - 34.5 / 35	34.5 - 35.5 / 35.5	36 - 37 / 37	
	Mode	High	dBA	32.5 - 33.5 / 33	34 - 35 / 34	34.5 - 36 / 35	
		Low	dBA	25.5 - 27.5 / 24	27 - 28.5 / 27	31 - 33 / 31	
Operation Range (Ambient)					- 10°C to 50°CDB (80% RH or Less)		
Connection D	Ouct Diameter		mm	ф 200	ф 200	ф 250	
Weight			kg	33	48	48	
Drawing Number				4D020374A	4D020375A	4D020376A	

Test conditions are as follows

Condition	Ind	oor	Outdoor		
Condition	°CDB	R.H (%)	°CDB	R.H (%)	
Cooling condition	27	50	35	60	
Heating condition	20	40	7	70	

Notes:

- Operation sound is measured at 1.5 m below the center the body.
- 2. Fan speed can be changed over to Low mode or High mode.
- Operating sound is measured in an anechoic chamber.
 Operating sound level generally become greater than this value depending on the operating conditions, reflected sound, and peripheral noise.
- 4. The sound level at the air discharge port is about 8 dB higher than the unit's operating sound.

Product Specification SiE00-01

(50 / 60Hz)

Model Name	9			VAM1000FJVE	VAM1500FJVE	VAM2000FJVE	
Power Suppl	ly			Siı	ngle Phase 220 – 240 V / 220 V, 50 / 60	Hz	
Temperature	Exchanging	Ultra-High	%	75 / 75	75 / 75	75 / 75	
Efficiency		High	%	75 / 75	75 / 75	75 / 75	
		Low	%	76.5 / 78	78 / 78	78 / 78	
Enthalpy	Cooling	Ultra-High	%	61 / 61	61 / 61	61 / 61	
Exchange Efficiency		High	%	61 / 61	61 / 61	61 / 61	
Efficiency		Low	%	63 / 66	64 / 64	66 / 66	
	Heating	Ultra-High	%	66 / 66	66 / 66	66 / 66	
		High	%	66 / 66	66 / 66	66 / 66	
		Low	%	68 / 71	68 / 68	70 / 70	
Casing		•	•		Galvanized Steel Plate		
Insulating Ma	aterial				Self-extinguishable Urethane Foam		
Dimensions		$H \infty W \infty D$	mm	348 x 988 x 1140	710 x 1498 x 852	710 x 1498 x 1140	
Heat Exchan	nging System			Air to Air Cross	Air to Air Cross Flow Total Heat (Sensible Heat + Latent Heat) Exchange		
Heat Exchan	nging Element			Specially Processed Nonflammable Paper			
Air Filter				Multidirectional Fibrous Fleeces			
Fan	Туре			Sirroco Fan			
	Fan	Ultra-High	m∏/h	1000 / 1000	1500 / 1500	2000 / 2000	
	Speed	High	m∏/h	1000 / 1000	1500 / 1500	2000 / 2000	
		Low	m∏/h	870 / 800	1200 / 1200	1400 / 1400	
	External	Ultra-High	Pa	157 / 196	137 / 206	137 / 196	
	Static Pressure	High	Pa	98 / 108	98 / 118	78 / 88	
	1 1033uic	Low	Pa	78 / 69	49 / 69	59 / 69	
Fan Motor	•	•	Type	Open Type Capa	icitor Permanent Split-phase Induction M	otor, 4 Poles ∞ 2	
Motor Output			kW	0.230 ∞ 2	0.230 ∞ 4	0.230 ∞ 4	
Operating	Heat	Ultra-High	dBA	36 – 37 / 37	39.5 – 41.5 / 40.5	40 – 42.5 / 41	
Sound	Exchange Mode	High	dBA	35 – 36 / 35	38 – 39 / 38	38 – 41 / 38	
	Wode	Low	dBA	31 – 32 / 30	34 – 36 / 33	35 – 37 / 35	
	Byapss	Ultra-High	dBA	36 – 37 / 37	40.5 – 41.5 / 40.5	40 – 42.5 / 41	
	Mode	High	dBA	35.5 – 36 / 35	38 – 39 / 38	38 – 41 / 38	
		Low	dBA	31 – 32 / 31	33.5 – 36 / 33	35 – 37 / 35	
Operation Range (Ambient)					- 10°C to 50°CDB (80% RH or Less)		
Connection I	Duct Diameter		mm	ф 250	ф 350	ф 350	
Weight			kg	61	132	158	
Drawing Number				4D020377A	4D020526A	4D020527A	

Test conditions are as follows

Condition	Indoo	or unit	Outdoor unit			
Condition	°CDB	R.H (%)	°CDB	R.H (%)		
Cooling condition	27	50	35	60		
Heating condition	20	40	7	70		

Notes:

- Operation sound is measured at 1.5 m below the center the body.
- 2. Fan speed can be changed over to Low mode or High mode.
- Operating sound is measured in an anechoic chamber.
 Operating sound level generally become greater than this value depending on the operating conditions, reflected sound, and peripheral noise.
- The sound level at the air discharge port is about 8 dB higher than the unit's operating sound.

Part 3 Operation

1.	Ope	ration	.10
		Explanation for Systems	
		Operation with The Remote Control for	
		Air Conditioning Operation HRV Units. (BRC301B61)	11

Operation SiE00-01


1. Operation

1.1 Explanation for Systems

This product is operated differently depending on the system configuration.

For the operation of the remote controller for indoor unit and centralized controller, refer to the instruction manual provided with each unit.

■ Operation for Each System



SiE00-01 Operation


1.2 Operation with The Remote Control for Air Conditioning Operation HRV Units. (BRC301B61)


For non-independent systems, starting/stopping operation and timer operation may not be possible. Use the air conditioner remote control or the Centralized controller in such cases.


Operation for INDIVIDUAL SYSTEM

- 1. Operation lamp
 - This pilot lamp (red) light up while the unit is in Operation.
- 2. Operation/Stop button
 - When pushed once, the unit starts operating.
 - When pushed twice, the unit stops.
- 3. Air flow rate changeover button

Remote Controller for HRV BRC301B61







For "Freshup" operation

When this indication does not show: The volume of outdoor air supplied into the room and that of the room air exhausted outdoors is equivalent.

For "Freshup" operation,

- If it is set to "Fresh up air supply": The volume of outdoor air supplied into the room is larger than that of room air exhausted outdoors.
 - (This operation prevents the odor and moisture from kitchens and toilets from flowing into the rooms.
- If it is set to "Fresh up air exhaust": The volume of room air exhausted outdoors is larger than that of outdoor air supplied into the room.

(This operation prevents the hospital odor and floating bacteria from flowing out to the corridors.)

SiE00-01 Operation

- 4. Ventilation mode changeover: button
 - " (Automatic) mode The temperature sensor of the unit automatically changes the ventilation of the unit in [Bypass] mode and [Heat Exchange] mode.
 - " (Heat Exchange) mode In this mode, the air passes through the heat exchange element to effect [Total Heat Exchanging] ventilation.
 - " (Bypass) mode In this mode, the air does not pass through the heat exchange element but bypasses it to effect [Bypass] ventilation.
- 5. Indication of operation control method:

When the operation of HRVs are linked with the air conditioners, this indication may be shown. While the indication is shown, the ON/OFF of HRVs cannot be operated by the HRV remote controller.

6. Indication of operation standby: (*)

It indicates the precooling/preheating operation. This unit is at stop and will start operation after the precooling/preheating operation is over.

Precooling/preheating operation means the operation of HRVs is delayed during the startup operation of linked air conditioners such as before the office hours. During this period the cooling or heating load is reduced to bring the room temperature to the set temperature in a short time.

7. Indication of centralized control: 人

When a remote controller for air conditioners or devices for centralized control are connected to the HRVs, this indication may show.

During this indication appears on the display, the ON/OFF and timer operation may not be possible with the HRV remote controllers.

8. Indication of air filter cleaning


When the indication " appears on the display, clean the filter.

- 9. Filter signal reset button
- 10. Inspection button

This button is to be used only for service. It is not to be used normally.

HOW TO OPERATE WITH TIMER

11. Push the button " $\frac{0\cdot 1}{0\cdot 0}$ " and select either one of " $\frac{1}{0\cdot 0}$ b $\frac{1}{0\cdot 0}$ " or " $\frac{1}{0\cdot 0}$ b $\frac{1}{0\cdot 0}$ " . Each time the button is pushed, the indication changes as shown below.



12. Push the button " 🏺 " and set the time.

Each time when " *\(\bigsim \) " is pushed, the time advances one hour.

Each time when " is pushed, the time goes back one hour.

13. Push the button " i. .

Then, the reservation is finished.

Either " ← or " ← | " changes from flashing to lighting.

After the reservation is finished, the remaining time is indicated in the display.

For cancelling the timer operation, push the button " a "once again."


The indication disappears.

SiE00-01 Operation

Operating The HRV Unit Using The Remote Controller of The VRV. System Air Conditioner When the VRV-system air conditioner is connected with the HRV unit with a direct duct, the remote controller of the air conditioner cannot be used to select the VENTILATION mode. To use the HRV unit without operating the air conditioner, set the air conditioner in the FAN VENTILATION mode and select the low fan speed.


- 1. Operation lamp
- 2. Operation/stop button
- 3. Operation mode display
- 4. Operation mode selector

Remote Controller for VRV BRC1A61-62



■ Every time the operation mode selector is pressed, the operation mode display changes as shown below.

(example)



■ When the #FILTER" indication appears on the display, clean the filter of the HRV unit.

Independent
Operation of The
HRV Unit Using The
Centralized
Controller
(DCS302B61)

- After selecting the zone where the only the HRV unit operation is desired, press the operation mode selector and select "

 " VENTILATION. The HRV unit can then be operated independently from the air conditioner.
- When the # "FILTER" indication apprears on the display, clean the filter of the HRV unit.

Operation SiE00-01

Part 4 Maintenance

1.	Mair	ntenance	16
	1.1	Maintenance for The Air Filter	16
	1.2	Maintenance for The Heat Exchange Element	19

Maintenance SiE00-01

1. Maintenance

1.1 Maintenance for The Air Filter



Caution


During operation, never check or clean the HRV. It may cause electrical shock and it is very dangerous to touch the rotating part. Be sure to turn off the OPERATION switch and disconnect the power.

■ CLEANING FREQUENCY

AT LEAST ONCE EVERY TWO YEARS (FOR GENERAL OFFICE USE) (CLEAN THE ELEMENT MORE FREQUENTLY IF NECESSARY.)


 Go into ceiling through the inspection hole, remove the hanging metals of maintenance cover and take it off.

VAM150~1000FJVE



1 Maintenance Cover 2 Binding Metal 3 Hanging Metal

VAM1500~2000FJVE



(HL004)


(HL003)

1	Maintenance Cover	2	Binding Metal
3	Hanging Metal		

SiE00-01 Maintenance

2. Take out the heat exchange elements from the unit body.


VAM150~1000FJVE



(HL013)

1	Heat Exchange Element (X2)	2	Handle
3	Rail	4	Filter x 2


VAM1500~2000FJVE



(HL014)

1	Heat Exchange Element (X4)	2	Handle
3	Rail	4	Filter x 4

3. To clean the air filter, lightly pat it with hand or remove dust with a vacuum cleaner. If excessively dirty, wash it in water.






(HL015)

4. If the air filter is washed, remove water completely and allow to dry Air filter for 20 to 30 minutes in the shade. When dried completely, install the air filter back in place.

Maintenance SiE00-01

5. Install the maintenance cover securely in place.





- 1. Do not wash the air filter in hot water.
- 2. Do not dry the air filter over a fire.
- 3. Do not expose the air filter to direct sunlight.
- 4. Do not use organic solvent such as gasoline and thinner on the air filter.
- 5. Be sure to install the air filter after servicing.(Missing air filter causes clogged heat exchange element.)The air filter is an optional item and the replacement is available.


SiE00-01 Maintenance

1.2 Maintenance for The Heat Exchange Element

■ CLEANING FREQUENCY

AT LEAST ONCE EVERY TWO YEARS (FOR GENERAL OFFICE USE) (CLEAN THE ELEMENT MORE FREQUENTLY IF NECESSARY.)

- 1. Use a vacuum cleaner to remove dust and foreign objects on the surface of the heat exchange element.
- Use the vacuum cleaner equipped with a brush on the tip of the suction nozzle.
- Lightly contact the brush on the surface of the heat exchanging element when cleaning. (Do not crush the heat exchange element while cleaning.)
- 2. Install the air filter securely in place.
- 3. Put the heat exchange element on the rail and insert it securely in place.
- 4. Install the maintenance cover securely in place.



(HL060)



Never wash the heat exchanger element with water.

Maintenance SiE00-01

Part 5 Control Functions

1.	Con	trol Functions	22
	1.1	List of Control Functions	22
	1.2	Explanation of Individual Functions	23
	1.3	Layout of switches on Printed Circuit Board	28

Control Functions SiE00-01

1. Control Functions

1.1 List of Control Functions

Classification	Function name	Outline of function			
Basic functions (functions related to basic performance)	1.1 Ventilation operation control function	Controls supply air fan motor, exhaust air fan motor and damper motor.			
	1.2 Abnormality control function	Detects abnormalities in thermistor, damper motor and data transmission to prevent errors.			
2. Additional functions	2.1 Ventilation mode changeover function	Operates equipment in selected ventilation mode (total heat exchange, normal, automatic).			
	2.2 Automatic ventilation operation function	Selects the most suitable ventilation mode by controlling damper motor according to temperature controller mode, temperature setting and thermistor data.			
	2.3 Ventilation capacity changeover function	Operates equipment at set airflow rate.			
	2.4 Humidifier operation control function	Controls humidifier output based on temperature controller judgment. Note 1			
	2.5 Pre-cool/pre-heat function	Prevents equipment operation for a preset time (set time) after air conditioner is turned on.			
	2.6 Freshup function	Sets motor tap so that supply air fan airflow rate is larger thar exhaust air fan airflow rate.			
	2.7 Filter sign function	Stores cumulative operation hour data and turns on air filter cleaning indicator.			
3. System control functions	3.1 Remote controller function	Operates equipment according to instructions from remote controller.			
	3.2 Group function	Operates two or more units based on instructions from single remote controller.			
	3.3 Air conditioner link function	Follows air conditioner ON/OFF instructions.			
	3.4 Power ON operation function	Operates equipment when power is turned on.			
	3.5 External link operation function	Turns equipment on and off according to external link terminal signal (no-voltage contact a).			
	3.6 Centralized control function	Allows remote control operation by centralized control equipment.			
	3.7 Timer function	Turns equipment on and off at set time.			
4. Other support functions	4.1 Troubleshooting function	Displays error codes to indicate locations of error.			
	4.2 Field setting function	Allows initial setting from LCD remote controller.			



Note 1

Requires optional humidifier and optional printed circuit board (KRP50-2: Wiring adapter for remote contact).

SiE00-01 Control Functions


1.2 Explanation of Individual Functions

1.2.1 Ventilation Operation Control

Controls ventilation fan motors (supply and exhaust air fans) and damper motor.


1) Normal operation

Operation chart



(HL020)

2) Direct duct connection with air conditioner Operation chart



(HL021)

Note:

Direct duct connection setting can be made in VRV system or using field setting mode of HRV LCD remote controller.

Control Functions SiE00-01

1.2.2 Pre-cool/Pre-heat

Pre-cool/pre-heat operations require the following conditions.

1. System


Pre-heat operation is possible only in air conditioner linked system (1 group, 2-group link). Check the system first.

2. Heat recovery ventilation setting

Set Preheat ON/OFF to ON.

Pre-cool/pre-heat On/OFF setting can be made in air conditioner or using field setting mode of LCD remote controller of heat recovery ventilation unit. (Pre-cool time can be set between 30 and 60 min, and pre-heat time can be set between 30 and 150 min.)

- 3. Others
 - a) Heat recovery ventilation unit must be in non-operating condition for two consecutive hours or more prior to pre-cool/pre-heat operation.
 - b) Temperature control mode of the air conditioner must be set to Cool, Heat or Dry.



(HL022)

Note:


Operation standby indication is displayed only on LCD remote controller of heat recovery ventilation unit.

SiE00-01 Control Functions

1.2.3 Cold Area Mode

Stops or lowers ventilation airflow during defrosting operation and compressor non-operating condition when equipment in heating mode, thus reducing heating load and cold air draft.

Operation chart (in heating operation only)



(HL023)

Note


Cold area mode can set using remote controller for air conditioner or field setting mode of LCD remoter controller of heat recovery ventilation unit.

1.2.4 Air Conditioner Link Operation

Link system enables simultaneous ON/OFF operation of heat recovery ventilation unit and air conditioner (VRV system, Skyair).

1) 1 group link control


- Allows simultaneous ON/OFF from remote controller for air conditioner.
- Allows independent operation of heat recovery ventilation unit from VRV-system remote controller during interim periods (not possible when direct duct connection is used).
- ON/OFF operation is not possible from LCD remote controller of heat recovery ventilation unit.



Control Functions SiE00-01

2) Link control of 2 or more groups (zone link)

- Heat recovery ventilation unit can be operated when one or more air conditioners are operating.
- Allows independent operation of heat recovery ventilation unit from VRV-system remote controller during interim periods (direct duct connection is not allowed in this system).
- ON/OFF operation is not possible from LCD remote controller of heat recovery ventilation unit.





Note: With Super Wiring, units of different outdoor systems can be linked in operation.

1.2.5 Field Setting, Service Mode

1. Field setting

Used for initial setting of heat recoveryw ventilation unit.

2. Service mode

Used for confirmation of unit Nos. in the group and reallocation of unit Nos.

List of Field Setting and Service Mode

Details of setting	Mode	Setting	Setting		Setting position					
		mode	switch No.	01	02	03	04	05	06	
Group No. setting for centralized controller (individual)	Field setting	00(30)								Refer to P55
Filter cleaning time setting		17(27)	0	Approx. 2500 hr.	Approx. 1250 hr.	No counting	_	_	_	
Pre-cool/pre-heat On/Off setting			2	Off	On	_	_	_	_	Refer to P54
Pre-cool/pre-heat time (min.) setting			3	30 min.	45 min.	60 min.		_	_	
Fan speed initial setting			4	Normal	Ultra-High	_	_	_	_	
Yes / No setting for direct duct Connection with VRV system			5	No duct (Air flow setting)	With duct (fan off)	_	_	_	_	
Setting for cold				_	_	No d	luct	With	duct	
areas (Fan operaiton selection for heater thermostat OFF)						Fan off	Fan L	Fan off	Fan L	
Centralized / individual setting			7	Centralized	Individual	_	_	_	_	
Centralized zone interlock setting			8	No	Yes	Priority on Operation	_	_	_	
Pre-heat time extension setting			9	0	30 min.	60 min.	90 min.	_	_	
External signal setting JC / J2		18(28)	0	Last command	Priority on external input	_	_	_	_	
Setting for direct power-on			1	Off	On	_	_	_	_	
Auto restart setting			2	Off	On					

SiE00-01 Control Functions

Details of setting	Mode	Setting	Setting		Setting position					
		mode	switch No.	01	02	03	04	05	06	
Indication of ventilation mode / Not indication	Field setting	18(28)	4	Indication	No Indication	_	_	_	_	Refer to P54
Fresh up air supply / exhaust			7	No Indication	No Indication	Indication	Indication	_	_	
setting				Supply	Exhaust	Supply	Exhaust	_	_	
External input terminal function selection (between J1 and JC)			8	Fresh up	Overall alarm	Overall malfunction	Forced off	Fan forced off	Air flow increase	
KRP50-2 output switching selection (between 1 and 3)			9	Humidify	Abnormal	Fan on / off	_	_	_	
Air flow setting		19(29)	0	Low	Low	Low	Low	High	High	
Ventilation mode setting			2	Automatic	Total heat exchange	Normal	_	_	_	
Fresh up operation			3	OFF	ON	_	_	_	_	
Electric heater setting			8	No delay	No delay	ON / OFF Delay	ON/OFF Delay	_	_	Refer to E/D "INSTALLATION MANUAL"
Error record display	Service	40								Refer to operation manual for remote controller of air conditioner
Forced ventilation fan On		43								Refer to P56
Unit No. allocation		45								Refer to P57



1. All the setting can be made by the remote controller for VRV and HRV unit.

The setting of mode No. 19 (29) and 40 can be made only by the remote controller for VRV unit. The mode No. 30 is used for the individual setting such as the calculation of power bill, etc.

- 2. The mode No. in () is used for making individual setting of each unit.
- 3. Group number setting for centralized controller
 - 1. Mode no. 00: Group controller
 - 2. Mode no. 30: Individual controller
 - * Regarding the setting procedure, refer to the section "Group number setting for centralized control" in the operating manual of either the on / off controller or the central controller.



Caution


1. The setting positions are set at "01" at the factory.

The ventilation air flow, however, is set at "05" (medium) in the HRV unit. When lower or higher setting is desired, change the setting after installation.

Control Functions SiE00-01

1.3 Layout of switches on Printed Circuit Board

1.3.1 Printed Circuit Board



1.3.2 Function of main connection terminal

Т	erminal No.	Contents of function
Power supply	L N TeS1	Single phase 220 – 240 V 50Hz Single phase 220 – 220 V 60Hz Power supply and earth terminal
Remote controller	P1 P2	Connection terminal for remote controller for HRV unit. This terminal is used to receive information of the indoor unit for interlocked operation.
Centralized control	F1 F2	This terminal is used to receive information when centralized controller is connected.
Input from outside	J1 J2 JC	Between terminal no. (J1) ~ (JC) Used for "fresh up operation" by external input. Between terminal no. (J2) ~ (JC) Used for Operation / Stop by external input.

(HC0043)

28 Control Functions


Part 6 Circuit Operations

1.	Circ	uit Operations	.30
	1.1	Circuit Configuration	. 30
	1.2	Circuit Functions	. 31

Circuit Operations SiE00-01

1. Circuit Operations

1.1 Circuit Configuration



(HL026)

SiE00-01 Circuit Operations

1.2 Circuit Functions

Classification	Circuit	Function
Input/output	Central data transmission interface	Used by centralized control equipment for operation control. Allows control of up to 64 groups of air conditioners and heat recovery ventilation units. Use of KRP2A61 allows zone link operation.
	Remote control data transmission interface	Use of dedicated LCD remote controller allows control of up to 16 heat recovery ventilation units. Also used for linked operation of air conditioners of 2 groups.
	Air conditioner link operation	Connects to remote control line of air conditioner for linked operation.
Output	KRP50-2 interface	Can be used to output signals of operating condition and abnormalities to external equipment or to connect humidifier via KRP50-2.
	Relay drive circuit	Supplies drive voltage to relay coils.
	Fan motor, damper motor relay	Power supply relay for fan motor and damper motor.
Input	Thermistor interface	Uses thermistor (temperature sensor) to detect inside and outside temperatures.
	Airflow rate setting switch interface	Used to set airflow rate of main unit when dedicated remote controller is not used.
	External input interface	Used to control main unit with external contact point. (Freshup, external link operation, etc.)
	Damper limit switch interface	Sends signal of limit switch condition to microcomputer for damper motor cam positioning.
Peripheral Parts	Control microcomputer	Controls entire equipment by varying output according to input condition.
	EEPROM	Stores operating condition and address data.
Microcomputer	Microcomputer reset circuit	Resets microcomputer when power is turned on.
	Microcomputer oscillation circuit	Generates clock frequency for microcomputer operation.
Power Supply	Power transformer	Produces power supply of approx. 26 VAC from 220-240 VAC.
	Power supply circuit	Supplies direct currents (16 VDC, 5 VDC) to control circuits.

Circuit Operations SiE00-01


Part 7 Troubleshooting

1.	Trou	bleshooting	34
	1.1	Error Code Indication	. 34
	1.2	Overall Alarm	. 35
	1.3	Overall Malfunction	. 36
	1.4	Indoor Air Thermistor Error	. 37
	1.5	Outdoor Air Thermistor Error	. 38
	1.6	Damper System Error (Alarm)	. 39
	1.7	Damper System Error (Alarm)	. 40
	1.8	Dedicated LCD Remote Controller	. 41
	1.9	Data Transmission Error	
		(Between LCD Remote Controller and Main Unit)	. 42
	1.10	Data Transmission Error (LCD Remote Controller)	. 43
	1.11	Data Transmission Error (Between LCD Master Remote Controller	
		and Slave Remote Controller)	. 44
	1.12	Field Setting Error	. 45
	1.13	Overlapping Central Control Address	. 46
	1.14	Main Unit PCB Assembly	. 47
	1.15	Dedicated LCD Remote Controller	. 48
	1.16	How to Check	. 49
	1.17	Thermistor	. 50
	1.18	Power Transformer	. 51
	1.19	Damper Motor	. 52

1. Troubleshooting

1.1 Error Code Indication

When an abnormality is generated, take necessary measures by referring to displayed error code. After the cause of abnormality is removed, operate equipment and check proper functioning.



(HL027)

List of malfunction codes displayed by LCD remote controller

LCD Remote Controller Display						
Error Code	Operation Lamp	Inspection Indication	Unit No.	Description of Abnormality	Page	
60	ON	OFF	Blinking	Overall alarm	P35	
80	Blinking	Blinking	Blinking	Overall malfunction	P36	
64	ON	OFF	Blinking	Inside air thermistor error	P37	
65	ON	OFF	Blinking	Outside air thermistor error	P38	
6 <i>R</i>	ON	OFF	Blinking	Damper system alarm	P39	
6A	Blinking	Blinking	Blinking	Damper system + thermistor error	P40	
US	Blinking	Blinking	Blinking	Data transmission error between LCD remote controller and main unit	P42	
US	OFF	Blinking	OFF	FF LCD remote controller connection error		
U8	OFF	Blinking	OFF	OFF Data transmission error between master-slave LCD remote controllers		
UA	OFF	Blinking	OFF	LCD remote controller connection error (no remote controller for air conditioner in air conditioner group)		
UC	ON	ON	ON	Overlapping central control address	P46	
UE	Blinking	Blinking	Blinking	Transmission error between the unit and centralized controller	_	

In case of the mulfunction with the shaded error code, the unit still operates. However, be sure to have it inspected and repaired and as soon as possible.

1.2 Overall Alarm

Remote Controller LCD Display

Error Code **50** Inspection — Unit No.❖

LED Indication

Remote Controller ۞ Main Unit ۞

Error Detection Method

Abnormalities are detected based on open circuit in external input terminals (J1-JC).


Error Generating Conditions

When external input terminal (J1-JC) is shorted during operation ("Overall Alarm" must be set in field setting mode).

Possible Causes

- Faulty external device
- Broken wire
- Faulty control PCB

Troubleshooting



(HF001)

1.3 Overall Malfunction

Remote Controller LCD Display

Error Code **60** Inspection 🗘 Unit No. 🗘

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method

Errors are detected based on open circuit in external input terminals (J1-JC).


Error Generating Conditions

When external input terminal (J1-JC) is shorted during operation ("Overall Alarm" must be set in field setting mode).

Possible Causes

- Faulty external device
- Broken wire
- Faulty control PCB

Troubleshooting



36 Troubleshooting

(HF002)

1.4 Indoor Air Thermistor Error

Remote Controller LCD Display

Error Code **6** 4 Inspection — Unit No. 🌣

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method Temperature detected by inside air temperature sensor is used to detect errors.


Error Generating Conditions

When value detected by inside air temperature sensor is -40°C or below (open circuit) or 70°C or higher (shorting).

Possible Causes

- Faulty sensor
- Broken wire
- Faulty control PCB
- Faulty contact in connector

Troubleshooting



Note

Note 1:


Refer to the thermistor temperature - resistance conversion table when measuring resistance.

Thermistor temperature - resistance conversion table

Thermistor temperature	Sensor resistance	Thermistor temperature	Sensor resistance
-10°C or less	108kΩ or more	22°C	Approx. 23kΩ
-5°C	Approx. 85kΩ	24°C	Approx. 21kΩ
0°C	Approx. 66kΩ	26°C	Approx. 19kΩ
5°C	Approx. 51kΩ	28°C	Approx. 18kΩ
10°C	Approx. 40kΩ	30°C	Approx. 16kΩ
14°C	Approx. 33kΩ	35°C	Approx. 13kΩ
16°C	Approx. 30kΩ	40°C	Approx. 11kΩ
18°C	Approx. 27kΩ	50°C or more	7kΩ or less
20°C	Approx. 25kΩ		

If measured value deviates significantly from above values, thermistor is faulty.

Use tester to check resistance



Troubleshooting

(HL028)

37

1.5 Outdoor Air Thermistor Error

Remote Controller LCD Display

Error Code **55** Inspection — Unit No. ❖

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method Temperature detected by outside air temperature sensor is used to detect errors.


Error Generating Conditions

When value detected by outside air temperature sensor is -40°C or below (open circuit) or 70°C or higher (shorting).

Possible Causes

- Faulty sensor
- Broken wire
- Faulty control PCB
- Faulty contact in connector

Troubleshooting



Note

Note 1:


Refer to the thermistor temperature - resistance conversion table when measuring resistance.

Thermistor temperature - resistance conversion table

Thermistor temperature	Sensor resistance	Thermistor temperature	Sensor resistance
-10°C or less	108kΩ or more	22°C	Approx. 23kΩ
-5°C	Approx. 85kΩ	24°C	Approx. 21kΩ
0°C	Approx. 66kΩ	26°C	Approx. 19kΩ
5°C	Approx. 51kΩ	28°C	Approx. 18kΩ
10°C	Approx. 40kΩ	30°C	Approx. 16kΩ
14°C	Approx. 33kΩ	35°C	Approx. 13kΩ
16°C	Approx. 30kΩ	40°C	Approx. 11kΩ
18°C	Approx. 27kΩ	50°C or more	7kΩ or less
20°C	Approx. 25kΩ		

If measured value deviates significantly from above values, thermistor is faulty.

Use tester to check resistance



(HL028)

1.6 Damper System Error (Alarm)

Remote Controller LCD Display

Error Code **5** *R* Inspection — Unit No. ❖

LED Indication

Remote Controller 🌣 Main Unit 🗘

Error Detection Method Measurement of damper motor limit ON/OFF time.


Error Generating Conditions

- When damper motor limit switch 1 (or 2) remains ON (or OFF) for more than a certain time duration after ventilation mode is changed.
- When damper motor limit switch 1 (or 2) repeats ON/OFF operations after damper motor 1 (or 2) stops.

Possible Causes

- Faulty damper motor or limit switch
- Broken wire in cable
- Faulty contact in connector (including relay connector)
- Faulty control PCB assembly


Troubleshooting



Note:

Note 1:

- Place tester probes on connectors of limit switch. Move switch by hand and check continuity. If tester indicates 0Ω when limit switch turns on, and infinity when it turns off, limit switch is normal.
- Place tester probes on connectors of damper motor and check resistance. If tester indicates approx. 17 $k\Omega$ in 200-V model, damper motor is normal.



(HL029)

1.7 Damper System Error (Alarm)

Remote Controller LCD Display

Error Code **58** Inspection **4** Unit No. **4**

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method

Measurement of damper motor limit switch ON/OFF time and temperatures detected by outdoor and indoor air thermistor.


Error Generating Conditions

- When damper system error (alarm) and indoor (or outdoor) thermistor error are generated at the same
- When damper system error (alarm) occurs and values of indoor and outdoor air thermistor meet frost conditions.

Possible Causes

- Faulty damper motor or limit switch
- Faulty indoor air thermistor
- Faulty outdoor air thermistor
- Frosting
- Broken wire in cable
- Faulty contact in connector (including relay connector)
- Faulty control PCB assembly

Troubleshooting



(HF006)

1.8 Dedicated LCD Remote Controller

Error Detection Method

When "88" remains on remote controller display.

Error Generating Conditions


Remote control setting error

Eg. one remote controller set to "SUB" and a second remote controller set to "MAIN, MAIN" or "SUB, SUB"


Possible Causes

Master-slave setting of remote controller Remote controller PCB assembly error Main unit PCB assembly error

Troubleshooting




Dedicated Remote Controller



(HL030)

Main Unit PCB



1.9 Data Transmission Error (Between LCD Remote Controller and Main Unit)

Remote Controller LCD Display

Error Code **U5** Inspection → Unit No. →

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method Microcomputer checks if data is transmitted properly between main unit and remote controller.


Error Generating Conditions

When data transmission is not performed correctly for a certain time period.

Possible Causes

- Faulty connection of remote controller cable
- Faulty remote controller cable
- External factor (noise, etc.)

Troubleshooting




a

Note:

1. Use tester to check continuity of remote controller cable.

- Disconnect cable from main unit terminal board and remote controller terminal board. Measure resistance between wires in cable. Resistance should be ∞MΩ (infinity).
- 2. Use tester to check voltage at terminal board. Check with power turned on.
- With remote controller cable disconnected, voltage between P1 and P2 on terminal board should be approx. 16 VDC. If measured value is not approx. 16 VDC, PCB assembly is faulty.
- Connect remote controller cable and disconnect remote controller. Voltage at the end of remote controller cable should be approx. 16 VDC. If measured value is not 16 VDC, remote controller cable is faulty.
- Connect remote controller cable and remote controller. Voltage between P1 and P2 on remote controller terminal should be approx. 16 VDC. If measured valued is not 16 VDC, remote controller is faulty.



1.10 Data Transmission Error (LCD Remote Controller)

Remote Controller LCD Display

Error Code **U5** Inspection ❖ Unit No. ●

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method

Microcomputer checks if data is transmitted properly between main unit and remote controller.


Error Generating Conditions

When data transmission is not performed correctly for a certain time period.

Possible Causes

- Erroneous connection
- Faulty remote controller setting
- Faulty remote controller

Troubleshooting



1.11 Data Transmission Error (Between LCD Master Remote Controller and Slave Remote Controller)

Remote Controller LCD Display

Error Code **UB** Inspection ❖ Unit No. ●

LED Indication

Remote Controller

Main Unit

Error Detection Method

Microcomputer checks if data is transmitted properly between master-slave remote controller.


Error Generating Conditions

When data transmission is not performed correctly for a certain time period.

Possible Causes

- Faulty remote controller setting
- Faulty remote controller

Troubleshooting



(HF010)

1.12 Field Setting Error

Remote Controller LCD Display

Error Code **UR** Inspection ★ Unit No. ●

LED Indication

Remote Controller

Main Unit

Error Detection Method

Microcomputers checks if data are transmitted correctly on the communication wire


Error Generating Conditions

Please consult flow chart below

Possible Causes

- Faulty combination of remote controller
- More than 16 units connected to remote controller cable.
- Faulty remote controller

Troubleshooting



(HF011)

<Combination-Right or Wrong>

Main body	Remote controller	Right/Wrong
Heat recovery ventilation unit only	Heat recovery ventilation unit	Right
Heat recovery ventilation unit only	Heat recovery ventilation unit + air-conditioner	Wrong
Heat recovery ventilation unit only	Air conditioner	Right
Heat recovery ventilation unit + air-conditioner	Heat recovery ventilation unit	Wrong
Heat recovery ventilation unit + air-conditioner	Heat recovery ventilation unit + air-conditioner	Right
Heat recovery ventilation unit + air-conditioner	Air-conditioner	Right

1.13 Overlapping Central Control Address

Remote Controller LCD Display

Error Code **UC** Inspection 🜣 Unit No. 🜣

LED Indication

Remote Controller 🗘 Main Unit 🗘

Error Detection Method

Remote controller microcomputer checks for double-setting of addresses.


Error Generating Conditions

When same address is set to two or more units.

Possible Causes

- Overlapping of central control address
- Faulty remote control

Troubleshooting



1.14 Main Unit PCB Assembly

Error Detection Method

Check microcomputer operation monitor.

Error Generating Conditions

When main unit PCB assembly does not operate.

When communication circuit errors.


Possible Causes

Fuse (excess current)
Power transformer


Noise

Main unit PCB

Troubleshooting



Main unit PCB



1.15 Dedicated LCD Remote Controller

When no indication is displayed on remote controller

Error Detection Method

Check to see if remote controller displays indication.

Error Generating Conditions


When main unit PCB assembly does not operate.

When communication circuit errors.

Possible Causes

Error on communication wire. Noise etc. other than malfunction. Faulty remote control PCB.

Troubleshooting




Check 1, 2, 3: Refer to page 49

1.16 How to Check


Check 1

Dedicated LCD remote controller (Option)




Check 2

Dedicated LCD remote controller (Option)



Check 3

Dedicated LCD remote controller (Option)



1.17 Thermistor

Error Detection Method

Remove thermistor and check resistance with tester.


Error Generating Conditions

Deterioration of thermistor.

Possible Causes

- Faulty thermistor
- Broken wire
- Faulty control PCB
- Faulty contact in connector

Troubleshooting



(HF015)




Refer to the thermistor temperature - resistance conversion table when measuring resistance.

Thermistor temperature - resistance conversion table

Thermistor temperature	Sensor resistance	Thermistor temperature	Sensor resistance
-10°C or less	108kΩ or more	22°C	Approx. 23kΩ
-5°C	Approx. 85kΩ	24°C	Approx. 21kΩ
0°C	Approx. 66kΩ	26°C	Approx. 19kΩ
5°C	Approx. 51kΩ	28°C	Approx. 18kΩ
10°C	Approx. 40kΩ	30°C	Approx. 16kΩ
14°C	Approx. 33kΩ	35°C	Approx. 13kΩ
16°C	Approx. 30kΩ	40°C	Approx. 11kΩ
18°C	Approx. 27kΩ	50°C or more	7kΩ or less
20°C	Approx. 25kΩ		

If measured value deviates significantly from above values, thermistor is faulty. Use tester to check resistance



(HL028)

1.18 Power Transformer

Error Detection Method

Check resistance and voltage with tester, and insulation resistance with megger.


Error Generating Conditions

Overcurrent (by surging etc.). Deterioration of transformer.


Possible Causes

Deterioration of transformer.

Troubleshooting



- \blacksquare Resistance of primary side of transformer: approx. 140 Ω
- Resistance of secondary side of transformer: approx. 1.9Ω
- Voltage at secondary side of transformer when rated voltage is applied to primary side: approx. 26 VAC
- Insulation resistance between primary side of transformer and case: 100 M Ω or higher
- Insulation resistance between secondary side of transformer and case: 100 M Ω or higher
- Insulation resistance between primary side and secondary side of transformer: 100 M Ω or higher



1.19 Damper Motor

Error Detection Method

Check damper motor and limit switch when damper motor does not operate.


Error Generating Conditions

Deterioration of damper motor. Deterioration of limit switch.


Possible Causes

Deterioration of damper motor. Deterioration of limit switch.

Troubleshooting



Check resistance and voltage — $\operatorname{\mathsf{DAMPER}}\nolimits$ MOTOR



Part 8 Supplementary Explanation

1.	Supp	lementary Explanation	54
	1.1	Field Setting, Service Mode Operation	54


Supplementary Explanation

1. Supplementary Explanation

1.1 Field Setting, Service Mode Operation


1.1.1 Field Setting

Initial setting (mode Nos. 17, 27, 18, 28)



Step 1	With equipment in normal mode, press the button for more than 4 seconds to enter field setting mode.	
Step 2	Mode No.: UP ↔ 🚱 Mode No.: DOWN Use [MODE] and [AIR VOLUME] to select desired mode No.	
Step 3	To setting heat recovery ventilation units by group, press button and select desired unit No.	
Step 4	Press button to select desired setting switch No.	
Step 5	Press button to select desired setting position No.	
Step 6	Press button to enter settings.	
Step 7	Press button to return to normal mode.	


Centralized control group No. setting (Mode No. 00) Setting of Individual No. (Mode No. 30)



Step 1	With equipment in normal mode, press the button for more than 4 seconds to enter field setting mode.	
Step 2	Mode No.: UP ← Mode No.: DOWN Use [MODE] and [AIR VOLUME] to select mode No.00 (30).	
Step 3	Press or button to select Group No.	
Step 4	Press button once to enter settings.	
Step 5	Press button to return to normal mode.	


1.1.2 Service Mode Operation

Turn on the forced fan (Mode No.43)



Step 1	With equipment in field setting mode, press the button for more than 4 seconds to enter service mode.
Step 2	Mode No.: UP ↔ Solution Mode No.: DOWN Use [MODE] and [AIR VOLUME] to select mode No.43.
Step 3	Use $\frac{\bullet \cdot 1}{\bullet \cdot \circ}$ to select desired Unit No.
Step 4	Press button to return to normal mode.

Unit No. reallocation (Mode No.45)




Step 1	With equipment in field setting mode, press the service mode. button for more than 4 seconds to enter
Step 2	Mode No.: UP ←
Step 3	Use ⊕ to select setting Unit No.
Step 4	Press or button to select Unit No. after reallocation.
Step 5	Press button once to enter settings.
Step 6	Press button to return to normal mode.

1.1.3 **Operation Changeover Control**

For group control of systems containing heat recovery ventilation units and air conditioners (VRV system), remote controllers of air conditioners are connected with remote controllers of new heat recovery ventilation units. In such system, both remote controllers display "Operation changeover control" according to the ON/OFF of cooling/heating selection privilege.

The following diagram shows the display ON/OFF condition determined by the unit combination.

Example of "Operation changeover control" display



Display ON/OFF condition by connection type and cooling/heating selection privilege

Connection type	"Operation changeover control" display		
Heat recovery ventilation unit only	No display		
Heat recovery ventilation unit +	Cooling/heating selection privilege not set	Flashing (Note 1)	
Air conditioner (VRV system)	Cooling/heating selection privilege ON	No display	
	Cooling/heating selection privilege OFF	Display	




Note 1:

Only master remote controller can display flashing "Operation changeover control" when cooling/heating selection privilege is not set.

1.1.4 Field Setting

The following shows the procedure for field setting using remote controller of new heat recovery ventilation unit.



(HL044)

List of field setting mode Nos.


	00	
Centralized control group No. setting		
General setting		
Centralized control group No. setting (group)	30	
Error record display	40	
Sensor data	41	
Forced fan ON	43	
Individual setting	44	
Unit No. reallocation	45	

Step 1	To field setting mode	Press of for more than 4 sec.
Step 2	Mode No. selection 1	
Step 3	Mode No. selection 2	Mode No.: UP ↔ Mode No.: DOWN
Step 4	Switch No. selection	(🛕) Switch No. selection
Step 5	Position selection	(▼) Position selection
Step 6	Position enter	Enters currently selected position.
Step 7	To normal mode	Exits field setting mode and enters normal mode.

In group control, use (0.0) to select unit No.

1.1.5 LCD and Operation Panel (Reference Information)

The following shows the operation panel and LCD of remote controller of new heat recovery ventilation unit.



LCD


LCD is equipped with a new function that graphically displays currently selected ventilation mode, as shown below

shown below.		
(Ventilation mode: Auto)	Total heat exchange ventilation mode	[A] (<u>L</u> <u>(D</u>) (HL046)
	Normal ventilation mode	
		(<u>I</u> (HL047)
	Display OFF in automatic ventilation mode	[五] (二] (HL048)
(Ventilation mode: Total heat exchange)		(HL049)
(Ventilation mode: Normal)	Normal ventilation mode	
		(HL050)

Display can be turned off using field setting 19 (29) - 7.


1.1.6 Ventilation Volume (Freshup)

Ventilation volume (Freshup) setting changes as follows.



Inspection

Inspection operation is shown below.



1.1.7 Field Setting

(Example of setting operation)


Centralized control group No. setting (mode No.: 00)

- 1. Press of for more than 4 seconds.
- 2. Set mode No. to "00" using each or .
- 4. Enter displayed group No. by pressing
- 5. Press to return to normal operation mode.

Centralized control group No. setting (mode No.: 30)


For group control, the following step must be performed.

(*) Set unit No. using (*) .




Procedure for entering individual settings (mode No.: 44) The setting is generally the same for all units in the same group control system. However, the setting of selected units can be fixed by the following method.

< Example >



This setting method can be used when a group control system is connected with units having a different airflow capacity from other units in the system.

- 1. Press of for more than 4 seconds.
- 2. Set mode No. to "44" using each or .
- 3. Set unit No. using (0) .
- 4. Set airflow volume (ventilation mode) using [[].
- 5. Set airflow direction (ventilation volume) using [♣ [▼].
- 6. Enter settings by pressing □ .



Individual Settings

Heat recovery Ventilation Unit		Air Conditioner				
Ventilation Volume	Ventilation Mode	Airflow Volume		entilation Mode Airflow Volume Airflow Direct		Direction
	As indicated by LCD	Low	1	P0	0	
As indicated by LCD				~	~	
As indicated by ESB		High	3	P4	4	
				Swing	5	

Part 9 Appendix


1.	Appendix		
	1.1	Wiring Diagram	66

Appendix SiE00-01

1. Appendix

1.1 Wiring Diagram


VAM150FJVE / VAM250FJVE / VAM350FJVE / VAM500FJVE / VAM650FJVE / VAM800FJVE / VAM1000FJVE



3D020069A

SiE00-01 Appendix

VAM1500FJVE / VAM2000FJVE



Appendix SiE00-01

Index

A	Direct duct connection with air conditioner 23
Abnormality control function22	Display OFF in automatic ventilation mode 60
Air conditioner link function22	Duct Connection Flange
Air Conditioner Link Operation25	_
Air conditioner link operation31	E
Air Filter (Long Life Filter)2, 3	EEPROM 31
Air flow setting27	Electric heater setting27
Air Supply Fan2, 3	Error Code
Airflow rate setting switch interface31	60 34
Auto restart setting26	64
Automatic ventilation operation function22	65 34
•	6A34
В	U534
BRC301B6111	U8 34
	UA 34
C	UC 34
Ceiling Hock2, 3	UE34
Central data transmission interface31	Error Code 60
Centralized / individual setting26	Error Code 64
Centralized control function22	Error Code 65
Centralized control group No. setting59	Error Code 6A
Centralized control group No. setting (group)59	Error Code Indication34
Centralized control group No. setting	Error Code U5
(Mode No. 00) Setting of Individual No.	Error Code U844
(Mode No. 30)55	Error Code UA45
Centralized control group No. setting	Error Code UC46
(mode No.: 00)62	Error record display27, 59
Centralized control group No. setting	Exhaust Air
(mode No.: 30)62	Exhaust Fan
Centralized System10	Explanation for Systems10
Centralized system	External input interface31
Check microcomputer operation monitor47	external input terminal (J1-JC)35
Circuit Functions31	External input terminal function selection
Circuit Operations30	(between J1 and JC)27
CLEANING FREQUENCY	External link operation function
Cold Area Mode25	External signal setting JC / J2
Combined Operation System with VRV Systems	3
and Skyair Series10	F
Control microcomputer31	Fan motor, damper motor relay31
Control microcomputer	Fan speed initial setting26
D	Field Setting59
Damper2, 3	Field Setting Error45
Damper limit switch interface31	Field setting function22
Damper Motor	Field Setting, Service Mode
Damper System Error (Alarm)39, 40	Field Setting, Service Mode Operation54
Data Transmission Error	Filter cleaning time setting
(Between LCD Master Remote Controller	Filter sign function22
and Slave Remote Controller)44	Forced fan ON59
Data Transmission Error	Forced ventilation fan On27
(Between LCD Remote Controller	FRESH UP11
and Main Unit)42	Fresh up air supply / exhaust setting
Data Transmission Error	Fresh up operation27
	Freshup function
(LCD Remote Controller)43 Dedicated LCD Remote Controller41, 48	Function of main connection terminal
Dedicated Remote Controller41, 48	2

Index

G		Operation chart	
General Constructions	2	Operation for INDIVIDUAL SYSTEM	
General setting		Operation mode selector	. 13
Group function		Operation with The Remote Control	
Group No. setting for centralized controller		for Air Conditioning Operation	
(individual)	26	HRV Units. (BRC301B61)	. 11
(,		Outdoor Air	2, 3
H		Outdoor Air Thermistor Error	
Heat Exchange Element (X2)	17	Overall Alarm	
Heat Exchange Element (X4)		Overall Malfunction	
Heat Exchange Elements		Overlapping Central Control Address	
How to Check			
HOW TO OPERATE WITH TIMER		P	
Humidifier operation control function		Power ON operation function	22
Trumumer operation control function	22	Power supply circuit	
ı		Power Transformer	
Independent Operation of The LIDV/ Limit Lieuw		Power transformer	
Independent Operation of The HRV Unit Using	40	Pre-cool/pre-heat function	
The Centralized Controller (DCS302B61)		·	
Independent System		Pre-cool/pre-heat On/Off setting	
Indication of ventilation mode / Not indication		Pre-cool/pre-heat operations	
Individual setting		Pre-cool/pre-heat time (min.) setting	
Individual Settings		Pre-heat time extension setting	
Indoor Air Thermistor Error		Printed Circuit Board	. 28
Initial setting (mode Nos. 17, 27, 18, 28)		Procedure for entering individual settings	-00
Inspection operation	61	(mode No.: 44)	
		Product Specification	6
K		n	
KRP50-2		R	
KRP50-2 interface	31	Relay drive circuit	
KRP50-2 output switching selection		Remote control data transmission interface	
(between 1 and 3)	27	Remote Controller	,
		Remote controller function	. 22
L		Remove thermistor and check resistance	
Layout of switches on Printed Circuit Board	28	with tester	. 50
LCD and Operation Panel		Return Air	2, 3
List of Control Functions			
List of field setting mode Nos.		S	
List of malfunction codes displayed		Sensor data	. 59
by LCD remote controller	34	Service Mode Operation	
by LOB Tomoto controller		Setting for cold areas (Fan operaiton selection	
M		for heater thermostat OFF)	. 26
Main Unit PCB	/11	Setting for direct power-on	
Main Unit PCB Assembly		Setting mode	
•		Setting switch No.	
Maintenance Cover		Supply Air	
		Switch Box	
Maintenance for The Heat Exchange Element	19	OWILOT DOX	۷, ٥
Maintenance Space for The Air Filters,		т	
Heat Exchange Elements and Switch Box		Thermistor	5 0
Microcomputer oscillation circuit		Thermistor interface	
Microcomputer reset circuit	31		. 31
		Thermistor temperature - resistance	
N		conversion table	
Name Plate		Timer function	
Normal operation		To clean the air filter	
Normal ventilation mode	60	to dry Air filter	
		Total heat exchange ventilation mode	
0		Troubleshooting function	
Operating The HRV Unit Using		Turn on the forced fan (Mode No.43)	. 56
The Remote Controller of The VRV.			
System Air Conditioner	13	U	
Operation Changeover Control		Unit No. allocation	. 27

ii Index

SiE00-01

Unit No. reallocation	59
Unit No. reallocation (Mode No.45)	57
v	
Ventilation capacity changeover function	22
Ventilation mode changeover function	
Ventilation mode setting	
Ventilation mode:Total heat exchange	60
Ventilation Operation Control	23
Ventilation operation control function	22
Ventilation volume (Freshup) setting changes	
w	
When no indication is displayed	
on remote controller	48
Y	
Yes / No setting for direct duct Connection	
with VRV system	26

Index

iv Index

Drawings & Flow Charts

A	н	
Air Conditioner Link Operation	HOW TO OPERATE WITH TIMER	12
1 group link control25		
Link control of 2 or more groups26	1	
Air flow rate can be changed over11	Initial setting (mode Nos. 17, 27, 18, 28)	
C		
Centralized control group No. setting 55, 62	L	
Check 149	LCD and Operation Panel	60
Check 249		
Check 349	M	
Check damper motor52	Main Unit PCB	41
Check microcomputer operation monitor47	Main unit PCB	
Check resistance and voltage with tester51	Maintenance Cover	
Circuit Configuration30	VAM150~1000FJVE	16
Cold Area Mode25	VAM1500~2000FJVE	
Connect remote controller cable	Maintenance for The Heat Exchange Element	
and remote controller42		
_	N	
D	Normal ventilation mode	60
Dedicated Remote Controller41		
Display OFF in automatic ventilation mode60	0	
dry Air filter17	Operation Changeover Control	58
,	Operation for Each System	
E	operation mode selector	
Error Code 60	•	
Error Code 64	P	
Error Code 6538	Power Transformer	51
Error Code 6A	Pre-cool/pre-heat operations	
Error Code Indication34	Printed Circuit Board	
Error Code U5	Procedure for entering individual settings	
Error Code U8	(mode No.: 44)	62
Error Code UA45	,	
Error Code UC46	R	
Explanation of Individual Functions	Remote Controller for HRV BRC301B61	11
Direct duct connection with air conditioner23	Remote Controller for VRV BRC1A61-62	13
Normal operation23	Remove thermistor and check resistance	
	with tester	50
F		
Field Setting59	T	
Function of main connection terminal28	Take out the heat exchange elements	
	VAM150~1000FJVE	
G	VAM1500~2000FJVE	17
General Constructions	Thermistor temperature - resistance	
VAM1000FJVE2	conversion table	50
VAM1500FJVE3	To clean the air filter	17
VAM150FJVE2	Total heat exchange ventilation mode	
VAM2000FJVE3	Turn on the forced fan (Mode No.43)	56
VAM250FJVE2		
VAM350FJVE2	U	
VAM500FJVE2	Unit No. reallocation (Mode No.45)	
VAM650FJVE2	Use tester to check resistance	7, 38
VAM800FJVE2		
	V	
	VAM2000EJVE	67

Drawings & Flow Charts

66 12
60
61
41
48
66

vi Drawings & Flow Charts



ISO14001 assures an effective environmental management system in order to help protect human health and the environment from the potential impact of our activities, products and services and to assist in maintaining and improving the quality of the environment.



Daikin Europe NV is approved by LRQA for its Quality Management System in accordance with the ISO9001 standard. ISO9001 pertains to quality assurance regarding design, development, manufacturing as well as to services related tot the product.



Daikin units comply with the European regulations that guarantee the safety of the product.

DAIKIN PRODUCTS ARE DISTRIBUTED BY:

Printed in Belgium by Vanmelle / SiE00-01 / 11/2000

Specifications subject to change without notice.

DAIKIN EUROPE NV

Zandvoordestraat 300 B-8400 Oostende Belgium

DAIKIN INDUSTRIES, LTD.

Head Office: Umeda Center Bldg., 4-12 Nakazaki-Nishi 2-chome, Kita-ku, Osaka 530 Japan