

# HITACHI

## SERVICE MANUAL TECHNICAL INFORMATION

**FOR SERVICE PERSONNEL ONLY**


**TC**

**NO. 0842E**


**RAF-25RXB/RAC-25FXB  
RAF-35RXB/RAC-35FXB  
RAF-50RXB/RAC-50FXB**

REFER TO THE FOUNDATION MANUAL

INDOOR UNIT



OUTDOOR UNIT



CONTENTS

SPECIFICATIONS-----	1-1
HOW TO USE-----	2-1
CONSTRUCTION AND DIMENSIONAL DIAGRAM-----	3-1
MAIN PARTS COMPONENT-----	4-1
WIRING DIAGRAM-----	5-1
CIRCUIT DIAGRAM-----	6-1
BLOCK DIAGRAM-----	7-1
BASIC MODE-----	8-1
REFRIGERATING CYCLE DIAGRAM -----	9-1
PROCEDURE FOR DISASSEMBLY AND REASSEMBLY-----	10-1
DESCRIPTION OF MAIN CIRCUIT OPERATION-----	11-1
SERVICE CALL Q & A-----	12-1
TROUBLE SHOOTING-----	13-1
VARIOUS SETTINGS-----	14-1
PARTS LIST AND DIAGRAM-----	15-1

**SPECIFICATIONS**

TYPE	DC INVERTER							
	INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT	INDOOR UNIT	OUTDOOR UNIT		
MODEL	RAF-25RXB	RAC-25FXB	RAF-35RXB	RAC-35FXB	RAF-50RXB	RAC-50FXB		
POWER SOURCE	1 PHASE, 50HZ, 220-230V		1 PHASE, 50HZ, 220-230V		1 PHASE, 50HZ, 220-230V			
COOLING	TOTAL INPUT (W)	580(155-1,180)		1,020(155-1,300)		1,560(155-1,950)		
	TOTAL AMPERES (A)	3.11-2.97		4.80-4.67		7.16-6.85		
	CAPACITY	(KW)	2.50(0.90-3.10)		3.50(0.90-4.00)		5.00(0.90-5.20)	
		(B.T.U./h)	8,530(3,070-10,580)		11,940(3,070-13,650)		17,060(3,070-17,740)	
HEATING	TOTAL INPUT (W)	790(115-1,120)		1,220(115-1,300)		1,780(115-2,100)		
	TOTAL AMPERES (A)	3.99-3.82		5.84-5.58		8.17-7.82		
	CAPACITY	(KW)	3.4(0.9-4.4)		4.5(0.9-5.0)		6.5(0.9-8.1)	
		(B.T.U./h)	11,600(3,070-15,010)		15,350(3,070-17,060)		22,180(3,070-27,640)	
DIMENSIONS (mm)	W	750	750(+65)*	750	750(+65)*	750	800(+63)*	
	H	590	548	590	548	590	736	
	D	215	288(+27.5)*	215	288(+27.5)*	215	350(+35.5)*	
NET WEIGHT (Kg)	15	34	15	34	15	49.5		

\*After installation

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

# ROOM AIR CONDITIONER


INDOOR UNIT + OUTDOOR UNIT

FEBRUARY 2015

Hitachi Appliances, Inc.


## 1. SAFETY DURING REPAIR WORK

1. In order to disassemble and repair the unit in question, be sure to disconnect the power cord plug from the power outlet before starting the work.



2. If it is necessary to replace any parts, they should be replaced with respective genuine parts for the unit, and the replacement must be effected in correct manner according to the instructions in the Service Manual of the unit.

If the contacts of electrical parts are defective, replace the electrical parts without trying to repair them



3. After completion of repairs, the initial state should be restored.
4. Lead wires should be connected and laid as in the initial state.
5. Modification of the unit by the user himself should absolutely be prohibited.
6. Tools and measuring instruments for use in repairs or inspection should be accurately calibrated in advance.
7. In installing the unit having been repaired, be careful to prevent the occurrence of any accident such as electrical shock, leak of current, or bodily injury due to the drop of any part.
8. To check the insulation of the unit, measure the insulation resistance between the power cord plug and grounding terminal of the unit.  
The insulation resistance should be  $1M\Omega$  or more as measured by a 500V DC megger.
9. The initial location of installation such as window, floor or the other should be checked for being safe enough to support the repaired unit again.  
If it is found not so strong and safe, the unit should be installed at the initial location after reinforced or at a new location.
10. Any inflammable object must not be placed about the location of installation.
11. Check the grounding to see whether it is proper or not, and if it is found improper, connect the grounding terminal to the earth.



# WORKING STANDARDS FOR PREVENTING BREAKAGE OF SEMICONDUCTORS

## 1. Scope


The standards provide for items to be generally observed in carrying and handling semiconductors in relative manufactures during maintenance and handling thereof. (They apply the same to handling of abnormal goods such as rejected goods being returned.)

## 2. Object parts

- (1) Microcomputer
- (2) Integrated circuits (I.C.)
- (3) Field effective transistor (F.E.T.)
- (4) P.C. boards or the like to which the parts mentioned in (1) and (2) of this paragraph are equipped.


## 3. Items to be observed in handling

- (1) Use a conductive container for carrying and storing of parts. (Even rejected goods should be handled in the same way.)




**Fig. 1 Conductive container**

- (2) When any part is handled uncovered (in counting, packing and the like), the handling person must always use himself as a body earth. (Make yourself a body earth by passing one M ohm earth resistance through a ring or bracelet.)
- (3) Be careful not to touch the parts with your clothing when you hold a part even if a body earth is being taken.
- (4) Be sure to place a part on a metal plate with grounding.
- (5) Be careful not to fail to turn off power when you repair the printed circuit board. At the same time, try to repair the printed circuit board on a grounded metal plate.




**Fig. 2 Body earth**

(6) Use a three wire type soldering iron including a grounding wire.



**Fig.3 Grounding of the working table**



**Fig.4 Grounding a solder iron**

Use a high insulation mode (100V, 10MΩ or higher) when ordinary iron is to be used.

(7) In checking circuits for maintenance, inspection, or some others, be careful not to have the test probes of the measuring instrument short circuit a load circuit or the like.

 **CAUTION**

1. In quiet or stop operation, slight flowing noise of refrigerant in the refrigerating cycle is heard occasionally, but this noise is not abnormal for the operation.
2. When it thunders near by, it is recommend to stop the operation and turn off the circuit breaker for safety.
3. In the event of power failure,the room air conditioner will restart automatically in the previously selected mode once the power is restored. In the event of power failure during TIMER operation, the room air conditioner will not start automatically. Re-press ON/OFF button after 3 minutes from when the unit off or power recovery.
4. If the room air conditioner is stopped by adjusting thermostat, or misoperation, and re-start in a moment, there is occasion that the cooling and heating operation does not start for 3 minutes, it is not abnormal and this is the result of the operation of IC delay circuit. This IC delay circuit ensures that there is no danger of blowing fuse or damaging parts even if operation is restarted accidentally.
5. This room air conditioner should not be used at the cooling operation when the outside temperature is below  $-10^{\circ}\text{C}$  ( $14^{\circ}\text{F}$ ).
6. This room air conditioner (the reverse cycle) should not be used when the outside temperature is below  $-15^{\circ}\text{C}$  ( $5^{\circ}\text{F}$ ).  
If the reverse cycle is used under this condition, the outside heat exchanger is frosted and efficiency falls.
7. When the outside heat exchanger is frosted, the frost is melted by operating the hot gas system, it is not trouble that at this time fan stops and the vapour may rise from the outside heat exchanger.

This manual describes only points that differ from  
 RAM-33NP2B(PM No. 0581E)  
 RAM-40NP2B(PM No. 0582E)  
 RAM-53NP2B, RAM-53NP3B(PM No. 0583E)  
 RAM-68NP3B(PM No. 0584E)  
 RAM-70NP4B(PM No. 0585E)  
 RAM-90NP5B(PM No. 0586E)  
 RAM-110NP6B(PM No. 0587E)  
 for items not described in this manual.

### Combination table


Indoor unit		RAF-25RXB	RAF-35RXB	RAF-50RXB
Single outdoor unit		RAC-25FXB	RAC-35FXB	RAC-50FXB
Multi outdoor unit	RAM-33NP2B	○	-	-
	RAM-40NP2B	○	○	-
	RAM-53NP2B	○	○	○
	RAM-53NP3B	○	○	○
	RAM-68NP3B	○	○	○
	RAM-70NP4B	○	○	○
	RAM-90NP5B	○	○	○
	RAM-110NP6B	○	○	○

## SPECIFICATIONS

MODEL		RAF-25RXB RAF-35RXB RAF-50RXB	RAC-25FXB	RAC-35FXB	RAC-50FXB
FAN MOTOR		30W (DC325V)	47W (DC120~380V)		
FAN MOTOR CAPACITOR		NO	NO		
FAN MOTOR PROTECTOR		NO	NO		
COMPRESSOR		—	ASD084SFNA7JK1	ASG133CDNB7AT	
COMPRESSOR MOTOR CAPACITOR		NO	NO		
OVERLOAD PROTECTOR		NO	YES(INTERNAL)		
OVERHEAT PROTECTOR		NO	YES		
FUSE (for MICROPROCESSOR)		3.15A	15A, 2A, 3A, 3.15A	25A, 2A, 3A, 3.15A	
POWER RELAY		NO	G4A-1A		
POWER SWITCH		NO	NO		
TEMPORARY SWITCH		YES	NO		
SERVICE SWITCH		NO	YES		
TRANSFORMER		YES	YES		
VARISTOR		450NR	450NR, ERZVA431		
NOISE SUPPRESSOR		NO	YES		
THERMOSTAT		YES(IC)	YES(IC)		
REMOTE CONTROL SWITCH (LIQUID CRYSTAL)		YES	NO		
REFRIGERANT CHARGING VOLUME (Refrigerant R410A)	UNIT	-----	870g	870g	1400g
	PIPES	MAX. 20m MIN.3m			MAX. 30m MIN.3m
		WITHOUT REFRIGERANT BECAUSE COUPLING IS FLARE TYPE.			

**Figure showing the installation of Indoor and Outdoor unit**


MODEL RAF-25RXB/RAC-25FXB  
RAF-35RXB/RAC-35FXB





# Figure showing the installation of Indoor and Outdoor unit

MODEL RAF-50RXB/RAC-50FXB



## HOW TO USE

MODEL RAF-25RXB / RAC-25FXB, RAF-35RXB / RAC-35FXB, RAF-50RXB / RAC-50FXB


# HITACHI

Inspire the Next

## Remote Controller Manual

MODEL


RAR-6N4



## PREPARATION BEFORE OPERATION



### ■ To install the batteries

1. Slide the cover to take it off.
2. Install two dry batteries AAAA.LR03 (alkaline). The direction of the batteries should match the marks in the case.
3. Replace the cover at its original position.



### ■ To fix the remote controller holder to the wall

1. Choose a place from where the signals can reach the unit.
2. Fix the remote controller holder to a wall, a pillar or similar location with the provided screws.
3. Place the remote controller in the remote controller holder.



### NOTE

#### Notes on batteries

- When replacing the batteries, use batteries of the same type, and replace both old batteries together.
- When the system is not used for a long time, take the batteries out.
- The batteries will last for approximately 1 year. However, if the remote controller display begins to fade and degradation of reception performance occurs within a year, replace both batteries with new size AAAA.LR03 (alkaline).
- The attached batteries are provided for the initial use of the system.





The usable period of the batteries may be short depending on the manufactured date of the air conditioner.

#### Notes on the remote controller

- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote controller signals happen to operate another appliance, move that appliance to somewhere else, or consult the service shop.
- When the remote controller is not in use, please close the slide cover to prevent failure.

SUOMI NEDERLANDS SVENSKA Ελληνικά PORTUGUES ESPAÑOL ITALIANO FRANÇAIS DEUTSCH ENGLISH

## PREPARATION BEFORE OPERATION



### To set calendar and clock

1. Press **RESET** (RESET) button when first time setting. "Year" blinks.
2. Press **TIME** (TIME) button to set the current year.
3. Press **CLOCK** (CLOCK) button. "Day" and "Month" blink.
4. Press **TIME** (TIME) button to set the current day and month.
5. Press **CLOCK** (CLOCK) button. "CLOCK" blinks.
6. Press **TIME** (TIME) button to set the clock to the current time.
7. Press **CLOCK** (CLOCK) button.

Calendar and clock are set.

To modify the calendar and clock, press **CLOCK** (CLOCK) button.

Then follow steps 1 to 7.

Calendar and clock need to be set again after changing batteries.

After changing the batteries,

1. Press **RESET** (RESET) button.
  2. Direct remote controller towards indoor unit and press **INFO** (INFO) button.
  3. The calendar and clock from indoor unit will be transmitted.
- Calendar and clock will not be transmitted from indoor unit when the following occurs:
- When there is a power failure.
  - When breaker is OFF by user (unit is not in STANDBY MODE).

### NOTE

- Note on setting the calendar and clock.
- If the calendar and clock are not set, the ON-timer, OFF-timer and Weekly Timer cannot be set.
  - If the calendar and clock are not set correctly, the ON-timer, OFF-timer and Weekly Timer will not operate correctly.
  - When the ON-timer, OFF-timer and Weekly Timer are set, the calendar and clock cannot be changed. If there is a need to change the calendar and clock, ON-timer, OFF-timer and Weekly Timer need to be cancelled.

## NAMES AND FUNCTIONS OF REMOTE CONTROLLER

### REMOTE CONTROLLER

- This controls the operation of the indoor unit. The range of control is about 7 meters. If indoor lighting is controlled electronically, the range of control may be shorter.
- This unit can be fixed on a wall using the fixture provided. Before fixing it, make sure the indoor unit can be controlled from the remote controller.
- Handle the remote controller with care. Dropping it or getting it wet may compromise its signal transmission capability.
- After new batteries are inserted into the remote controller, the unit will initially require approximately 10 seconds to respond to commands and operate.
- When remote controller is not in use for about 3 minutes during OFF condition, indicated by **OFF** on the display, the LCD will turn off.
- During clock setting, the LCD will turn off about 10 minutes later if the remote controller is not in use.
- When pressing any button, the LCD will turn on.
- The LCD will not turn off during TIMER setting.

### Signal Transmitting/Receiving Window

Point this window towards the indoor unit when controlling it.

### Sensor

A temperature sensor inside the remote controller senses ambient temperature around the remote-controller.

### Display

This indicates the room temperature selected, current time, timer status, function and airflow rate selected.


### ROOM TEMPERATURE setting Buttons

Press these buttons to set the room temperature.

Press the [**▲**] button to raise the room temperature.

Press the [**▼**] button to lower the room temperature.

Keep pressing and the value will change more quickly.



### Transmission sign

The transmission sign lights up when a signal is sent.

### START/STOP button

Press this button to start operation. Press it again to stop operation.

### FAN SPEED selector Button


This determines the fan speed.

Every time you press this button, the airflow rate will change from (AUTO) → (HIGH) → (MED) → (LOW) → (SILENT) (This button allows selection of optimal or preferred fan speed for each operation mode).

### ECO Button

Use this button to set the ECO mode. (▶ p. 13)

## NAMES AND FUNCTIONS OF REMOTE CONTROLLER



MODE SELECTOR	FAN
AUTO	POWERFUL
HEAT	SILENT
DEHUMIDIFY	INFO
COOL	SLEEP TIMER
FAN	AUTO SWING (VERTICAL)
FAN SPEED	EXTENDED AIRFLOW button
AUTO	LEAVE HOME
SILENT	CLEAN
LOW	Mon-Sun
MED	DAY
HIGH	PROGRAM NO.
START / STOP	1-6
ECO	

OFF	ON / OFF TIMER
ON	TIME
TIME	OK
OK	DELETE
DELETE	COPY / PASTE
COPY/PASTE	CANCEL
CANCEL	SEND
SEND	CLOCK
CLOCK	

### Precautions for Use

- Do not put the remote controller in the following places.
  - Under direct sunlight.
  - In the vicinity of a heater.
- Handle the remote controller carefully. Do not drop it on the floor, and protect it from water.
- Once the outdoor unit stops, it will not restart for about 3 minutes (unless you turn the power switch off and on or unplug the power cord and plug it in again).
- This is to protect the device and does not indicate a failure.
- If you press the MODE selector button during operation, the device may stop for about 3 minutes for protection.


## VARIOUS FUNCTIONS

### Auto Restart Control

- If there is a power failure, operation will be automatically restarted when the power is resumed with previous operation mode and airflow direction.  
(As the operation is not stopped by remote controller.)
  - If you intend not to continue the operation when the power is resumed, switch off the power supply.
  - When you switch on the circuit breaker, the operation will be automatically restarted with previous operation mode and airflow direction.
- Note: 1. If you do not require Auto Restart Control, please consult your sales agent.  
2. Auto Restart Control is not available when Timer or Sleep Timer mode is set.


## AUTOMATIC OPERATION

The device will automatically determine the mode of operation, HEAT or COOL depending on the current room temperature. The selected mode of operation will change when the room temperature varies. However, the mode of operation will not change when indoor unit is connected to multi-type outdoor unit.



## HEATING OPERATION

- Use the device for heating when the outdoor temperature is under 21°C. When it is too warm (over 21°C), the heating function may not work in order to protect the device.
- In order to maintain reliability of the device, please use this device when outdoor temperature is above -15°C.




### Defrosting

Defrosting will be performed about once an hour when frost forms on the heat exchange of the outdoor unit, for 5-10 minutes each time.  
During defrosting operation, the operation lamp blinks in a cycle of 3 seconds on and 0.5 second off. The maximum time for defrosting is 20 minutes.  
However, if the indoor unit is connected to multi type outdoor unit, the maximum time for defrosting is 15 minutes.  
(If the piping length used is longer than usual, frost is likely to form.)

## DEHUMIDIFYING OPERATION

Use the device for dehumidifying when the room temperature is over 16°C. When it is under 15°C, the dehumidifying function will not work.



### Dehumidifying Function

- When the room temperature is higher than the temperature setting: The device will dehumidify the room, reducing the room temperature to the preset level.
- When the room temperature is lower than the temperature setting: Dehumidifying will be performed at the temperature setting slightly lower than the current room temperature, regardless of the temperature setting.
- The preset room temperature may not be reached depending on the number of people present in the room or other room conditions.

## COOLING OPERATION

Use the device for cooling when the outdoor temperature is -10~ 43°C.  
If indoors humidity is very high (80%), some dew may form on the air outlet grille of the indoor unit.

- 1 Press the MODE selector button so that the display indicates (COOL).
- 2 Set the desired FAN SPEED with the FAN (FAN SPEED) button (the display indicates the setting).  
 (AUTO) → (HIGH) → (MED) → (LOW) ←  
 (SILENT) ← (SILENT) → (LOW) ←
- 3 Set the desired room temperature with the TEMPERATURE buttons (the display indicates the setting).  
 The temperature setting and the actual room temperature may vary depending on conditions.  
 Temperature range can be set between 16°C and 32°C

START/STOP

- As the settings are stored in the memory of the remote controller, you only have to press the (START/STOP) button next time.
- During AUTO fan, the fan speed automatically changes as below:
  - When the difference between room temperature and setting temperature is large, fan starts to run at HI speed.
  - After room temperature reaches the preset temperature, fan speed will be changed to lower speed to obtain optimum room temperature condition for natural healthy cooling.

## FAN OPERATION


User can use the device simply as an air circulator.

- 1 Press the MODE selector so that the display indicates (FAN).
- 2 Set the desired FAN SPEED with the FAN (FAN SPEED) button (the display indicates the setting).  
 (HIGH) → (MED) → (LOW) → (SILENT) →

START/STOP

Press the (START/STOP) button. Fan operation starts with a beep. Press the button again to stop operation.

## AUTO SWING OPERATION



### VERTICAL SWING

#### To start Vertical Auto Swing

- Press (AUTO SWING (VERTICAL)) button. The deflector(s) will start to swing up and down.  
 is displayed on the LCD.

#### To cancel Vertical Auto Swing

- Press (AUTO SWING (VERTICAL)) button again. The deflector(s) will stop in the current position.  
 disappeared from the LCD.

### NOTE

- During cooling and dehumidifying operation, do not keep the deflectors swinging or in the lower position (in the case of vertical auto swing) for a long time. It may cause dew condensation on the deflectors.

## EXTENDED AIRFLOW OPERATION



#### To start Extended Airflow operation

- Press (EXTENDED AIRFLOW) button during operation.  
 " " is displayed on the LCD.  
 The airflow direction will automatically set according to the type of operation and the fan speed will change to allow air to blow further. (During cooling operation, fan speed will return to the original position after 3 hours.)


- If the (EXTENDED AIRFLOW) button is pressed while the AUTO SWING mode is set, the AUTO SWING mode is cancelled and the EXTENDED AIRFLOW mode is set.
- If the (AUTO SWING) button is pressed while the EXTENDED AIRFLOW mode is set, the EXTENDED AIRFLOW mode is cancelled and the AUTO SWING mode is set.
- If the (EXTENDED AIRFLOW) button is pressed when the horizontal air deflector stops at your preferred angle, the deflector will change to EXTENDED AIRFLOW.
- Press (EXTENDED AIRFLOW) button to lower the room temperature quickly when the temperature is high during the cooling operation.

#### To cancel Extended Airflow operation

- Press (EXTENDED AIRFLOW) button again.  
 EXTENDED AIRFLOW operation stops.  
 " " disappears from LCD.

## POWERFUL OPERATION

- By pressing **POWERFUL** (POWERFUL) button during AUTO, HEATING, DEHUMIDIFYING, COOLING or FAN operation, the air conditioner performs at the maximum power.
- During POWERFUL operation, cooler or warmer air will be blown out from indoor unit for COOLING or HEATING operation respectively.



### To start POWERFUL operation

- Press **POWERFUL** (POWERFUL) button during operation.

"**POWERFUL**" is displayed on the LCD.

POWERFUL operation ends in 20 minutes. Then the system automatically operates with the previous settings used before POWERFUL operation.

### To cancel POWERFUL operation

- Press the **START/STOP** button. Or
- Press **POWERFUL** (POWERFUL) button again.

POWERFUL operation stops.


"**POWERFUL**" disappears from the LCD.

### NOTE

- When SLEEP mode, ECO mode, SILENT mode or LEAVE HOME mode is selected, POWERFUL operation is cancelled.
- During POWERFUL operation, capacity of the air conditioner will not increase
  - if the air conditioner is already running at maximum capacity.
  - just before defrost operation (when the air conditioner is running in HEATING operation).
- After auto restart, POWERFUL operation is cancelled and previous operation shall start.
- For multi model connections, POWERFUL operation may not function depending on operation conditions.

## SILENT OPERATION

- By pressing **SILENT** (SILENT) button during AUTO, HEATING, DEHUMIDIFYING, COOLING or FAN operation, the fan speed will change to ultra slow.



### To start SILENT operation

- Press **SILENT** (SILENT) button during operation.

"**SILENT**" is displayed on the LCD. Fan speed will be ultra slow.

### To cancel SILENT operation

- Press **START/STOP** button. Or

- Press **SILENT** (SILENT) button again or **FAN SPEED** button.

Fan speed will return to previous fan speed before SILENT operation starts.

SILENT operation stops.

"**SILENT**" disappears from the LCD.

### NOTE

- When POWERFUL operation is selected, SILENT operation is cancelled. Fan speed will return to previous fan speed before SILENT operation.
- After auto restart, SILENT operation is cancelled. Fan speed will return to previous fan speed before SILENT operation.
- During any operation with fan speed **SILENT** (SILENT), if press **SILENT** (SILENT) button, fan speed will not change.




## ECO OPERATION

There are two kinds of ECO OPERATION with sensor or without sensor, depending on models. Please refer to [Names and Functions of each part] in the unit instruction manual to verify if your unit is equipped with a sensor and read the following instruction on ECO Operation accordingly.

### ECO OPERATION

ECO operation is an energy saving function by changing set temperature automatically and by limiting the maximum power consumption value.



1

- By pressing the (ECO) button during AUTO, HEATING, DEHUMIDIFYING or COOLING operation, the air conditioner performs the "ECO" operation.

#### To start ECO operation

- Press (ECO) button during operation.
  - "" is displayed on the LCD.
  - A beep sound is emitted from indoor unit.
- Energy saving operation will start by changing the set temperature higher or lower automatically and reducing operation power consumption. This function may vary based on the connected outdoor unit.

#### To cancel ECO operation

- Press (START/STOP) button. Or
- Press (ECO) button again.
- "" disappears from the LCD.
- A beep sound is emitted from indoor unit.

#### NOTE


- ECO function will not be effective when power consumption is low.
- By pressing (POWERFUL) button, ECO operation is cancelled.
- After auto restart, ECO operation is cancelled and previous operation mode shall start.
- For multi model connections, energy saving operation shall start only by changing set temperature higher or lower automatically. However, effectiveness of ECO depends on operation conditions.



## ECO OPERATION

### ECO OPERATION with sensor

The sensor detects the presence of people in the room. When nobody is detected, the unit automatically starts energy saving operation by shifting the set temperature in two steps.



1

- By pressing the (ECO) button during AUTO, HEATING, DEHUMIDIFYING or COOLING operation, the air conditioner performs the "ECO" operation.

#### To start ECO operation


- Press (ECO) button during operation.
- "" is displayed on the LCD.
- A beep sound is emitted from indoor unit and the (ECO) lamp on the indoor unit lights up.
- The sensor starts to detect the presence of people in the room.

#### To cancel ECO operation


- Press (START/STOP) button. Or
- Press (ECO) button again.
- "" disappears from the LCD.
- A beep sound is emitted from indoor unit and the (ECO) lamp on the indoor unit turns off.

When the presence of people is not detected for 20 minutes, the set temperature is automatically shifted for energy saving. If nobody is in the room for 60 minutes, the set temperature is shifted further.

Cooling operation [diagram representation for illustrative purpose only]



Heating operation [diagram representation for illustrative purpose only]



The unit returns to normal operation when the sensor detects human movement.

#### NOTE


- By pressing (POWERFUL) button, ECO operation is cancelled.
- After auto restart, ECO operation is cancelled and previous operation mode shall start.



## 100% LEAVE HOME (LH) OPERATION

Prevent the room temperature from falling too much when no one is at home. The initial setting temperature is 10°C and the temperature range can be set between 10°C and 16°C. This operation is able to operate by "Continuous operation" or "Day timer operation". Please use "Day timer operation" to set the number of days up to 99 days.

### Continuous operation



### To start LEAVE HOME operation


#### Option 1. Continuous operation.

- Press **LEAVE HOME** (LEAVE HOME) button during stop or operation. Room temperature is set at 10°C and heating operation starts.
- Set the desired room temperature with the **TEMPERATURE** buttons. Temperature range can be set between 10°C and 16°C.  
 \* "10" : "LH", "11" : "LH", "12" : "LH", "13" : "SET TEMPERATURE" is displayed on the LCD.

#### Option 2. Day timer operation.

- Press **LEAVE HOME** (LEAVE HOME) button during stop or operation. Room temperature is set at 10°C and heating operation starts.
- Set the desired room temperature with the **TEMPERATURE** buttons. Temperature range can be set between 10°C and 16°C.  
 \* "10" : "LH", "11" : "LH", "12" : "LH", "13" : "SET TEMPERATURE" is displayed on the LCD.
- Set number of operation days (1 to 99 days), if needed.  
 Press **TIME** (TIME) button to select number of days.  
 Number of days blink.  
 \* Press "**UP**" or "**DOWN**" to set number of days from 1 day to 99 days.  
 \* Number of day is counted when clock indicates 0:00.

### Day timer operation



### To cancel LEAVE HOME operation


- Press **START/STOP** button. Or
- Press **LEAVE HOME** (LEAVE HOME) button again. Return to previous operation mode. Or
- Change to other operation mode by pressing **MODE** (MODE) button.

### NOTE

- After reaching the set number of operation days for Leave Home or by pressing the (Leave Home) button again, the unit will operate in previous mode.
- During Leave Home operation, fan speed and horizontal air deflector position cannot be changed.
- By pressing (Leave Home) button, implementation of Weekly Timer or Once Timer is cancelled.
- In case of power supply shut down, after autorestart, all setting for number of days operation will be reset and unit shall be in continuous operation.
- POWERFUL, SILENT** and **ECO** operations are not applicable during Leave Home operation.
- For multi connection
  - FAN/COOLING/DEHUMIDIFYING** and **Leave Home** cannot operate at the same time.
  - The first-run unit has a priority and other units in different mode will be in standby mode.
  - Heating operation can be used with **Leave Home**.
  - When two or more rooms are set to operate **Leave Home**, the temperature set by **Leave Home** may not be reached. It also depends on outdoor temperature.

## CLEAN (ONE TOUCH CLEAN) OPERATION

Drying indoor heat exchanger after cooling operation to prevent mildew.



### To start CLEAN operation

- Press **CLEAN** (CLEAN) button when unit is OFF. Total time taken for One Touch Clean operation is 60 minutes. During this operation, **HEATING** or **FAN** operation shall operate.  
 During one touch clean, operation lamp is blinking.

1

### To cancel CLEAN operation

- Press **START/STOP** button. Or
- Press **CLEAN** (CLEAN) button again.

### NOTE

- When **CLEAN** operation finish, unit will switch OFF automatically.
- If **Weekly Timer** or **Once Timer** is set, there is a need to cancel those timer before operating **CLEAN** function.
- For multi connections, when pressing **CLEAN** (CLEAN) button, operation is limited to **FAN** operation.
- For multi connections, when one room operates **CLEAN** operation first, other rooms can operate **COOLING, DEHUMIDIFYING** or **FAN** operation. However, when other rooms need to operate **HEATING** operation, air conditioner will be in **STANDBY** mode. After **CLEAN** operation finish, **HEATING** operation will start.



## ECO SLEEP TIMER OPERATION

### To set ECO SLEEP TIMER and ON TIMER

The air conditioner will be turned off by ECO SLEEP TIMER and turned on by ON TIMER.






1. Set the ON TIMER.
2. Press  (SLEEP) button and set ECO SLEEP TIMER.



Example:  
In this case, air conditioner will turn off in 2 hours (at 1:38) and it will be turned on at 6:00 the next morning.

### To cancel ECO SLEEP TIMER and ON TIMER operation


Direct the remote controller towards the indoor unit and press  (CANCEL) button.

-  ,  ,  ,  , "OFF", off time,  , "OFF", off time, "ON" and ON TIMER set time disappear from the remote controller display.
- A beep sound emitted from indoor unit and the (TIMER) lamp on the indoor unit turns off.
- ECO SLEEP TIMER and ON TIMER reservations are cancelled.


30 minutes after setting ECO SLEEP TIMER, outdoor fan speed will be reduced to lower the noise level and to have comfort operation.  
1 hour after setting ECO SLEEP TIMER, set temperature will be slightly shifted. Amount of temperature shifted depends on type of air conditioner.

These automatic operation changes contribute to energy saving without losing comfort.  
The level of energy consumption depends on outside temperature, room temperature, set temperature or air conditioner type.

Cooling operation [diagram representation for illustrative purpose only]



Heating operation [diagram representation for illustrative purpose only]



#### NOTE

- If ECO SLEEP TIMER is set when OFF TIMER or ON/OFF TIMER has been set earlier, the ECO SLEEP TIMER becomes effective instead of the OFF TIMER or ON/OFF TIMER.

## WEEKLY TIMER OPERATION


- It is possible to select Mode A or Mode B. For each mode, up to 6 programs can be set per day. In total, a maximum of 42 programs can be set for a week for each mode.
- If calendar and clock are not set, the reservation setting for WEEKLY TIMER cannot be set.
- If calendar and clock are not set correctly, WEEKLY TIMER will not operate correctly.
- Reservation for calendar and clock shall be set first before operating WEEKLY TIMER.

**Step 1:** Set the reservation schedule to the remote controller. Send the registered reservation to indoor unit and then operate.

**Step 2:** Select Mode A or Mode B and activate or deactivate WEEKLY TIMER .

**Step 3:** Copy and cancel the reservation schedule.

**Step 1:** Set reservation schedule to the remote controller. Send the registered reservation to indoor unit and then operate.









How to set a WEEKLY TIMER.

1. Select Mode A or Mode B


Press  (WEEKLY) button. WEEKLY lights up  and  blink on the display. (Mode A is selected).


Press  (WEEKLY) button again,  and  blink on the display. (Mode B is selected).

- If no reservation has been made, ON/OFF, , ,  appear.
- If reservation has been made, ON/OFF, , ,  will not appear.

2. Set a program

Press  (WEEKLY) button for about 3 seconds. The selection mode can be changed.

 . day: Mon, program no. : 1, ON/OFF, setting time and setting temperature blink on the display.



3. Select the desired day of the week

Press  (DAY) button.


The day changes from Mon → Tue → Wed → Thu → Fri → Sat → Sun → Mon, Tue, Wed, Thu, Fri, Sat, Sun [Full days] → Mon, Tue, Wed, Thu, Fri [weekday] → Sat, Sun [weekend] → Mon → Tue .....


Select [Full days] for daily reservation.

Select [weekday] for Monday to Friday reservation.

Select [weekend] for Saturday and Sunday reservation.

- After reservation has been set, it is easy to check and edit at the same time.




4. Press  button to select a program number.


The number changes from 1 → 2 → 3 → 4 → 5 → 6 → 1 → 2 .....

- If program number has been set, follow above in order to make changes.

## WEEKLY TIMER OPERATION



5. Press **OFF/TIMER ON** (ON-OFF TIMER) button to select ON TIMER or OFF TIMER reservation.




6. Press **TIME** (TIME) button to set time reservation.

7. Press **TEMP** (TEMP  $\wedge$  or  $\searrow$ ) button to set temperature reservation.

8. Press **OK** (OK) button. The reservations are set. Day, program number, ON reservation, setting temperature will light up. **ON** will be continuously blinks. If reservation is not complete, settings will not be stored in memory.

To continue with the reservation, press **MON-SUN** **1-6** **TIME** **OFF/TIMER ON** buttons. Follow step 3 to 8 for reservation.




9. After all the reservations have been set, press **SEND** (SEND) button while directing the remote controller towards the indoor unit for about 3 seconds. Timer lamp on the indoor unit will blink rapidly. After beep sound emitted from indoor unit, TIMER lamp will light up.

**Please ensure that the TIMER lamp lights up.**

This indicates that the reservation has been stored in the indoor unit and Timer function has been completed.


The reservation contents will appear on the remote controller display.



● If **TIMER** lamp on the indoor unit does not light up, press **SEND** (SEND) button while directing the remote controller towards the indoor unit for about 3 seconds.

● **CAUTION !** Do not press **CANCEL** (CANCEL) button during reservation setting because this will result in all reservation contents to be lost.

● The reservation contents will not stored in the indoor unit until **SEND** (SEND) button has been pressed.



### NOTE


- Up to 6 programs can be set per day. Setting ON TIMER or OFF TIMER for each program number can be at random. When pressing **SEND** (SEND) button, the set ON TIMER or OFF TIMER for each program number will automatically arranged so that program number 1 shall have the earliest time and program number 6 shall have the latest time.
- If the setting time is the same, Priority will be given to the latest reservation contents.
- **CAUTION !** If the remote controller is left idle and **SEND** (SEND) button is not pressed within 3 minutes after reservations have been made, all current reservations will be lost.

## ENGLISH

## WEEKLY TIMER OPERATION



### Step 2: Select Mode A or Mode B and activate or deactivate WEEKLY TIMER.



■ How to select Mode A or Mode B of WEEKLY TIMER setting.

1. Press **WEEKLY (A/B)** (WEEKLY) button. **A** and **B** blink on the display. (Normally Mode A will blink first).

2. Press **WEEKLY (A/B)** (WEEKLY) button again. **B** and **A** blink on the display.


3. Select Mode A or Mode B. Press **SEND** (SEND) button while directing the remote controller towards the indoor unit for about 3 seconds. Timer lamp on the indoor unit will blink rapidly.

After beep sound emitted from indoor unit, TIMER lamp will light up.

**Please ensure that the TIMER lamp lights up.**

This indicates that Mode A or Mode B selection and active WEEKLY TIMER have been confirmed.

■ Setting non-active WEEKLY TIMER .



1. Direct the remote controller towards the indoor unit and press **CANCEL** (CANCEL) button.

Beep sound will be emitted from indoor unit and TIMER lamp will be OFF. Reservation indication on remote display will also disappear. This indicates that non-active WEEKLY TIMER has been confirmed.

● To activate back the setting of WEEKLY TIMER, repeat the steps for "How to select Mode A or Mode B of WEEKLY TIMER setting".

### NOTE

- When setting ONCE TIMER, operation of WEEKLY TIMER is interrupted. After ONCE TIMER operation is complete, WEEKLY TIMER operation will be activated.
- When ONCE TIMER is cancelled, operation of WEEKLY TIMER is also cancelled. Need to set WEEKLY TIMER operation for activation.
- After auto restart, WEEKLY TIMER operation is cancelled. Need to set WEEKLY TIMER operation for activation.

## WEEKLY TIMER OPERATION



### Step 3: Copy and cancel the reservation schedule.

1. How to copy and paste. Editing the reservation schedule is easy by copying data from one day to another day.

2. Press **WEEKLY** (WEEKLY) button to select Mode A or Mode B.

3. Press **WEEKLY** (WEEKLY) button for about 3 seconds to start editing the reservation schedule.

4. Press **Mon-Sun** (DAY) button to select a day of the week to copy. \* Press **CANCEL** (CANCEL) button to cancel the COPY mode. Normal setting mode is activated.








5. Press **Mon-Sun** (DAY) button to select a day of the week to paste.

6. Press **COPY/PASTE** (COPY/PASTE) button one more time to paste. only blinks on the display.

7. To continue copying to other days, press **Mon-Sun** or **1-6** or or . Then start from step 3.

8. After copy and paste completed, press **SEND** (SEND) button while directing the remote controller towards the indoor unit for about 3 seconds. Timer lamp on the indoor unit will blink rapidly. After beep sound emitted from indoor unit, TIMER lamp will light up. **Please ensure that the TIMER lamp lights up.**

● Reservation data will not change if **SEND** (SEND) button is not pressed.

#### NOTE

- If there is no reservation data, copying data from one day to another day cannot be done.

## ENGLISH

## WEEKLY TIMER OPERATION



### Step 3: Copy and cancel the reservation schedule.

1. How to delete WEEKLY TIMER data. [Delete one program number reservation]

2. Press **WEEKLY** (WEEKLY) button to select Mode A or Mode B.

3. Press **WEEKLY** (WEEKLY) button for 3 seconds to start editing the reservation schedule.







4. Press **Mon-Sun** (DAY) button to select a day of the week to edit.

5. Press **1-6** to select program number. Selected program number will blink.

6. Press **DELETE** (DELETE) button. Reservation of selected program number is deleted.

7. After deleting, press **SEND** (SEND) button while directing the remote controller towards the indoor unit for about 3 seconds. Timer lamp on the indoor unit will blink rapidly. After beep sound emitted from indoor unit, TIMER lamp will light up. **Please ensure that the TIMER lamp lights up.**

● Reservation will not change if **SEND** (SEND) button is not pressed.

Step 3: Copy and cancel the reservation schedule.

[Delete one day reservation]

1. Press **WEEKLY** (WEEKLY) button to select Mode A or Mode B.
2. Press **WEEKLY** (WEEKLY) button for 3 seconds to start editing the reservation schedule.
3. Press **MON-SUN** (DAY) button to select a day of the week to edit.
4. Press **DELETE** (DELETE) button for about 10 seconds. Reservations for all program numbers will be deleted.
  - If press for a short time, reservation for one program number will be deleted.
5. After deleting, press **SEND** (SEND) button while directing the remote controller towards the indoor unit for about 3 seconds. Timer lamp on the indoor unit will blink rapidly.
 

After beep sound emitted from indoor unit, **TIMER lamp will light up.**

  - Reservation will not change if **SEND** (SEND) button is not pressed.

[Delete Mode A or Mode B]


1. Press **WEEKLY** (WEEKLY) button to select Mode A or Mode B.
2. Direct the remote controller towards the indoor unit and press **DELETE** (DELETE) button for about 10 seconds while Mode A or Mode B display blinks.
 

After beep sound emitted from indoor unit, reservations for Mode A or Mode B will disappear.

**NOTE**

- If all reservations in the remote controller were deleted and pressed **SEND** (SEND) button, no signal will be transmitted to indoor unit. **TIMER lamp will remain off** and no changes will be done to the reservations stored in the indoor unit.

- By pressing **INFO** (INFO) button, temperature around remote controller and monthly power consumption will be displayed on the remote controller.
- After changing the batteries, direct the remote controller towards the indoor unit and press **INFO** (INFO) button. Current calendar and clock will be transmitted from indoor unit.
- In order to receive information from indoor unit, the distance between remote controller and receiver of indoor units is within 2 meters.



- To check temperature around remote controller**

Press **INFO** (INFO) button.  
Temperature will be displayed for 10 seconds.
- To check monthly power consumption**

Direct the remote controller towards the receiver of indoor unit (within 2 meters in front of indoor unit) and press **INFO** (INFO) button. Wait for 2 seconds for signal transmission.  
While temperature around remote controller is displayed, press **INFO** (INFO) button repeatedly. The display will show as below:  
this month power consumption amount for heating → last month power consumption amount for heating → this month power consumption amount for cooling → last month power consumption amount for cooling → this month power consumption amount for heating ..... cyclically.

  - If indication is not given, bring remote controller closer to the receiver of the indoor unit.
  - Indicated value shall be regarded as a guide only.

- Current calendar and clock can be retrieved from indoor unit**

Direct the remote controller towards the receiver of indoor unit (within 2 meters in front of indoor unit) and press **INFO** (INFO) button. Wait for 2 seconds for signal transmission.  
Once received the current calendar and clock, check whether they are correct or not by pressing **CLOCK** (CLOCK) button.

  - If there is no power supply to indoor unit or calendar and clock have not been set, INFO function cannot be used for sending or receiving information.


**NOTE**

- In case failure occurs to the air conditioner, by pressing **INFO** (INFO) button, an error code will be displayed. Direct the remote controller towards the receiver of indoor unit (within 2 meters in front of indoor unit) and press **INFO** (INFO) button. Wait for 2 seconds for signal transmission.  
An error code will be displayed.  
Call service center and inform the error code.
- Information of "Monthly power consumption" is not available for 6 rooms multi system.
- Info Function to check monthly power consumption.  
During installation, in case of power failure or breaker ON / OFF, ensure to set the clock and calendar for each indoor unit (unit in standby mode or auto restart), for single or multi connection, by pressing **START / STOP** button.  
Failure to do the above, monthly power consumption amount will not be displayed on the remote controller.

# OPERATION MODE LOCK

ENGLISH

The remote controller can be set to fix the HEATING mode (including FAN), COOLING mode (including FAN) and DEHUMIDIFYING mode (including FAN) operations.



Method to lock HEATING mode (including FAN) operation.

Press **ECO** and **POWERFUL** buttons simultaneously for about 5 seconds when the remote controller is OFF.

"**☀**", "**☁**" and "**❄**" will be displayed for about 10 seconds. Later, "**☀**" and "**❄**" will remain.

This indicates that HEATING mode operation is locked.

When pressing **MODE** button, "**☀**" or "**☁**" will be displayed.

Method to unlock HEATING mode (including FAN) operation.

Press **ECO** and **POWERFUL** buttons simultaneously for about 5 seconds when the remote controller is OFF.

All operation mode symbols will appear on the display for about 10 seconds. After that, operation mode symbol before cancellation will be displayed. This indicates that HEATING mode operation is unlocked.

Method to lock COOLING and DEHUMIDIFYING modes (including FAN) operations.

Press **ECO** and **SILENT** buttons simultaneously for about 5 seconds when the remote controller is OFF.

"**☀**", "**☁**", "**❄**", "**☁**" and "**❄**" will be displayed for about 10 seconds. Later, "**☀**" and "**❄**" will remain.

This indicates that COOLING and DEHUMIDIFYING mode operation is locked.


When pressing **MODE** button, "**☀**", "**☁**" or "**❄**" will be displayed.

Method to unlock COOLING and DEHUMIDIFYING modes (including FAN) operations.

Press **ECO** and **SILENT** buttons simultaneously for about 5 seconds when the remote controller is OFF.

All operation mode symbols will appear on the display for about 10 seconds. After that, operation mode symbol before cancellation will be displayed.

This indicates that COOLING and DEHUMIDIFYING modes operation is unlocked.




## NOTE



- Operation Mode Lock function will not activate if TIMER reservations activate.
- TIMER reservations shall be deactivated first. Then, Operation Mode Lock function can be activated.
- HEATING, COOLING and DEHUMIDIFYING mode (including FAN) operations can be unlocked by pressing the **RESET** button. However, by pressing the **RESET** button, all the information stored in the remote controller will disappear. You may need to set the necessary information again.
- For multi connections, unit and mode which is set to lock HEATING and switched on first shall have higher priority. Other units which are chosen to operate at different modes shall be in STANDBY until either the first unit operation is switched off or the mode is selected to be same as the first unit.

# SAFETY PRECAUTION




- Please read the "Safety Precaution" carefully before operating the unit to ensure correct usage of the unit.
- Pay special attention to signs of "▲ Warning" and "▲ Caution". The "Warning" section contains matters which, if not observed strictly, may cause death or serious injury. The "Caution" section contains matters which may result in serious consequences if not observed properly. Please observe all instructions strictly to ensure safety.
- The signs indicate the following meanings. (The following are examples of signs.)

- ⓘ Make sure to connect earth line.  This sign in the figure indicates prohibition.
- ⓘ Indicates the instructions that must be followed.
- ⓘ Please keep this manual after reading.




## PRECAUTIONS DURING INSTALLATION

<b>▲ WARNING</b>	<ul style="list-style-type: none"> <li>• Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.</li> <li>• Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.</li> <li>• Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock or fire.</li> <li>• Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.</li> <li>• Do not install the unit near a location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.</li> <li>• Please ensure smooth flow of water when installing the drain hose.</li> <li>• Make sure that a single phase 220V~230V power source is used. The use of other power sources may cause electrical components to overheat and lead to fire.</li> </ul>	 PROHIBITION










## PRECAUTIONS DURING SHIFTING OR MAINTENANCE

<b>▲ WARNING</b>	<ul style="list-style-type: none"> <li>• Should abnormal situation arise (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.</li> <li>• Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.</li> <li>• Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Avoid an extended period of direct airflow for your health.</li> <li>• Do not put objects like thin rods into the panel of blower and suction side because the high-speed fan inside may cause danger.</li> <li>• Do not use any conductor as fuse wire, this could cause fatal accident.</li> <li>• During thunder storm, disconnect the plug top and turn off the circuit breaker.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Spray cans and other combustibles should not be located within a meter of the air outlets of both indoor and outdoor units. As a spray can's internal pressure can be increased by hot air, a rupture may result.</li> </ul>	 PROHIBITION

## PRECAUTIONS DURING OPERATION

<b>▲ WARNING</b>	<ul style="list-style-type: none"> <li>• Do not reconstruct the unit. Water leakage, fault, short circuit or fire may occur if you reconstruct the unit by yourself.</li> <li>• Please ask your sales agent or qualified technician for the installation of your unit. Water leakage, short circuit or fire may occur if you install the unit by yourself.</li> <li>• Please use earth line. Do not place the earth line near water or gas pipes, lightning-conductor, or the earth line of telephone. Improper installation of earth line may cause electric shock or fire.</li> <li>• Be sure to use the specified piping set for R410A. Otherwise, this may result in broken copper pipes or faults.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• A circuit breaker should be installed depending on the mounting site of the unit. Without a circuit breaker, the danger of electric shock exists.</li> <li>• Do not install the unit near a location where there is flammable gas. The outdoor unit may catch fire if flammable gas leaks around it.</li> <li>• Please ensure smooth flow of water when installing the drain hose.</li> <li>• Make sure that a single phase 220V~230V power source is used. The use of other power sources may cause electrical components to overheat and lead to fire.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Should abnormal situation arise (like burning smell), please stop operating the unit and turn off the circuit breaker. Contact your agent. Fault, short circuit or fire may occur if you continue to operate the unit under abnormal situation.</li> <li>• Please contact your agent for maintenance. Improper self maintenance may cause electric shock and fire.</li> <li>• Please contact your agent if you need to remove and reinstall the unit. Electric shock or fire may occur if you remove and reinstall the unit yourself improperly.</li> </ul>	 PROHIBITION

## PRECAUTIONS DURING OPERATION


<b>▲ CAUTION</b>	<ul style="list-style-type: none"> <li>• The product shall be operated under the manufacturer specification and not for any other intended use.</li> <li>• Do not attempt to operate the unit with wet hands, this could cause fatal accident.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• When operating the unit with burning equipments, regularly ventilate the room to avoid oxygen insufficiency.</li> <li>• Do not direct the cool air coming out from the air-conditioner panel to face household heating apparatus as this may affect the working of apparatus such as the electric kettle, oven etc.</li> </ul>	 STRICTLY OBSERVE PRECAUTIONS
	<ul style="list-style-type: none"> <li>• Please ensure that outdoor mounting frame is always stable, firm and without defect. If not, the outdoor unit may collapse and cause danger.</li> <li>• Do not wash the unit with water or place a water container such as a vase on the indoor unit. Electrical leakage could be present and cause electric shock.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Do not place plants directly under the airflow as it is bad for the plants.</li> <li>• Be sure to stop the operation by using the remote controller and turn off the circuit breaker during cleaning, the high-speed fan inside the unit may cause danger.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Turn off the circuit breaker if the unit is not operated for a long period.</li> <li>• Do not climb on the outdoor unit or put objects on it.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• When operating the unit with the door and windows opened, (the room humidity is always above 80%) and with the air deflector facing down or moving automatically for a long period of time, water will condense on the air deflector and drips down occasionally. This will wet your furniture. Therefore, do not operate under such condition for a long time.</li> <li>• If the amount of heat in the room is above the cooling or heating capability of the unit (for example: more people entering the room, using heating equipments and etc.), the preset room temperature cannot be achieved.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Indoor unit cleaning must be performed by authorized personnel only. Consult your sales agent. Using a commercially available detergent or similar can damage the plastic parts or clog the drain pipe, causing water to drip with potential electric shock hazard.</li> <li>• Do not touch the air outlet, bottom surface and aluminium fin of the outdoor unit. You may get hurt.</li> </ul>	 PROHIBITION
	<ul style="list-style-type: none"> <li>• Do not touch the refrigerant pipe and connecting valve. Burns may result.</li> <li>• This appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction. Children must be supervised not to play with the appliance.</li> </ul>	 DONT TOUCH
		 DONT TOUCH



**OPERATING RANGE**

Operation mode	Cooling / Dehumidifying	Heating
Outdoor temperature	-10 to 43°C	-15 to 21°C

**NAMES AND FUNCTIONS OF EACH PART**



**MODEL NAME AND DIMENSIONS**

MODEL	WIDTH	HEIGHT	DEPTH
RAF-25RXB, RAF-35RXB, RAF-50RXB	750mm (29-17/32")	590mm (23-6/25")	215mm (8-15/32")

**NOTE FOR MULTI SYSTEM**

Several indoor units can be connected to one outdoor unit. You can operate only one unit or several units according to your needs.

**Combination of operations:**

When operation mode is selected:


One unit	Other unit
	Cooling
Heating	Dehumidifying
	Fan

**During automatic operation:**


- When heating operation is automatically selected for the first indoor unit, the next indoor unit will then start to heat. Also, if cooling or dehumidifying is automatically selected for the first indoor unit, the next indoor unit will also start to cool or dehumidify.

**Adjusting the number of indoor units:**

Decrease the number of indoor units to be operated especially when it is very hot or very cold or when you want to reach the preset temperature quickly.




**TEMPORARY SWITCH**



**TEMPORARY SWITCH**  
Use this switch to start and stop when the remote controller does not work.

- By pressing the temporary switch, the operation is done in automatic mode.
- When the operation is done using the temporary switch after the power source is turned off and turn on again, the operation is done in automatic mode.

**INDOOR UNIT INDICATORS**



**FILTER lamp**  
This lamp lights when the device is operated for a total of about 200 hours, it is time to clean the filter. The lamp goes out when the "AUTO SWING" button is pressed while the operation is stopped.

**OPERATION lamp**

This lamp lights during operation. During heating, the operation indicator may blink, blowing very lightly or totally stopping under the following conditions:  
(1) **During preheating (heating operation)** For about 2-3 minutes after start up.  
(2) **During defrosting (heating operation)** Defrosting will be performed about once an hour when frost forms on the heat exchanger of the outdoor unit, for 5-10 minutes each time. (If the piping length used is longer than usual, frost will likely to form.)

**TIMER lamp**

This lamp lights when the timer is working.

**HOW TO OPEN OR CLOSE THE FRONT PANEL**


**Open the front panel**

- To open the front panel, use the remote controller to stop unit operation. Then press at the top left and right corners of the front panel.
- Grasp the left and right sides of the front panel and open it toward you.

**Close the front panel**

- To close the front panel, press at the top left and right corners of the front panel.
- Press the upper center part of the front panel to close properly.

Top left and right corners





Upper center part

## ADJUSTING THE AIR DEFLECTORS

1


Adjustment of the conditioned air in the upward and downward directions.  
The horizontal air deflector is automatically set to the proper angle suitable for each operation. The deflector can be swung up and down continuously and also set to the desired angle using the " (AUTO SWING)" button.

- If the " (AUTO SWING)" button is pressed once, the horizontal air deflector swings up and down. If the button is pressed again, the deflector stops in its current position.
- Use the horizontal air deflector within the adjusting range shown in the right figure.
- When the " (AUTO SWING)" button is pressed while the operation is stopped, the horizontal air deflector moves and stops at the position where the air outlet closes.
- When the auto swing operation is performed, if the horizontal air deflector is moved manually, the swinging range may drift. However, it will return to the original operation range after a short time.
- When the humid in the room is high during cooling or dehumidifying operation, the horizontal air deflector may automatically change to the straight direction to prevent dew (except during auto swing operation).
- For a certain period of time (about 30 minutes) after starting the cooling operation, it operates to cool the room quickly. During this operation, if the horizontal air deflector is adjusted to your preferred angle by " (AUTO SWING)" button, it returns to the proper angle automatically after a certain period of time. In this case, press " (AUTO SWING)" button to adjust the deflector to your preferred angle again.



2 Adjustment of the conditioned air to the left and right.

Hold the vertical air deflector as shown in the figure and adjust the conditioned air to the left and right.



Vertical air deflector

### CAUTION

- When operating the unit in cooling operation with the air deflector facing down and moving for a long period of time, water will be condensed on the air deflector and drips down occasionally. It will wet your furniture.

## CIRCUIT BREAKER

When you do not use the room air conditioner, set the circuit breaker to "OFF".

## HOW TO USE THE AIR CONDITIONER EFFECTIVELY

1. **An average room temperature setting is probably the best for you as well as being economical.**
  - Excessive cooling or heating is not recommended for health reasons. High electricity bills may also result.
  - Close the curtains or blinds to prevent heat from flowing into or escaping the room as well as to make more effective use of electricity.
2. **At intervals, the doors and windows should be opened to let fresh air in.**
  - **CAUTION** Make sure the room is ventilated when operating the air conditioner at the same time as other heating appliances.
3. **Using the timer is recommended before going to sleep or going out.**
4. **The following must never be used for cleaning the indoor and outdoor units:**
  - Benzine, thinner and scrub can damage plastic surfaces or coating.
  - Hot water above 40°C can shrink the filter and deform plastic parts.
5. **Do not block the air intake and air outlet.**
  - Do not block the air outlets and intakes of the indoor and outdoor units with curtains or other obstacles which could degrade air conditioner performance and cause unit failure.

## MAINTENANCE

### ▲ WARNING

- Before cleaning, stop unit operation with the remote controller and turn off the circuit breaker.

### ▲ CAUTION


- Do not expose the unit to water as it may cause an electric shock.
- For cleaning inside the air conditioner, consult your sales agent.
- Avoid using detergent when cleaning the heat exchanger of the indoor unit. Unit failure may result.
- When cleaning the heat exchanger with a vacuum cleaner, make sure to wear gloves so as not to injure your hands on the heat exchanger fins.

## 1. AIR FILTER

Clean the air filter, as it removes dust inside the room.

Be sure to clean the filter once every two weeks so as not to consume electricity unnecessarily.


### PROCEDURE



### 1

#### Open the front panel.

- To open the front panel, use the remote controller to stop unit operation. Then press at the top left and right corners of the front panel.
- Grasp the left and right sides of the front panel and open it toward you.



### 2

#### Remove the filters.

(Front side 2 pieces, upper side 2 pieces, total 4 pieces.)

### 3

#### Remove dust of the filters using a vacuum cleaner.

- After using neutral detergent, wash with clean water and dry in shade.

### 4


#### Attach the filters.

- Attaching the filters.  
(Front side 2 pieces, upper side 2 pieces, total 4 pieces.)

### 5

#### Close the front panel.

- To close the front panel, press at the top left and right corners of the front panel.
- Press the upper center part of the front panel to close properly.



### ▲ CAUTION


- Do not wash with hot water at more than 40°C. The filter may shrink.
- When washing it, shake off moisture completely and dry it in the shade; do not expose it directly to the sun. The filter may shrink. And also use a soft sponge to wash. Using a scrubber or brush cause the metal film on the surface to come off.
- Don't operate the unit without filter. Fault may occur if you continue.

## 2. HOW TO INSTALL AND REMOVE THE FRONT PANEL

- Be sure to use both hands to grasp the front panel when removing it or attaching it.
- The front panel may be installed up or down to suit user preference.

### Removing

- 1 Press the hook found at the tip of the resin band installed inside the front panel's right section to remove the resin band.
- 2 Pull the front panel down toward you and once fully open, pull it to remove.



### Attaching

- 1 Attach three front panel bearings to the axis of the front cover. (Set the hook to face up.)
- 2 Insert the tip of the resin band into the hole of the protrusion inside the right section of the front panel.

## 3. CLEANING OF FRONT PANEL

The front panel can be washed in water. It can be kept clean at all times.

- Front panel can be removed and washed in water. Gently clean the front panel using a soft sponge.
- When the air conditioner is to be cleaned without removing the front panel, clean both the body and remote controller with a dry soft cloth.
- Wipe off water completely. If water remains on the display section or light receiver section, this could cause a malfunction.




### ▲ CAUTION

- Do not splash or direct water to the body of the unit when cleaning it as this may cause short circuit.
- Never clean with hot water (above 40°C), benzene, gasoline, acid, thinner or a brush, because it will damage the plastic surface and the coating.





## 4. MAINTENANCE AT BEGINNING OF LONG OFF PERIOD

- Activating air conditioner drying will keep the interior of the indoor unit dry and prevent mold formation.
- Turn off the circuit breaker.



## REGULAR INSPECTION

PLEASE CHECK THE FOLLOWING POINTS EVERY EITHER HALF YEARLY OR YEARLY. CONTACT YOUR SALES AGENT SHOULD YOU NEED ANY HELP.

1		<b>WARNING</b>	<p><b>Check to see if the unit's earth line has been connected correctly.</b> If the earth line is disconnected or faulty, unit failure or electric shock hazard may result.</p>
2		<b>WARNING</b>	<p><b>Check to see if the mounting frame has rusted excessively or if the outdoor unit has tilted or become unstable.</b> It could collapse or fall, causing injury.</p>

## AFTER SALES SERVICE AND WARRANTY

### WHEN ASKING FOR SERVICE, CHECK THE FOLLOWING


CONDITION	CHECK THE FOLLOWING POINTS
<p>If the remote controller is not transmitting a signal. (Remote controller display is dim or blank.)</p> <p style="text-align: center;">↑</p>	<ul style="list-style-type: none"> <li>Do the batteries need replacement?</li> <li>Is the polarity of the inserted batteries correct?</li> </ul>
<p>When it does not operate.</p> <p style="text-align: center;">↑</p>	<ul style="list-style-type: none"> <li>Is the fuse all right?</li> <li>Is the voltage extremely high or low?</li> <li>Is the circuit breaker "ON"?</li> <li>Is the setting of operation mode different from other indoor units?</li> </ul>
<p>When it does not cool well. When it does not heat well.</p> <p style="text-align: center;">↑</p>	<ul style="list-style-type: none"> <li>Is the air filter blocked with dust?</li> <li>Is the set temperature suitable?</li> <li>Have the top and bottom air deflectors been adjusted to their correct positions according to the operation mode selected?</li> <li>Are the air inlets or air outlets of indoor and outdoor units blocked?</li> <li>Is the fan speed "LOW" or "SILENT"?</li> </ul>

■ The following phenomena do not indicate unit failure.

<p>&lt;Operation start&gt; The unit is preparing to blow warm air. Please wait.</p> <p>&lt;In operation&gt; The outdoor unit is defrosting. Please wait.</p>	<p>During heating, the operation indicator blinks and air flow stops</p>
<p>Refrigerant flow noise in the pipe or valve sound generated when flow rate is adjusted.</p>	<p>Hissing or fizzy sounds</p>
<p>Noise generated when the unit expands or contracts due to temperature changes.</p>	<p>Squeaking noise</p>
<p>Noise generated with the indoor unit fan's rpm changing such as operation start times.</p>	<p>Rustling noise</p>
<p>Noise of the motorized valve when the unit is switched on.</p>	<p>Clicking noise</p>
<p>Noise of the ventilation fan sucking in air present in the drain hose and blowing out dehumidifying water that had accumulated in the condensed water collector. For details, consult your sales agent.</p>	<p>Perking noise</p>
<p>Operation noise changes due to power variations according to room temperature changes.</p>	<p>Changing operation noise</p>
<p>Mist is generated as the air within the room is suddenly cooled by conditioned air.</p>	<p>Mist emission</p>

## 5. AIR CLEANSING FILTERS (SPX-CFH15)

- When installing the air cleansing filters, remove the air filters and attach them onto the hooks of the front cover frame.
- The cooling capacity is slightly weakened and the cooling speed becomes slower when the air cleansing filters are used. So, set the fan speed to "HIGH" when using it in this condition.
- The air cleansing filters can be used for 2 years.



## INFORMATION

### CAPABILITIES

#### Heating Capability

- This room air conditioner utilizes a heat pump system that absorbs exterior heat and brings it into a room to be heated. As the ambient temperature gets lower, heating capability will also lower. In such a situation, the PAM and inverter work to increase compressor rpm to keep the unit's heating capability from decreasing. If the unit's heating performance is still unsatisfactory, other heating appliances should be used to augment this unit's performance.
- The air conditioner is designed to heat an entire room so that it may take some time before you feel warm. Timer operation is recommended for effective preheating ahead of the desired time.



**CAUTION**  
Do not use a stove or any other high-temperature devices in proximity to the indoor unit.

#### Cooling and Dehumidifying Capabilities

- If the heat present in a room exceeds the unit's cooling capacity (for example, if there are many people in the room or other heating appliances are used), the preset room temperature may not be reached.

Steam emitted from the outdoor unit	Water generated during defrosting operation evaporates and steam is emitted.
Odors	Caused as the smells and particles of smoke, food, cosmetics, etc. present in room air become attached to the unit and blown off into the room again.
The outdoor unit continues to operate even if operation is stopped	Defrosting is underway (as the heating operation is stopped, the microcomputer checks frost accumulated in the indoor unit and instructs the unit to perform automatic defrosting if necessary).
The OPERATION lamp is blinking	Shows preheating or defrosting operation is underway. As the protective circuit or preheat sensor operates when unit operation is stopped during preheating and then restarted, or when operation mode is switched from cooling to heating, the lamp continues to blink.
Does not reach the temperature setting	Actual room temperature may deviate slightly from the remote controller's temperature setting depending on the number of people in the room, indoor or outdoor conditions when the air conditioner is used for more than one room at the same time.

- If the unit still fails to operate normally after performing the above inspections, turn the circuit breaker off and contact your sales agent immediately.

**Contact your sales agent immediately if the following phenomena should occur:**

- The circuit breaker switches off or the fuse blows frequently.
- The switch operation is not stable.
- Foreign matter or water accidentally enters the unit interior.
- The power cord gets excessively hot or its insulation is torn or stripped.
- TIMER lamp on the indoor unit display blinks.  
(As the nature of the failure can be identified by the blinking cycle, check the blinking cycle before turning off the circuit breaker.)



**Notes**

- In quiet operation or stopping the running, the following phenomena may occasionally occur, but they are not abnormal for the operation.
  - (1) Slight flowing noise of refrigerant in the refrigerating cycle.
  - (2) Slight rubbing noise from the fan casing which is cooled and then gradually warmed as operation stops.
- The odor will possibly be emitted from the room air conditioner because the various odor, emitted by smoke, foodstuffs, cosmetics and so on, sticks to it. So please clean the air filter and the evaporator regularly to reduce the odor.



- Please contact your sales agent immediately if the air conditioner still fails to operate normally after the above inspections. Inform your agent of the model of your unit, production number, date of installation. Please also inform him regarding the fault.

**Please note:**


On switching on the equipment, particularly when the room light is dimmed, a slight brightness fluctuation may occur. This is of no consequence.  
The conditions of the local Power Supply Companies are to be observed.

# CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAF-25RXB,RAF-35RXB,RAF-50RXB

INDOOR UNIT

Unit : mm




# CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAC-25FXB, RAC-35FXB

OUTDOOR UNIT

Unit : mm



**NOTE:**




1. For outdoor unit installation, allow at least 2 sides of space around the unit ensure ventilation flue.
2. The connecting pipe, should all the insulated with insulation pipe.
3. Piping length is within 20m.
4. Height different of the piping between the indoor unit and outdoor unit should be within 10m.

# CONSTRUCTION AND DIMENSIONAL DIAGRAM

MODEL RAC-50FXB

OUTDOOR UNIT

Unit : mm



**NOTE:**

1. For outdoor unit installation, allow at least 2 sides of space around the unit ensure ventilation flue.
2. The connecting pipe, should all the insulated with insulation pipe.
3. Piping length is within 20m.
4. Height different of the piping between the indoor unit and outdoor unit should be within 10m.



# MAIN PARTS COMPONENT



## THERMOSTAT (Room temperature Thermistor)

Thermostat Specifications

MODEL			RAF-25RXB,RAF-35RXB,RAF-50RXB			
THERMOSTAT MODEL			IC			
OPERATION MODE			COOL		HEAT	
TEMPERATURE °C (°F)	INDICATION 16	ON	15.3	(59.54)	16.7	(62.06)
		OFF	15.0	(59.00)	16.7	(62.06)
	INDICATION 24	ON	23.3	(73.94)	24.7	(76.46)
		OFF	23.0	(73.40)	24.7	(76.46)
	INDICATION 32	ON	31.3	(88.34)	32.7	(90.86)
		OFF	31.0	(87.80)	32.7	(90.86)

## FAN MOTOR

Fan Motor Specifications

MODEL	RAF-25/35/50RXB	RAC-25/35/50FXB
POWER SOURCE	DC : 280V	DC : 120 - 380V
OUTPUT	38W	47W
CONNECTION	 <p>(Control circuit built in)</p>	

BLU : BLUE  
GRY : GRAY  
BLK : BLACK

YEL : YELLOW  
ORN : ORANGE  
PNK : PINK

BRN : BROWN  
GRN : GREEN  
VIO : VIOLET

WHT : WHITE  
RED : RED


## MAIN ELECTRIC COMPONENTS FOR OUTDOOR UNIT

NAME	RATING	APPLICABLE MODELS
REACTOR	15 (mH) 230 mΩ MAX (20 °C)	RAC-25/35FXB
	5.3 (mH), 67mΩ	RAC-50FXB

# COMPRESSOR MOTOR

## Compressor Motor Specifications

MODEL		RAC-25/35FXB	RAC-50FXB
COMPRESSOR TYPE		ASD084SFNA7JK1	ASG133CDNB7AT
POWER SOURCE		100 - 240 V	220 - 350 V
CONNECTION			
RESISTANCE VALUE ( $\Omega$ )	25°C	2M= 0.74	2M= 2.4
	75°C	2M= 0.88	2M= 2.0



FRONT SIDE OF OUTDOOR UNIT

### **CAUTION**

When the refrigerating cycle has been operated for a long time with the capillary tubes clogged or crushed or with too little refrigerant, check the color of the refrigerating machine oil inside the compressor. If the color has been changed conspicuously, replace the compressor.


# WIRING DIAGRAM

INDOOR UNIT

MODEL RAF-25/35/50RXB

## WIRING DIAGRAM

BLK:BLACK GRN:GREEN  
RED:RED WHT:WHITE  
GRY:GRAY



**CAUTION !**  
HIGH VOLTAGE


TURN OFF THE POWER SOURCE  
DURING THE SERVICE WORK.

OUTDOOR UNIT

MODEL RAC-25/35FXB

## WIRING DIAGRAM

BLU:BLUE RED:RED  
BLK:BLACK WHT:WHITE  
BRN:BROWN YEL:YELLOW  
GRN:GREEN GRY:GRAY




INDOOR UNIT

OUTDOOR UNIT

MODEL RAC-50FXB

## WIRING DIAGRAM




BLU:BLUE RED:RED  
BLK:BLACK WHT:WHITE  
BRN:BROWN YEL:YELLOW  
GRN:GREEN GRY:GRAY



INDOOR UNIT

# WIRING DIAGRAM OF THE PRINTED WIRING BOARD

[Remote controller] RAR-6N4










**BLOCK DIAGRAM**  
**MODEL RAF-25/35/50RXB**  
**RAC-25/35/50FXB**





# BASIC MODE


MODEL RAF-25/35/50RXB

Operation mode	Fan	Cooling	Dehumidifying	Heating	Auto	
Basic operation of start/stop button						
Timer functions	Off-timer					
	On-timer					
	Off -> On On -> Off timer					
Fan speed mode (indoor fan)	Auto	<p>Changes from "Hi" to "Med" or "Lo" depending on room temperature.</p> <p>1. Runs at "Hi" until room temperature reaches to "setting temperature-SFTDSC" after operation is started. 2. Runs at "ultra-Lo" when thermo is off.</p>		<p>Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.)</p> <p>In modes other than left</p> <p>When the compressor is running at maximum speed during hot-dash or when recovered from defrosting.</p> <p>90° Fan speed UP/DOWN delay time</p>	<p>Operating mode is judged by room temperature.</p> <p>(1) Judging by room temperature</p> <ul style="list-style-type: none"> <li>Operating mode at start up is judged (initial judgment).</li> <li>(a) Conditions for judgment (any of the followings). <ul style="list-style-type: none"> <li>When auto operation is started after the previous auto mode operation.</li> <li>When auto operation is started after the previous manual mode operation.</li> <li>When the operating mode is switched to auto while operating at manual mode.</li> </ul> </li> <li>(b) Judging method <ul style="list-style-type: none"> <li>[ Cooling ] : Room temperature <math>\geq</math> Remote controller setting</li> <li>[ Heating ] : Room temperature <math>&lt;</math> Remote controller setting</li> </ul> </li> </ul> <p>(2) Judging operating mode change during operation (Continuous judgment)</p> <p>(a) Conditions for judgment</p> <ul style="list-style-type: none"> <li>The mode is reviewed at interval time.</li> <li>Interval time as below <ul style="list-style-type: none"> <li>The first interval time : 10 minutes</li> <li>The second interval time : 15 minutes</li> <li>On and after the third interval time : 55 minutes</li> </ul> </li> </ul> <p>(b) Judging method</p> <ul style="list-style-type: none"> <li>Judge by setting the hysteresis on the final preset temperature.</li> <li>The final preset temperature is the actually targeted preset temperature which is sum of basic preset temperature and each type of shift value.</li> <li>(e.g. preset temperature correction value, powerful shift value, eco shift value, eco sleep shift value, etc.)</li> </ul> <p>[ Currently cooling ]</p> <ul style="list-style-type: none"> <li>Room temperature <math>\leq</math> Final preset temperature - 3°C Change to heating</li> <li>Room temperature <math>&gt;</math> Final preset temperature - 3°C Continue cooling</li> </ul> <p>[ Currently heating ]</p> <ul style="list-style-type: none"> <li>Room temperature <math>\geq</math> Final preset temperature + 2°C Change to cooling</li> <li>Room temperature <math>&lt;</math> Final preset temperature + 2°C Continue heating</li> </ul>	
	Hi	Operates at "Hi" regardless of the room temperature.	Set to "ultra-Hi" when the compressor runs at cold dash mode speed, and to "Hi" in other modes. Runs at "ultra-Lo" when thermo is off.		Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.) Set to "ultra-Hi" when the compressor is running at maximum speed during hot dash or when recovered from defrosting.	
	Med	Operates at "Med" regardless of the room temperature.	Operates at "Med" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.		Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.)	
	Lo	Operates at "Lo" regardless of the room temperature.	Operates at "Lo" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.	Set to "Lo" in modes other than when the compressor stops.	Set to "ultra-Lo", "Silent", "Lo", "Med", "Hi", "ultra-Hi" or "stop" depending on the room temperature, time and heat exchanger temperature. Set to "stop" if the heat exchanger temperature is "DNZKOF" during Thermo OFF. (When reach at "DNZKON", fan speed set to "ultra-Lo" again.) The fan speed is controlled by the heat exchanger temperature; the overload control is executed as in the following diagram:	
	Silent	Operates at "Silent" regardless of the room temperature.	Operates at "Silent" regardless of the room temperature. Runs at "ultra-Lo" when thermo is off.	Set to "Silent" in modes other than when the compressor stops.		
Basic operation of temperature controller	Performs only fan operation at the set speed regardless of the room temperature.	See page 8-3.	See page 8-5.	See page 8-7.		
Sleep operation (with sleep button ON)	<ul style="list-style-type: none"> <li>Enters sleep operation after set as on the left.</li> <li>Action during sleep operation Lo (sleep) operation</li> </ul>	<ul style="list-style-type: none"> <li>Same as at left</li> <li>See page 8-4.</li> </ul>	<ul style="list-style-type: none"> <li>Same as at left</li> <li>See page 8-6.</li> </ul>	<ul style="list-style-type: none"> <li>Same as at left</li> <li>See page 8-8.</li> </ul>	<ul style="list-style-type: none"> <li>Same as at left.</li> <li>Performs the sleep operation of each operation mode.</li> </ul>	

Table 1 Mode data file




MODEL	RAF-25RXB	RAF-35RXB	RAF-50RXB
LABEL NAME	VALUE		
WMAX	6000 min <sup>-1</sup>	6000 min <sup>-1</sup>	6000 min <sup>-1</sup>
WMAX2	6000 min <sup>-1</sup>	6000 min <sup>-1</sup>	6000 min <sup>-1</sup>
WSTD	4000 min <sup>-1</sup>	4550 min <sup>-1</sup>	4800 min <sup>-1</sup>
WJKMAX	3400 min <sup>-1</sup>	3400 min <sup>-1</sup>	4200 min <sup>-1</sup>
WBEMAX	3200 min <sup>-1</sup>	3200 min <sup>-1</sup>	3400 min <sup>-1</sup>
WSZMAX	3200 min <sup>-1</sup>	3200 min <sup>-1</sup>	3400 min <sup>-1</sup>
CMAX	3600 min <sup>-1</sup>	3800 min <sup>-1</sup>	4900 min <sup>-1</sup>
CMAX2	3600 min <sup>-1</sup>	3800 min <sup>-1</sup>	4900 min <sup>-1</sup>
CLMXTP	30.00 °C	30.00 °C	30.00 °C
CSTD	2800 min <sup>-1</sup>	3400 min <sup>-1</sup>	4750 min <sup>-1</sup>
CJKMAX	2200 min <sup>-1</sup>	2200 min <sup>-1</sup>	3200 min <sup>-1</sup>
CBEMAX	1700 min <sup>-1</sup>	1700 min <sup>-1</sup>	2200 min <sup>-1</sup>
CSZMAX	1700 min <sup>-1</sup>	1700 min <sup>-1</sup>	2200 min <sup>-1</sup>
WMIN_CMPH	2800 min <sup>-1</sup>	2800 min <sup>-1</sup>	3200 min <sup>-1</sup>
WMIN_CMPL	2800 min <sup>-1</sup>	2800 min <sup>-1</sup>	3200 min <sup>-1</sup>
CMIN	1100 min <sup>-1</sup>	1100 min <sup>-1</sup>	1800 min <sup>-1</sup>
STARTMC	60 Seconds	60 Seconds	70 Seconds
DWNRATEW	80 %	80 %	80 %
DWNRATEC	60 %	60 %	60 %
SHIFTW	0.00 °C	0.00 °C	0.00 °C
SHIFTC	0.00 °C	0.00 °C	0.00 °C
OFTMPC	1.00 °C	1.00 °C	1.00 °C
FCAUT_H	2.00 °C	2.00 °C	1.00 °C
FCAUT_L	0.66 °C	0.66 °C	0.00 °C
TEION	2.00 °C	2.00 °C	1.00 °C
TEIOF	9.00 °C	9.00 °C	9.00 °C
PDCIN2	50.00 °C	50.00 °C	50.00 °C
PDCOF2	44.00 °C	44.00 °C	44.00 °C
DNZKON	15.00 °C	15.00 °C	15.00 °C
DNZKOF	13.00 °C	13.00 °C	13.00 °C
DASUPHH	45.00 °C	45.00 °C	45.00 °C
DASDNHH	44.00 °C	44.00 °C	44.00 °C
DASUPH	44.00 °C	44.00 °C	44.00 °C
DASDNH	40.00 °C	40.00 °C	40.00 °C
DASUPL	40.00 °C	40.00 °C	40.00 °C
DASDNL	37.00 °C	37.00 °C	37.00 °C
DASUPS	35.00 °C	35.00 °C	35.00 °C
DASDNS	33.00 °C	33.00 °C	33.00 °C
NORUPH	49.00 °C	49.00 °C	49.00 °C
NORDNH	47.00 °C	47.00 °C	47.00 °C
NORUPL	45.00 °C	45.00 °C	45.00 °C
NORDNL	42.00 °C	42.00 °C	42.00 °C
NORUPS	42.00 °C	42.00 °C	42.00 °C
NORDNS	40.00 °C	40.00 °C	40.00 °C
SFTDSW	0.66 °C	0.66 °C	0.66 °C
SFTDSC	1.00 °C	1.00 °C	1.00 °C
DFTIM_OTP0	43 Minutes	43 Minutes	51 Minutes
DFTIM_OTP5	100 Minutes	115 Minutes	61 Minutes
DFTIM_OTP10	50 Minutes	50 Minutes	120 Minutes
DFMAX_STD	4300 min <sup>-1</sup>	4550 min <sup>-1</sup>	5400 min <sup>-1</sup>
DFMAX_ATF	4000 min <sup>-1</sup>	4000 min <sup>-1</sup>	4000 min <sup>-1</sup>
FNUPPW_C	30 min <sup>-1</sup>	30 min <sup>-1</sup>	30 min <sup>-1</sup>
FUDICOL1_DSH	10 °	10 °	10 °
FUDICOL2_DSH	70 °	70 °	70 °
TYONTM_M	0.0 Hour	0.0 Hour	0.0 Hour

## Basic Cooling Operation




### Notes:

- (1) Condition for entering into Cool Dashed mode. When fan set to "Hi" or "Auto" and when the compressor speed (P section) due to temperature difference between setting temperature (including the correction shift only) and room temperature is  $C_{MAX}$  or higher.
- (2) Cool Dashed will release when i) a maximum 25 minutes is lapsed and ii) room temperature is lower than set temperature  $-3^{\circ}\text{C}$  (thermo off) and iii) when room temperature has achieved setting temperature  $-1^{\circ}\text{C}$  then maximum Cool Dashed time will be revised to 20 minutes. And iv) indoor fan is set to Lo and Med fan mode and v) change operation mode.
- (3) During Cool Dashed operation, thermo off temperature is set temperature (with shift value)  $-3^{\circ}\text{C}$ . After thermo off, operation continue in Fuzzy control mode.
- (4) Compressor minimum "ON" time and "OFF" time is 3 minutes.
- (5) During normal cooling mode, compressor maximum rpm  $C_{MAX}$  will maintain for 60 minutes if indoor temperature is lower than  $CLM_{XTP}$ . No time constrain if indoor temperature is higher than  $CLM_{XTP}$ .
- (6) When fan is set to "Hi", compressor rpm will be limited to  $C_{STD}$ .
- (7) When fan is set to "Med", compressor rpm will be limited to  $C_{JMAX}$ .
- (8) When fan is set to "Lo", compressor rpm will be limited to  $C_{BEMAX}$ .
- (9) During Cool Dashed, when room temperature reaches set temperature  $-1^{\circ}\text{C}$  compressor rpm is actual rpm x  $DWNRATEC$ .




# Dehumidifying



**Notes:**

- (1) If the room temperature is (cooling preset temperature) -  $(1.33^{\circ}\text{C})$  or less after 30 seconds from starting the operation, the operation is done assuming as the preset temperature = (room temperature at the time) -  $(2^{\circ}\text{C})$ .
- (2) The indoor fan is operated in the "Lo" mode. During thermo OFF indoor fan will be OFF for 5 minutes and ON for 1 minute.
- (3) When the operation is started by the thermostat turning ON, the start of the indoor fan is delayed 32 seconds after the start of compressor operation.
- (4) The compressor is operated forcedly for 3 minutes after operation is started.
- (5) The minimum ON time and OFF time of the compressor are 3 minutes.


## Dehumidifying Powerful Operation



### Notes :

- (1) Pressing the "POWERFUL" button will reduce the temperature setting by PWSFTSD.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (5) If the sleep timer is set during powerful operation, the powerful operation will be canceled.
- (6) If the differential (the room temperature - the temperature setting) is "the differential  $\geq 3\text{ }^{\circ}\text{C}$ " after powerful setting, the compressor's maximum speed during powerful operation will be set to SDMAX. Then the differential reduce "the differential  $\leq 2.33\text{ }^{\circ}\text{C}$ " during powerful operation, the compressor's speed will be set to SDRPM.  
If the differential (the room temperature - the temperature setting) is "the differential  $< 3\text{ }^{\circ}\text{C}$ " after powerful setting, the compressor's minimum speed during powerful operation will be set to SDRPM.
- (7) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


## Dehumidifying Sleep Operation



### Notes :




- (1) The sleep operation starts when the "SLEEP" button is pressed.
- (2) When the sleep operation is set, the indoor fan set is "sleep"(FDOY\_P).
- (3) The indoor fan speed does not change even when the fan speed mode is changed.
- (4) If sleep operation is canceled by the cancel button or sleep button, all data is cleared.
- (5) 1 hour after the sleep operation is set, the sleep shift value(OYSFTSD) is added.

## Basic Heating Operation




**Notes:**

- (1) Condition for entering into hot dashed mode. When fan set to "Hi" or "Auto" and i) room temperature is 18 or less, and ii) outdoor temperature is 10 or less, and iii) compressor speed (P section) due to temperature difference between setting temperature(including shift value only) and room temperature is WMAX or more.
- (2) The maximum compressor speed period during hot dash is finished when i) room temperature has reached the setting temperature + SFTDSW. ii) thermo off.
- (3) During hot dashed operation, thermo off temperature is setting temperature (with shift value) +3 . After thermo off, operation continue inn Fuzzy control mode.
- (4) Minimum "ON" time and minimum "OFF" time of compressor operation is 3 minutes.
- (5) During normal heating mode, compressor maximum rpm WMAX will maintain for 120 minutes. No time limit constrain if room temperature is 18 or less and outdoor temperature is 2 or less.
- (6) During preheating or defrosting or auto fresh defrosting mode, indoor unit operation lamp will blink at interval of 2 seconds "ON" and 1 second "OFF".
- (7) When heating mode starts, it will enter into preheating mode if indoor heat exchanger temperature is less than YNEOF + 0.33 .
- (8) When fan is set to "Med" or "Lo" or "Silent", compressor rpm will be limited to "WJKMAX" or "WBEMAX" or "WSZMAX".
- (9) During "Ultra-Lo" mode, if room temperature is 18 or less, indoor fan will stop. If room temperature is 18 + 0.33 or more, fan will continue in "Ultra-Lo" mode. However, "Ulrrta-Lo" mode during preheating or preheating after defrosting does not stop if room temperature is 18 or less.
- (10) During hot dashed or outdoor temperature is -5 or less, compressor rpm is WMAX2.
- (11) During hot dashed, when room temperature reaches setting temperature + SFTDSW compressor rpm is actual rpm x DWNRATEW.






## Heating Powerful Operation



### Notes :

- (1) Pressing the "POWERFUL" button will increase the temperature setting by PWSFTW.
- (2) The powerful operation is for 20 minutes after setting.
- (3) Operation is continued forcibly thermo-ON for 20 minutes after the powerful operation is finished.
- (4) Defrost is inhibited for 20 minutes after the start of the powerful operation.
- (5) Pressing the "START/STOP" button and "POWERFUL" button during powerful operation will cancel the powerful operation.
- (6) If the sleep timer is set during powerful operation, the powerful operation will be canceled.
- (7) When the powerful operation is set, the fan speed will be set to "HIGH" and the compressor's maximum speed will be set to WMAX2 during powerful operation. The compressor's lower limit speed is WKYMIN\_PW.
- (8) After the powerful operation is ended, the system automatically operates with the previous settings used before the powerful operation.


## Setting Defrosting Inhibit Period



### Notes:

- (1) The first inhibit time after operation start is set to DFTIM\_FST.
- (2) From the second time onwards, the inhibit time is set according to the time required for defrosting.  
Reverse cycle operation time  $\geq$  [DEFCOL] : DEFTIM\_COL is set.  
Reverse cycle operation time  $<$  [DEFCOL] : The time corresponding to outdoor temperature is set.

## Leave Home




### Notes:

Perform Leave Home operation according to the following control contents.

- (1) Operation mode : Heating
- (2) Temperature setting correction shift : + 『SFTLVHM』
- (3) Indoor fan : 『FWH\_P』
- (4) Outdoor fan speed :
- (5) Compressor start control : } Same as Basic Heating operation
- (6) Compressor speed :
- (7) Lamp indication : i) Operation lamp : ON  
ii) Timer lamp : OFF( Continuous operation ) ; ON( Day timer operation )


## Reversing valve defrosting



**Notes:**

- (1) The defrosting inhibit period is set as shown in the diagram below. When defrosting has finished once, the inhibit period is newly set, based on the outdoor temperature when the compressor was started. During this period, the defrost signal is not accepted.
- (2) If the difference between the room and outdoor temperature is large when defrosting is finished, the maximum compressor speed (WMAX) or (WMAX2) can be continued for 120 minutes maximum.
- (3) The defrosting period is 20 minutes maximum.
- (4) When operation is stopped during defrosting, it is switched to auto refresh defrosting.
- (5) Auto refresh defrosting cannot be engaged within 15 minutes after operation is started or defrosting is finished.

## Reversing valve defrosting




**Notes:**

- (1) The defrosting inhibit period is set as shown in the diagram below. When defrosting has finished once, the inhibit period is newly set, based on the outdoor temperature when the compressor was started. During this period, the defrost signal is not accepted.
- (2) If the difference between the room and outdoor temperature is large when defrosting is finished, the maximum compressor speed (WMAX) or (WMAX2) can be continued for 120 minutes maximum.
- (3) The defrosting period is 20 minutes maximum.
- (4) When operation is stopped during defrosting, it is switched to auto refresh defrosting.
- (5) Auto refresh defrosting cannot be engaged within 15 minutes after operation is started or defrosting is finished.


# REFRIGERATING CYCLE DIAGRAM

MODEL RAF-25/35RXB  
 RAC-25/35FXB



# REFRIGERATING CYCLE DIAGRAM

MODEL RAF-50RXB  
RAC-50FXB



# Procedure for Disassembly and Reassembly


## <INDOOR UNIT> RAF-25/35/50RXB

### 1. AIR FILTER


Clean the air filter, as it removes dust inside the room.  
Be sure to clean the filter once every two weeks so as not to consume electricity unnecessarily.

#### PROCEDURE

- 1 Open the front panel.**
  - To open the front panel, use the remote controller to stop unit operation. Then press at the top left and right corners of the front panel.
  - Grasp the left and right sides of the front panel and open it toward you.



- 2 Remove the filters.**  
(Front side 2 pieces, upper side 2 pieces, total 4 pieces.)




- 3 Remove dust of the filters using a vacuum cleaner.**
  - After using neutral detergent, wash with clean water and dry in shade.



- 4 Attach the filters.**
  - Attaching the filters.
  - (Front side 2 pieces, upper side 2 pieces, total 4 pieces.)

- 5 Close the front panel.**
  - To close the front panel, press at the top left and right corners of the front panel.
  - Press the upper center part of the front panel to close properly.





### 2. HOW TO INSTALL AND REMOVE THE FRONT PANEL

- Be sure to use both hands to grasp the front panel when removing it or attaching it.
- The front panel may be installed up or down to suit user preference.

#### Removing


- Press the hook found at the tip of the resin band installed inside the front panel's right section to remove the resin band.
- Pull the front panel down toward you and once fully open, pull it to remove.





#### Attaching

- Attach three front panel bearings to the axis of the front cover. (Set the hook to face up.)
- Insert the tip of the resin band into the hole of the protrusion inside the right section of the front panel.


### 3. Remove the front cover




① Push the latch at both sides to open the front panel. Pull out the filter and remove 3 screws.



② Lift up the front panel and latch the claws firmly at the lower part of rear of the front panel. Then remove 3 screws.




③ Take off 2 screw caps at the lower part of the horizontal air deflector and remove 2 screws. Then leave the upper louver in open position.




④ Hold both sides of the lower part of front cover and pull down towards an oblique direction.


### 4. Install the front cover



① Set the upper louver in open position.




② Insert the front cover fixing claws (4 places) to the insertion groove of the cabinet and put the upper louver through to the front cover frame.



③ Put the horizontal air deflector to the lower part of front cover frame and insert to the cabinet. After fixed the front cover, fix back all the screws in order.


## 5. INDICATING P.W.B.

- (1) Remove the front panel and the front cover.
- (2) Remove the three fixing screws of the suction frame.
- (3) Remove the one fixing screw of the indicating P.W.B. case.
- (4) Slide the indicating P.W.B. case to the right while removing it from the suction frame.




## 6. ELECTRICAL PARTS CASE

- (1) Remove the front panel and the front cover.
- (2) Remove the two fixing screws of the electrical parts case.




## 7. DISCHARGE FRAME

- (1) Remove the front panel and the front cover.
- (2) Remove the two fixing screws of the discharge frame.
- (3) Remove the screw on the rat prevention cover.
- (4) Remove the hook that is the fixation of a lower center part of Discharge frame.
- (5) Lower the rear side of the discharge frame, remove the tab on the interfit section, and then pull out the discharge frame towards you.




## 8. DISCHARGE FRAME AUTO SWEEP MOTOR






## 9. FAN MOTOR AND TANGENTIAL AIR FLOW FAN


- (1) Two screws that are the fixation of evaporator are removed.
- (2) The tab where the left side of evaporator is fixed is removed.
- (3) Evaporator is lifted up and remove.



- (4) Two screws that is the fixation of fan-motor support is removed, and fan motor support is removed.




- (5) The tangential air flow fan and fan motor are fixed with screw.  
Please loosen screw when you remove.




**OUTDOOR UNIT** MODEL RAC-25FXB, RAC-35FXB

**1. Electrical parts**


- (1) Remove the upper cover fixing screws and lift the cover to remove it.
- (2) Remove the service valve cover.
- (3) Remove the terminal plate cover.
- (4) Remove the right side cover.




- (5) Remove the electrical box fixing screws and GND wire fixing screw.



- (6) Remove P lock which binds lead wires.
- (7) Set the electrical box upside down.




- (8) Remove P.W.B. fixing screws (2 locations) and radiation fin fixing screws (5 locations), and remove the P.W.B. from the support.




**OUTDOOR UNIT** MODEL RAC-50FXB

**1. Electrical parts**

- (1) Remove the service value cover lock screws and lower the cover to remove it.
- (2) Remove the top cover lock screw and raise the cover to remove it.



- (3) Remove the front cover lock screw.
- (4) Lower the right side of the front cover and pull it forward. Then, remove the cover from the hook.
- (5) Pull the right side of the front cover a little and pull up the left side to remove it from the hook.



- (6) Remove each connector and earth cable from the lead wire. Then, remove the electrical box.

# DESCRIPTION OF MAIN CIRCUIT OPERATION

MODEL RAF-25/35/50RXB

## 1. Control power circuit




Fig. 1-1

- An AC power supply from outdoor unit passes through the 3.15 A fuse, varistor (VA001), and noise filter circuit and rectified and smoothed by DB1 and C003 to become a DC current 325 V. It is then supplied to indoor fan motor drive circuit, and switching power circuit.
- The switching power circuit, as controlled by IC001, drives the primary winding of the transformer (T001) to produce a specified voltage at the output winding. [The output terminal (pin ①) of IC001 has a switching voltage. But it changes in voltage peak and oscillation period depending on the power load. usually, the oscillation frequency when the air condition operation is about 67 kHz. In the standby state, the oscillation frequency is lowered to a level as low as 20 kHz or so to reduce the standby power.]
- The outputs of the output windings of the transformer is rectified and smoothed to become DC voltages at primary 18.5 V, 12 V, and 8.5 V respectively. The primary 18.5 V is supplied to the drive circuit of the indoor fan motor, the 12 V is supplied to each vane motor and to the drive circuits of the cleaning unit driving motor and other equipment, and the 8.5 V is adjusted to a stable 5 V by the 3-terminal regulator IC (IC101, IC103) and supplied to the microcomputer peripheral circuit.

### Check

If a failure in a part or circuit has produced an abnormal current in the power supply, the 3.15 A fuse will melt down to prevent further damage. If the 3.15 A fuse melts down, check the indoor fan motor, switching electrical circuit, and other components and replace any defective part.

### Check

If an abnormally high voltage is applied to the power supply, the 3.15 A fuse and varistor (VA001) will prevent further damage. If a high voltage results in the 3.15 A fuse melted down, the varistor (VA001) should have deteriorated and destroyed. Therefore replace it at the same time.

### Caution

The primary circuit of the transformer (T001) has a voltage to ground. Guard against electric shocks.

## 2. Reset Circuit




Fig.2-1

### Timing chart




Fig.2-2

- Reset circuit is to initialize the indoor unit microcomputer when switching ON the power or after recovering from power failure.
- Microcomputer operates when ⑪ pin of the indoor unit microcomputer (reset input) is "Lo" for resetting and "Hi" for heating.
- Waveform of each part when switching ON the power and when shutting down is shown in the Fig. 2-2.
- After switching ON the power, ① pin of IC501 supply voltage and ⑪ pin of microcomputer becomes Hi when DC5V line rises and reaches approximately 4.4V or higher. Then, resetting will be cancelled and microcomputer starts operating.
- After shutting down the power, ① pin of IC501 supply voltage and ⑪ pin of microcomputer becomes Lo when DC5V line falls and reaches approximately 4.2V or lower. Then, the microcomputer will be in reset condition.

### 3. Drive circuit of the indoor fan motor





Fig. 3-1

< The circuit check (For test) >

Name	Test point	Test voltage
Motor drive power	CN2 ① pin- ④ pin	About 325V
Motor control power	CN2 ⑤ pin- ④ pin	About 15V
Motor speed signal	CN2 ⑥ pin- ④ pin	About 2-6V
Motor rotation speed debug	CN2 ⑦ pin- ④ pin	About 7.5V

< Pin 6 - Pin 4 voltage one example >



- \* The voltage above is all motor operation vol. when you start the test, take care of your connector, do not touch the different pin together.
- \* The voltage of pin ⑥ - pin ④ , pin ⑦ - ④ maybe different from above.

\* The different mode maybe have different FAN rotation speed.

< Typical circuit waveform >




Fig. 3-2

- The indoor fan motor receives VDC (motor drive power supply), VCC (power supply for the control circuit inside the motor), and VS (speed command voltage) from CN2. The indoor fan motor returns an FG signal of a frequency that matches the rotation speed.
- VCC stabilizes the primary 18.5 V power supply into 15 V by using Q201 and supplies it.
- While on standby for a remote control signal, the Q201 shuts down the VCC and reduces the standby power.
- The VS receives a command voltage from the microcomputer (IC601). The VS terminal undergoes an analog voltage that matches the Lo level time ratio of the pulse signal from pin ④5 of the microcomputer. (See Fig. 3-2.)
- The FG terminal undergoes a signal of 12 pulses per revolution of the motor shaft. By counting the pulse rate, the microcomputer (IC601) recognizes the motor speed, thereby performing feedback control.

**Caution**

The indoor fan motor and drive circuit are connected to the primary power supply. They therefore have voltage to ground. Guard against electric shocks.

**Caution**

While the product is energized, do not under any circumstances detach or reattach a connector. Any such practice would cause a high voltage to run, resulting in the indoor fan motor and board circuit being destroyed. (Check the discharge of the C003 before detaching or reattaching the connectors.)

### 4. Buzzer Circuit




Fig.4-1 Buzzer Circuit

- When the buzzer sounds, an approx. 3.9kHz square signal is output from buzzer output pin (83) of the micro computer. After the amplitude of this signal has been set to 12Vp-p by a transistor, it is applied to the buzzer. The piezoelectric element in the buzzer oscillates to generate the buzzer's sound.




Fig.4-2 Buzzer Operation

### 5. Remote control reception circuit




Fig.5-1

[Typical communication waveform]





Fig. 5-2


- An infrared signal from the remote control unit is converted to an electrical signal by the remote control light-receiving unit (IRR) and is received by the microcomputer. Data is transmitted as digital data 0 and 1 by changing the interval of the basic pulses at about 420μs.

## 6. Initial Setting Circuit (IC531)

- When power is supplied, the microcomputer reads the data in IC531 (E<sup>2</sup>PROM) and sets the preheating activation value and the rating and maximum speed of the compressor, etc. to their initial values.
- Data of self-diagnosis mode is stored in IC531; data will not be erased even when power is turned off.



## 7. Temporary Switch Circuit





- The temporary switch is used to operate the air conditioner temporarily when the wireless remote control is lost or faulty.
- The air conditioner operates in the previous mode at the previously set temperature. However, when the power switch is set to OFF, it starts automatic operation.

## 8. Room Temperature Thermistor Circuit

A room temperature thermistor circuit is shown in Fig. 8-1.

According to room temperature, the voltage of point (A) becomes as it is shown in Fig.8-2.





## 9. Heat Exchanger Thermistor Circuit

Heat exchanger temperature is noticed inside the room

- (1) Preheating
- (2) Low-temperature defrosts at cooling and dehumidification operation time.
- (3) Not working of reversing valve or detection of opening of heat exchange thermistor is controlled.

According to heat exchange temperature, the voltage of point (A) becomes as it is shown in Fig. 9-2.





## 10. Dip-switch




Fig.10-1 Dip switch Circuit

- Fig.10-1 shows the dip switch circuit; the table shown in Fig.10-2 are function and setting position from ①–⑥ of the switch no.

SW No.	ITEM	FUNCTION							
1	AUTO RESTART	OFF*	ENABLE	ON	DISABLE				
2	CARD KEY MODE	OFF*	DISABLE	ON	ENABLE				
3	CARD KEY LOGIC SELECT	OFF*	INPUT HIGH ACTIVE	ON	INPUT LOW ACTIVE				
4	HEATING/COOLING ONLY MODE SELECT	OFF*	HEATING & COOLING	OFF	HEATING ONLY	ON	COOLING ONLY	ON	HEATING & COOLING
5	HEATING/COOLING ONLY MODE SELECT	OFF*		ON				OFF	
6	REMOCON ID SELECT	OFF*	SELECT ID : A	ON	SELECT ID : B				

Fig.10-2 Functions of Dip switch

NOTE:

\* Marking is position of shipping [FACTORY default setting]

## 11. Indoor/outdoor communication circuits




Fig. 11-1




Fig. 11-2

- Indoor and outdoor communications are conducted by using lines 2 and 3 of F cable. Line 2 of F cable is shared with a transmission channel that powers the outdoor unit.
- Data communicated between the indoor and outdoor units are outputted from the microcomputer as serial signals and are transmitted as demodulated by a 30 kHz carrier wave. (Both the indoor and outdoor microcomputers directly output a signal demodulated at 30 kHz.)

### Check

If a cable poorly inserted in the indoor terminal board or some other failure overheats the terminal board and the temperature fuse of the terminal board blows out, the power to the indoor communication circuit will be shut down to stop the communications function. (In that case, the failure will be displayed by the timer lamp blinking 3 times.)

### Check

If communication fails between the indoor and outdoor units for some reason, the product will give a self-diagnosis display either by "the timer lamp blinking 3 times" or "the timer lamp blinking 12 times" depending on the cause.

## 12. Stepping motor drive circuit




Fig. 12-1

[Connector circuit waveform while the motor runs]

Voltage waveforms of different phases as viewed from the OV line while the motor rotor is turning counterclockwise as viewed from the shaft side




Fig. 12-2

- Each stepping motor runs as excited in 1 or 2 phases at 100 PPS or 200 PPS.
- The excitation pattern passes the microcomputer (IC601) and then the driver IC and excites the coil of each stepping motor.
- Some models not need to install the horizontal sweep motor.

1. Power Circuit




Fig 1-1

※ This circuit full-wave rectifies 230VAC applied between terminals L and N and boosts it to a required voltage with the IPM to create a DC voltage.

The voltage become 300-330V when the compressor is operated.

※ Main parts

- (1) Intelligence Power Module (IPM)  
A module that constitute by an inverter part.
- (2) Diode Stack (DB601)  
These rectify the 230VAC from terminal A and B to a DC power supply.
- (3) Smoothing capacitors (C021-C023, 500 $\mu$ F, 450V)
- (4) IGBT to improve efficiency (Q601, Q602)

<Reference>

※ In case of Intelligence Power Module malfunction or connection failure immediately after compressor starts, its may stop due to error of [abnormal low speed], [switching failure],[Ip stop] and others.

<Reference>

※ If diode stack (DB601) are faulty, DC voltage may not be generated and the compressor may not operate at all. Also be aware that the 25A fuse might have blown.

※ This smoothes (averages) the voltage rectified by the diode stack.

※ It will improve the efficiency during compressor load become heavy when current flow thru the chopper period of Q601, Q602.

## 2. Power circuit (Low voltage)




Fig. 2-1

- The 230V AC voltage is rectified to DC voltage (B-12V,16V,12V,5V) pass through switching control IC (IC1), switching transformer.
  - (1) B-12V Power supply for electrical expansion valve.
  - (2) 16V Power supply for IPM driver circuit of compressor and fan motor, IGBT action.
  - (3) 12V Power supply for 4 way valve relay, power relay, inrush current relay, motor current amplification,
  - (4) 5V Power supply for microcomputer, peripheral circuits.

## Main parts

(1) C001,C002,C003,C004,C005,C011,C013,C014, NF1

These absorb electrical noise generated during operation of compressor and also absorb external noise entering from power line to protect electronic parts.

(2) Surge Absorber, Varistor1,2,5,8.

These absorbs external power surge.

(2) IC4

DC/DC convertor IC (DC12V → DC5V).

### 3. P.W.B. for power circuit

Voltage specification of power circuit as shown in below table.

〈Checking point〉

Output	Spec	Main load	Measuring point	Example of possible failure mode.
5V O/P	$5 \pm 0.4V$	Micon, Thermistor	Tester⊕ : L105 (JUMPER) Tester⊖ : D110 (EARTH)	Outdoor not operate, no blinking indication
12V O/P	$12 \pm 0.5V$	Micon, IC2, 3, 4 Relay circuit	Tester⊕ : L104 (JUMPER) Tester⊖ : D110 (EARTH)	Outdoor not operate, no blinking indication
16V O/P	$15.5^{+1.5V}_{-1.0V}$	IPM for Comp IPM for DC fan	Tester⊕ : L103 (JUMPER) Tester⊖ : D110 (EARTH)	Stop : LD301 3, 4 or 12 times blinking
B-12V O/P	$13^{+2.5V}_{-1.0V}$	Expansion valve	Tester⊕ : R120 (B-12V) Tester⊖ : R120 (B-0V)	Stop : LD301 5 times blinking

※ Power circuit for pwb can consider normal if the result is satisfied with above specification.

4.Reversing valve control circuit

This model reversing valve control used to control the reley ON/OFF of the revesing valve, and also control the coil of the reversing valve ON/OFF.

The realy ON/OFF has different type when in the different operation mode.

You can see each operation mode as follows. If the reaversing valve not connected or all the condition not the same as follow, it may be something wrong with the reversing valve circuit.

Point operation mode		micon ②8pin - 0V	HIC ③4 pin - 0V	CN2①- CN2④
		Cooling	Usual cooling	Hi
Heating	Usual heating	Lo	12V	0V
	Defrost	Hi	0V	AC230V




Fig.4-1

## 5. Temperature Detection Circuit




Fig. 5-1

- OH thermistor circuit detect the temperature at the surface of compressor head, DEF thermistor circuit detect the defrosting operation temperature.
  - A thermistor is a negative resistor element which has characteristics that the higher(lower) the temperature, the lower(higher) the resistance.
  - When the compressor is heated, the resistance of the OH thermistor becomes low and  $\oplus 5V$  is divided by OH thermistor and R301 and the voltage at pin ⑦④ of microcomputer.
  - Compare the voltage at microcomputer pin ⑦④ and setting value stored inside. If the value exceed the set value, microcomputer will judge that the compressor is overheated and stop the operation.
  - When frost is formed on the outdoor heat exchanger, the temperature at the exchanger drops abruptly. Therefore the resistance of the DEF thermistor becomes high and the voltage at pin ⑦① of micro computer drops. If this voltage becomes lower than the set value stored inside, microcomputer will enter the defrost control.
  - During defrost operation, the microcomputer will transfer the defrosting condition command to indoor unit via SDO pin of interface of IF transmission output.
  - The microcomputer read the outdoor temperature by Outside Air thermistor and transfer it to the indoor unit, thus controlling the compressor rotation speed according to the set value in the EEPROM of indoor unit and switching the operation mode (outdoor fan on/off etc.) to DRY mode.
- Below table show the typical values of outdoor temperature in relation to the voltage.

Table 5-1

Outside Air Temperature (°C)	-10	0	10	20	30	40
Voltage at both side of R303 (V)	1.19	1.69	2.23	2.75	3.22	3.62

<Reference>

When the thermistor is open, open condition or disconnect, microcomputer pin ⑦①⑦④⑦⑤ are approx. 0V;

When thermistor is shorted, they are approx. 5V and LD301 will blink 7 times.

However, an error is detected when only the OH thermistor is shorted and will enter blinking mode after 12 minutes start the compressor operation.




## 2.Failure phenomenon: The product will not receive a remote control signal.

- [Situation ] The product does not receive a remote control signal. It is not very responsive.  
(The product does run normally in response to the emergency operation switch.)
- [Estimated failure locations ]
- Remote control failure, remote control low battery level, remote control poorly set
  - Remote control light-receiving unit
  - Connector loose, wire break
  - Normal product (external factors: the remote control units for lighting equipment and other equipment, electrical noise, etc.)
- [Cautions ]
- Even if the product is trouble-free, a factor coming from outside the product may hamper the reception of signals from the remote control unit.
  - Batteries may decline in capacity at low temperatures. Old batteries decline particularly much in voltage in the morning and evening of winter, resulting in the poor arrival of remote control signals. Instruct your users to use new alkaline batteries.

### [Diagnosis flow ]

#### Initiating troubleshooting



[Cautions in replacing the indicating P.W.B] Be sure to replace the indicating P.W.B. components.

## 7. Outdoor DC fan motor control circuit

- This model is built with DC fan motor control circuit inside outdoor electrical unit.




Fig 7-1

This DC fan motor is control by outdoor microcomputer that follow the operating instruction received from indoor microcomputer. The DC current that flow from R741 will presume actual operation speed and control the rotation to follow the operating instruction. Based on this DC current it will detect a over current and other fan motor failure.

### (1) Fan motor speed controller during starting

Due to the interference of strong wind etc., operation movement is changed based on fan direction and rotation speed as shown below during starting of operation.

In addition, the fair wind is define as wind that blow to outside direction using Mouth Ring part. At strong and contrary wind ...The rotational speed is not controlled as to protect the equipment and fan will rotate reversely depend on the wind. Automatically start when wind condition become weak.

At contrary wind ...The rotational speed is controlled in fair wind direction after it slowly reduce the speed and finally stop.

At fair wind ...The rotational speed is controlled as it is.

At strong fair wind ...The rotational speed is not controlled as to protect the equipment and fan will rotate reversely depend on the wind. Automatically start when wind condition become weak.

### (2) Fan motor speed controller during unit operating


There is a case where fan rpm is reducing during rotating caused by interference of strong wind. If this condition continue in long period, fan will stop rotating. (LD301 : 11 times blinking)  
The unit will restart according to control as per during start (1).

(3) Method of confirming self diagnosis LD301 lamp : 12 times blinking

If the unit stop and LD301 on the pwb blinking 12 times [fan lock stop is detected], follow below steps to confirm it.

1. Fan lock stop is detected when something has disturb the fan rotation by inserting material into propeller fan or ice has growing inside outdoor unit caused by snow.  
Remove it if found something is bloking the fan.
2. Confirmed that CN24 connector is securely inserted. Fan lock stop is detected also when connector is not properly inserted. Please securely insert if found any disconnection.
3. Fan lock stop also can be detected where strong wind blown surrounding the unit.  
Please confirm after restart the unit. (It may take few minutes to operate the compressor)  
It is not a malfunction of electrical unit or fan motor if the unit run continuesly after restart the unit.
4. Check fan motor condition as below procedure.

[Checking Fan Motor] procedure



5. Reconnect again fan motor connector (CN24).

※Please confirm above checking procedure if found 2A fuse blown.

If fan motor is broken, replace both electrical unit and fan motor.

Caution

※Beware of electric shock due to high voltage when conducting an operation check.

Power supply for DC fan motor and compressor is common (DC300-330V).

MODEL RAC-50FXB

1. Power Circuit




Fig 1-1

※ This circuit full-wave rectifies 230VAC applied between terminals L and N and boosts it to a required voltage with the IPM to create a DC voltage.

The voltage become 300-330V when the compressor is operated.

※ Importance component

- ( 1 ) Intelligence Power Module (IPM)  
A module that constitute by an inverter part.
- ( 2 ) Diode Stack (DB601, DB602)  
These rectify the 230VAC from terminal A and B to a DC power supply.

<Reference>

※ In case of Intelligence Power Module malfunction or connection failure immediately after compressor starts, its may stop due to error of [abnormal low speed],[switching failure],[Ip stop] and others.

<Reference>

※ If diode stack (DB601, DB602) are faulty, DC voltage may not be generated and the compressor may not operate at all. Also be aware that the 25A fuse might have blown.

(3) Smoothing capacitors (C021-C023, 500 $\mu$ F, 450V)

This smoothes (averages) the voltage rectified by the diode stack.




Fig. 1-2




Fig. 1-3

(4) IGBT to improve efficiency (Q601, Q602)

It will improve the efficiency during compressor load become heavy when current flow thru the chopper period of Q601, Q602.

## 2. Power circuit (Low voltage)




Fig. 2-1

- The 230V AC voltage is rectified to DC voltage (B-12V, 16V, 12V, 5V) pass through switching control IC (IC1), switching transformer.
- (1) B-12V Power supply for electrical expansion valve.
- (2) 16V Power supply for IPM driver circuit of compressor and fan motor, IGBT action.
- (3) 12V Power supply for 4 way valve relay, power relay, inrush current relay, motor current amplification,
- (4) 5V Power supply for microcomputer, peripheral circuits.

## Main parts

(1) C001,C002,C003,C004,C005,C011,C013,C014, NF1

These absorb electrical noise generated during operation of compressor and also absorb external noise entering from power line to protect electronic parts.

(2) Surge Absorber, Varistor1,2,5,8.

These absorbs external power surge.

(2) IC4

DC/DC convertor IC (DC12V → DC5V).

### 3. P.W.B. for power circuit

Voltage specification of power circuit as shown in below table.

<Checking point>

Output	Spec	Main load	Measuring point	Example of possible failure mode.
5V O/P	$5 \pm 0.4V$	Micon, Thermistor	Tester⊕ : L105 (JUMPER) Tester⊖ : D110 (EARTH)	Outdoor not operate, no blinking indication
12V O/P	$12 \pm 0.5V$	Micon, IC2, 3, 4 Relay circuit	Tester⊕ : L104 (JUMPER) Tester⊖ : D110 (EARTH)	Outdoor not operate, no blinking indication
16V O/P	$15.5^{+1.5V}_{-1.0V}$	IPM for Comp IPM for DC fan	Tester⊕ : L103 (JUMPER) Tester⊖ : D110 (EARTH)	Stop : LD301 3,4 or 12 times blinking
B-12V O/P	$13^{+2.5V}_{-1.0V}$	Expansion valve	Tester⊕ : R148 (B-12V) Tester⊖ : C401 (" - ")	Stop : LD301 5 times blinking

※ Power circuit for pwb can consider normal if the result is satisfied with above specification.

#### 4. Reversing valve control circuit

This model reversing valve control used to control the revaly ON/OFF of the revesing valve, and also control the coil of the reversing valve ON/OFF.

The realy ON/OFF has different type when in the different operation mode.

You can see each operation mode as follows. If the reaversing valve not connected or all the condition not the same as follow, it may be something wrong with the reversing valve circuit.

Point operation mode		micon (28) pin - 0V	HIC (28) pin - 0V	CN2 (1) - CN2 (4)
		Cooling	Usual cooling	Hi
Heating	Usual heating	Lo	12V	0V
	Defrost	Hi	0V	AC230V




Fig.4-1



## 5. Temperature Detection Circuit




Fig. 5-1

- OH thermistor circuit detect the temperature at the surface of compressor head, DEF thermistor circuit detect the defrosting operation temperature.
  - A thermistor is a negative resistor element which has characteristics that the higher(lower) the temperature, the lower(higher) the resistance.
  - When the compressor is heated, the resistance of the OH thermistor becomes low and  $\oplus 5V$  is divided by OH thermistor and R301 and the voltage at pin ⑦④ of microcomputer.
  - Compare the voltage at microcomputer pin ⑦④ and setting value stored inside. If the value exceed the set value, microcomputer will judge that the compressor is overheated and stop the operation.
  - When frost is formed on the outdoor heat exchanger, the temperature at the exchanger drops abruptly. Therefore the resistance of the DEF thermistor becomes high and the voltage at pin ⑦① of micro computer drops. If this voltage becomes lower than the set value stored inside, microcomputer will enter the defrost control.
  - During defrost operation, the microcomputer will transfer the defrosting condition command to indoor unit via SDO pin of interface of IF transmission output.
  - The microcomputer read the outdoor temperature by Outside Air thermistor and transfer it to the indoor unit, thus controlling the compressor rotation speed according to the set value in the EEPROM of indoor unit and switching the operation mode (outdoor fan on/off etc.) to DRY mode.
- Below table show the typical values of outdoor temperature in relation to the voltage.

Table 5-1

Outside Air Temperature (°C)	-10	0	10	20	30	40
Voltage at both side of R303 (V)	1.19	1.69	2.23	2.75	3.22	3.62

<Reference>

When the thermistor is open, open condition or disconnect, microcomputer pin ⑦①⑦④⑦⑤ are approx. 0V;

When thermistor is shorted, they are approx. 5V and LD301 will blink 7 times.

However, an error is detected when only the OH thermistor is shorted and will enter blinking mode after 12 minutes start the compressor operation.

## 6. Electric expansion valve circuit




Fig. 6-1

- The electric expansion valve is driven by DC12V. Power is supplied to 1 or 2 phases of 4-phase winding to switch magnetic pole of winding in order to control the opening degree.
- Relationship between power switching direction of phase and open/close direction is shown below. When power is supplied, voltages at pins ④ to ① of CN15 are about 0.9V and 12V when no power is supplied. When power is reset, initial operation is performed for 10 or 20 seconds. During initial operation, measure all voltages at pin ④ to ① of CN15 by using a multimeter. If there is any pin with voltage that has not changed from 0.9V or 12V, expansion valve or microcomputer is broken.
- Fig. 5-2 shows logic waveform when expansion valve is operating.

Table 6-1

CN15 pin no.	Wire	Drive status							
		1	2	3	4	5	6	7	8
①	WHT	ON	ON	OFF	OFF	OFF	OFF	OFF	ON
②	YEL	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
③	ORG	OFF	OFF	OFF	ON	ON	ON	OFF	OFF
④	BLU	OFF	OFF	OFF	OFF	OFF	ON	ON	ON

Operation mode  
 1→2→3→4→5→6→7→8 VALVE CLOSE  
 8→7→6→5→4→3→2→1 VALVE OPEN




Fig. 6-2

With expansion valve control, opening degree is adjusted to stabilize target temperature by detecting compressor head temperature. The period of control is about once per 20 seconds and output a few pulse.

## 7. Outdoor DC fan motor control circuit

- This model is built with DC fan motor control circuit inside outdoor electrical unit.




Fig 7-1

This DC fan motor is control by outdoor microcomputer that follow the operating instruction received from indoor microcomputer. The DC current that flow from R741 will presume actual operation speed and control the rotation to follow the operating instruction. Based on this DC current it will detect a over current and other fan motor failure.

### (1) Fan motor speed controller during starting

Due to the interference of strong wind etc., operation movement is changed based on fan direction and rotation speed as shown below during starting of operation.

In addition, the fair wind is define as wind that blow to outside direction using Mouth Ring part. At strong and contrary wind ... The rotational speed is not controlled as to protect the equipment and fan will rotate reversely depend on the wind. Automatically start when wind condition become weak.

At contrary wind ... The rotational speed is controlled in fair wind direction after it slowly reduce the speed and finally stop.

At fair wind ... The rotational speed is controlled as it is.

At strong fair wind ... The rotational speed is not controlled as to protect the equipment and fan will rotate reversely depend on the wind. Automatically start when wind condition become weak.

### (2) Fan motor speed controller during unit operating


There is a case where fan rpm is reducing during rotating caused by interference of strong wind. If this condition continue in long period, fan will stop rotating. (LD301 : 11 times blinking)  
The unit will restart according to control as per during start (1).

(3) Method of confirming self diagnosis LD301 lamp : 12 times blinking

If the unit stop and LD301 on the pwb blinking 12 times [fan lock stop is detected], follow below steps to confirm it.

1. Fan lock stop is detected when something has disturb the fan rotation by inserting material into propeller fan or ice has growing inside outdoor unit caused by snow.  
Remove it if found something is bloking the fan.
2. Confirmed that CN24 connector is securely inserted. Fan lock stop is detected also when connector is not properly inserted. Please securely insert if found any disconnection.
3. Fan lock stop also can be detected where strong wind blown surrounding the unit.  
Please confirm after restart the unit. (It may take few minutes to operate the compressor)  
It is not a malfunction of electrical unit or fan motor if the unit run continuesly after restart the unit.
4. Check fan motor condition as below procedure.

[Checking Fan Motor] procedure



5. Reconnect again fan motor connector (CN24).

※Please confirm above checking procedure if found 2A fuse blown.

If fan motor is broken, replace both electrical unit and fan motor.

Caution

※Beware of electric shock due to high voltage when conducting an operation check.

Power supply for DC fan motor and compressor is common (DC300-330V).

## SERVICE CALL Q&A

MODEL RAF-25/35/50RXB

### Cooling operation

**Q1** The compressor sometimes stops during cooling.



**A1** Check if the heat exchanger of the indoor unit is covered with frost. Wait for 3 to 4 minutes until the frost disappears.

Cooling when the room temperature is low may cause the heat exchanger of the indoor unit to gather frost.

### Dehumidification

**Q1** The indoor unit produces a noise that goes "shaaahhh" during dehumidification.



**A1** That is a noise produced by refrigerant flowing through the pipe.

**Q2** Cold air comes out during a dehumidifying operation.



**A2** To improve the dehumidification efficiency performs quiet fan operation. Therefore the air is cold and it is not a malfunction.

**Q3** The operation does not stop even by setting the temperature higher than room temperature on the remote controller.



**A3** It sets to perform dehumidifying operation by setting the temperature slightly lower than remote controller setting.

### Heating operation

**Q1** The product sometimes fails to produce a wind during heating.



**A1** Defrosting is in progress. Wait 5 to 10 minutes until the dew on the outdoor unit disappears.

**Q2** The product begins with a "Low" during heating even though set to "Hi" or "Med".



**A2** At the first of the heating, the product will run for 30 seconds with a "Low". When set to "Hi", the product will begin with a "Low" operation, producing a "Med" for 30 seconds, and then switch to "Hi".

**Q3** The product stops during heating even though it is set to "30°C".



**A3** When heating is conducted despite the high outdoor temperature, the product may stop to protect its equipment.

### Auto-fresh defrost

**Q1** During heating, I turned off the product by using the START/STOP button. But the "operation lamp" is blinking and the outdoor unit is running.



**A1** The "auto-fresh defrost" should be working. When stopped, the product will check its outdoor unit for frost and, if there is any frost, conduct defrosting and then stop operating.

### Automatic operation

**Q1** How is the automatic operation mode determined?



**A1** According to the room temperature, heating or cooling operation is automatically selected. Refer to the basic operation section.

Common, etc.

**Q1** In "automatic fan speed" mode, the indoor fan changes from "Hi" to "Med" to "Low".



**A1** This does not abnormal. It is because the cold wind prevention is working.

In fan speed "automatic" mode, the product will sense the heat exchange temperature and, when the temperature goes down, the product will automatically switch to "Hi" to "Med" to "Low".

**Q2** At operation startup, the outdoor unit becomes noisy.



**A2** At operation startup, the product will set the rotation speed of the compressor to full power and increase its heating and cooling capacity, resulting in a slightly higher noise level. This is not a sign of a breakdown.

**Q3** The outdoor unit sometimes changes in its noise.



**A3** The difference between the thermometer temperature setting and room temperature will change the rotation speed of the compressor. This is not a sign of a breakdown.

**Q4** There is a difference between the temperature setting and room temperature in room temperature control.



**A4** The room structure, air stream, or other factor may cause a gap between the room temperature setting and actual room temperature. If there is any difference between the setting and the room temperature, adjust the temperature setting to match the living space to a comfortable temperature.

**Q5** The product will not produce wind right after startup.



**A5** After turning ON the power switch or breaker, setting the product to heating or dehumidification will activate a preliminary operation for 1 minute. At that time, heating will cause the operation lamp to blink. This is not a sign of a breakdown.

**Q6** I performed internal cleaning, but didn't succeed in controlling the mold in the room.



**A6** Internal cleaning will clean the inside of the indoor unit of the air-conditioner, thereby controlling mold generation. This will not control the mold in the room.

## Wireless remote control

**Q1** The timer will not become set.



**A1** Have you set the product to the current time? The timer cannot be set unless it is set to the current time.

**Q2** The current time display will disappear at once.



**A2** The current time disappears 10 seconds later. The timer set display is given priority.

When set to the current time setting, the reading blinks for about 3 minutes.

**Q3** I made a timer "reservation". But the time setting has disappeared.



**A3** Is the time not past the reserved time? The set time disappears when the current time reaches the reserved time.

**Q4** I tried to set the "sleep" timer while the ON timer is reserved. But it will not set itself to a desired time.



**A4** The time set in the "sleep" timer can be set with a time up to the time set with the ON timer. If the end time of the "sleep" timer is past the time set with the ON timer, you cannot make that setting.

**Q5** I set the "sleep" timer during operation. But  
① the indoor fan will not run (it will not produce wind)  
② wind intensity will not change.



**A5** ① This occurs when the room temperature and humidity have reached their settings during dehumidification and the air-conditioner is in a pause. The product will begin again to run within about 3 minutes.  
② The product will run with the wind speed set to a "quiet" state.

**Q6** I tried to change the setting with the "room temperature" button of the remote control unit in vain.



**A6** You cannot make this setting when the product is in "air purification" mode. Moreover, you cannot set the product to a desired setting when quick laundry or dew control is being performed with the "auto" or "quick dehumidification" button.

# TROUBLE SHOOTING



MODEL RAC-25/35/50FXB

## Inspection instructions




### Warning

Note that the 0 V line of the outdoor electrical parts and the primary power circuit of the indoor electrical parts have voltages to ground as illustrated in the right-hand figure.



### Warning

When conducting a check with an oscilloscope or something similar, do not ground the oscilloscope. Note that the oscilloscope will be subjected to voltages as illustrated in the figure above.





# DISCHARGE, PROCEDURE AND POWER SHUT OFF METHOD FOR POWER CIRCUIT



## Caution


- Voltage of about 350 V is charged between the terminal of smoothing capacitors (375 $\mu$ F x 2).
- During continuity check for each circuit part of the outdoor unit, be sure to discharge the smoothing capacitors.

## Discharge Procedure


1. Turn off the power.
2. After power is turned off, wait for 10 minutes or more. Then, remove electrical parts cover and apply soldering iron of 30 to 75 W for 15 seconds or more to IPM(25) and IPM(33) terminals on the main P.W.B. as shown in the figure below, in order to discharge voltage in smoothing capacitor.

Do not use a soldering iron with transformer: Otherwise, thermal fuse inside transformer will be blown.

RAC-25FXB, RAC-35FXB




RAC-50FXB




# STRUCTURE OF AN INDOOR UNIT ELECTRIC PARTS

RAF-25/35/50RXB



## Removing electrical parts

1. Remove the electrical parts cover.
2. Remove the connectors from the CN4 (heat exchange thermistor), CN15 (stepping motor), CN19 (stepping motor), CN2 (fan motor), and CN17 (humidity thermistor).
3. Remove two lock screws.



## Removing receiver

1. Remove the connectors from the CN13.

## Removing the indicating P.W.B.

1. Remove the connector from the CN11 on the control P.W.B.


## Other instructions

### (1) Detaching and reattaching the receptacles for tab terminal

All the receptacles for connecting tab terminals are with a locking mechanism. Forcibly pulling any such receptacle without unlocking it will destroy it. Be on guard.


When reconnecting it, insert it securely all the way home.

- Receptacle types and how to unlock them



Vertical (with a resin case)

Hold the resin case and pull it out.




Horizontal (with a mild resin cover)

Hold the cancel button down on the mild resin cover while pulling it out.

### (2) Detaching and reattaching the board connector

The product comes equipped with many board connectors provided with lock mechanism. Forcibly pulling any such part without unlocking it will destroy it. Be on guard. When reconnecting it, insert it securely all the way home.

Pinch the locking mechanism with your fingers and pull it out unlocked.



### (3) Do not detach or reattach the connectors while energized

Do not under any circumstances detach or reattach the connectors while energized. That would destroy the board components and fan motor. For both the indoor and outdoor boards, ensure that the smoothing capacitor has discharged its electricity fully before you do your work.


No	Function	Description
1	Self-diagnosis display [Display on the indoor unit side]	<ul style="list-style-type: none"> <li>· The failure mode detected on the indoor unit side is displayed by blinking the "timer lamp". And a failure detected on the outdoor unit side will be indicated by the "time lamp" blinking 4 times.</li> <li>· If the outdoor unit side detects a failure, the product will first conduct several operation retrials. There are some failure modes with no lamp display while retrials are continued. [Failure mode where retrials are continued and the indoor unit lamp does not end up giving a display] OH thermistor heat-up Overload lower limit cut Low-frequency things</li> </ul>
	[Display on the outdoor unit side]	<ul style="list-style-type: none"> <li>· The failure mode detected on the outdoor unit side is displayed by blinking the "LD301". Detecting a failure will stop the outdoor unit and keep blinking the LD301 until it is restarted. (The communication error will persist until the communication is reestablished.)</li> </ul>
2	Self-diagnosis memory	<ul style="list-style-type: none"> <li>· The failure modes detected on the indoor and outdoor unit sides are stored in the nonvolatile memory of the indoor unit and can be read later on. (The memory will remain even after power-off.)</li> <li>· The failure modes detected on the outdoor unit side are written in memory every time any such mode occurs. The failure mode can therefore be detected on the indoor unit side without waiting for the retry frequency to reach the display of the indoor unit lamp. Moreover, the normal self-diagnosis display function which rarely occurs will store and display failure modes that do not end up displaying the indoor unit lamp. (Any such mode may be unable to be stored if indoor or outdoor communications is in a failure.)</li> <li>· The product stores 5 last-stored failure modes.</li> <li>· There is a function for deleting memory. Once you clear the memory and run the product for several days, you can read the failure modes and check them, thereby detecting the less frequent failure phenomena.</li> <li>· Failure modes can be checked by both the blinking of the lamp of the indoor unit and the display of the remote control liquid crystal display.</li> </ul>

※The "self-diagnosis function of the communication circuit" available in our conventional models is now incorporated as part of the normal self-diagnosis function. In the case of a failure in the communication circuit, you do not have to conduct a special operation and the operations can be automatically divided into 3 blinking operations and 12 blinking operations of the timer lamp. However, a strong external noise may have resulted in 12 times of blinking.

## Self-diagnosis display function (indoor side display)

While the "timer lamp" (orange), of the indoor unit is blinking, troubleshoot the product while referring to the table below.

- How to count the lamp blinking frequency
  - The product will repeat blinking with 2-second intermissions.
  - The blinking speed is as follows: on for 0.35 seconds and off for 0.35 seconds.



- If you wish to try another operation while the lamp is blinking, operate the START/STOP button on the remote control unit twice. The first push will reset the indoor microcomputer, while the second will activate the product

## DESCRIPTION OF THE SELF-DIAGNOSIS INDICATION

REFER TO THE TABLE BELOW IF THE TIMER INDICATOR (ORANGE) IS BLINKING.

LAMP BLINKING MODE	MAIN DEFECTIVE
2 sec ..... ONCE	REFRIGERANT CYCLE DEFECTIVE
2 sec ..... 2 TIMES	FORCED COOLING OPERATION
2 sec ..... 3 TIMES	INTERFACE DEFECTIVE(INDOOR)
2 sec ..... 4 TIMES	OUTDOOR UNIT DEFECTIVE
2 sec ..... 9 TIMES	INDOOR THERMISTOR DEFECTIVE
2 sec ..... 10 TIMES	ABNORMAL ROTATING NUMBERS OF DC FAN MOTOR
2 sec ..... 12 TIMES	INTERFACE DEFECTIVE(OUTDOOR)
2 sec ..... 13 TIMES	IC531 DEFECTIVE

( ..... LIGHTS FOR 0.35 SEC AT INTERVAL OF 0.35 SEC. )

\*IF THE INTERFACE CIRCUIT IS DEFECTIVE WHEN THE POWER IS TURNED ON, THE SELF-DIAGNOSIS INDICATION WILL NOT WORK.

\*IF THE INDOOR UNIT CAN NOT BE OPERATED AT ALL, REFER TO THE TABLE BELOW.




CHECK POINT	ACTION/REPLACEMENT PARTS,etc
FU1(3.15A)FUSE BLOWN	REPLACE THE PART WHICH CAUSED BLOWING /DISCONNECTION OF FU1(3.15A)FUSE
COME OFF OR DISCONNECTION OF THE CONNECTOR FOR LIGHT RECEIVING UNIT AND SWITCH P.W.B	FIX CN13 AND CN17 CONNECTOR
FAILURE OF CONTROL P.W.B	REFER TO THE SERVICE GUIDE FOR HOW TO DETERMINE THE FAILED PART






## SELF-DIAGNOSIS MEMORY FUNCTION



Failure modes are stored in the nonvolatile memory of indoor unit and shall be redisplayed by remote controller.

This function is useful in checking the failure modes either during switching OFF the power or restarting the device without checking the number of indication lamp blinking. Remote controller can redisplay up to last 5 failure modes from the memory. However, failure modes which are rarely to occur are also stored in the memory which caused the numbers of failure more than 5. Thus, for some failure modes which are unable to retrieve because of remote controller limit to redisplay only 5 failure modes, it can be found by clearing up the memory first then recheck the memory content again during the visit at the customer place.




### < How to redisplay failure diagnosis >

1. Turn the circuit breaker OFF.
2. Set the remote controller to OFF condition, indicated by **OFF** on the display.
3. By pressing  (MODE) button on the remote controller, set to Cooling operation indicated by  (COOL).
4. Turn the circuit breaker ON.
5. Set the room temperature setting on the remote controller to 32°C by pressing the (TEMP  $\downarrow$  or  $\uparrow$ ) button.
6. Set the fan speed with the  (FAN SPEED) button according to the desired failure information. (Refer to the corresponding table below)


Fan Speed	Data
AUTO 	Newest
HI 	Second newest
MED 	Third newest
LOW 	Fourth newest
SILENT 	Oldest


7. While directing the remote controller towards the receiver of the indoor unit, press (TEMP  $\uparrow$ ) button and  (START/STOP) button simultaneously. (The remote controller perform signal transmission with the device.)
8. The device beeps [Pi-] to indicate that it has just received the signal to redisplay the failure mode.
9. Direct the remote controller towards the receiver of indoor unit (within 2 meters in front of indoor unit) and press the  (INFO) button. Wait for 2 seconds for signal transmission. An error code will be displayed on the remote controller display.

### < How to clear the troubleshooting data >


1. Redisplay the troubleshooting status. (See the above procedure.)
2. Turn the circuit breaker OFF.
3. By pressing  (MODE) button on the remote controller, set to Heating operation indicated by  (HEAT).
4. Turn the circuit breaker ON.
5. Set the room temperature setting on the remote controller to 16°C by pressing the (TEMP  $\downarrow$  or  $\uparrow$ ) button.
6. While directing the remote controller towards the receiver of the indoor unit, press (TEMP  $\downarrow$ ) button and  (START/STOP) button simultaneously. (The remote controller perform signal transmission with the device.)
7. The product beeps for a second [Pi-] to indicated that it has just received the signal. The data has now been cleared.

### < How to display error code in case of failure just occurs >

If timer lamp  of the indoor unit blinking and operation stops, please perform below procedures.

1. Direct the remote controller towards the receiver of indoor unit (within 2m in front of the indoor unit) and press  (INFO) button.
2. Wait for 2 seconds for signal transmission.
3. Indication of error code will be shown on the remote controller display for 10 seconds.

For example :



For details information regarding error code, please refer to page 91 .

	TIMER LAMP BLINKING	LD301 BLINKING	CODE	MEANING	DETAILS	MAIN CHECK POINT
INDOOR	-	-	000 00	Normal		
	1 time	-	001 00	Refrigerant cycle fault	When the indoor heat exchanger temperature is too low in the heating mode or it is too high in the cooling mode.	1. Reversing valve defective 2. Heat exchanger thermistor disconnected. (only in heating mode)
	2 times	-	-	Outdoor unit is under forced operation.	It is not failure. Outdoor unit is in forced operation or balancing operation after forced operation.	1. Electrical parts in the outdoor unit.
	3 times	-	003 00	Communication error between indoor and outdoor units.	Interface signal from the outdoor unit is interrupted.	1. Indoor interface circuit 2. Outdoor interface circuit
	9 times	-	009 00	Indoor thermistor	Room thermistor or heat exchanger thermistor is opened circuit or short circuit.	1. Room thermistor 2. Heat exchanger thermistor
	10 times	-	010 00	Abnormal rotating numbers of DC fan motor	Overcurrent is detected at the DC fan motor of the indoor unit.	1. Indoor interface circuit 2. Outdoor interface circuit 3. Indoor control P.W.B
	13 times	-	013 00	IC531 data reading error	When data read from IC401 or IC531 is incorrect.	1. IC531 or IC402 abnormal
OUTDOOR	4 times	2 times	002 01	Peak current cut	Over current is detected.	1. Compressor 2. P.W.B.s
	4 times	3 times	003 01	Compressor abnormal low speed rotation	Position detection signal is not input during operation.	1. P.W.B.s 2. Compressor
	4 times	4 times	004 01	Compressor switching failure	Fail to switch from initial low frequency sync to position detection sync.	1. P.W.B.s 2. Compressor
	4 times	5 times	005 01	Overload lower limit cut	Overload condition still persisting even when rotation speed is below the lower rpm limit.	1. Outdoor unit is exposed to direct sunlight or its air flow blocked. 2. Fan motor 3. Fan motor circuit 4. The voltage is extremely low.
	-	6 times	006 01	OH thermistor temperature rise	OH thermistor is operating.	1. Leak of refrigerant 2. Compressor 3. OH thermistor circuit 4. Fan motor 5. Fan motor circuit
	4 times	7 times	007 01	Abnormal outdoor thermistor	Thermistor is opened or shorted.	1. Thermistor 2. Connection of thermistor is faulty 3. Thermistor circuit
	4 times	8 times	008 01	Acceleration defective		
	-	9 times	009 01	Communication error	When indoor unit is not connected, it blinks similarly, not malfunction.	1. Cable is wrong connected 2. Cable is open 3. Interface circuit between indoor and outdoor unit
	-	10 times	010 01	Abnormal power source	Power supply voltage is incorrect.	1. Power supply voltage 2. Receptacle of wire for P.W.BIPM is not properly inserted
	-	11 times	011 01	Fan stop for strong wind	Fan motor load is too heavy or rotation disturbed by wind blow.	1. Fan motor 2. Outdoor condition (wind)
	4 times	12 times	012 01	Fan motor fault	Outdoor fan rpm is not rotate as intended rpm.	1. Fan motor 2. Fan motor circuit
	4 times	13 times	013 01	EEPROM reading error	Microcomputer cannot read the data in EEPROM.	1. P.W.B main
	4 times	14 times	014 01	Active converter defective	Over voltage is detected, compressor abnormal load.	1. P.W.B.s 2. Compressor
	4 times	15 times	015 01	Abnormal PWB circuit	Active circuit abnormal.	1. P.W.B.s
-	16 times	016 01	Software peak current cut			

< Cautions >

This function is effective only once immediately after the power is turned on. It will not work if you have performed another remote control operation beforehand. Note also that it may not function in response to a procedure other than the above. (If it does not work, turn off the power, turn it back on and repeat the procedure.)

If the memory stores nothing, performing a redisplay operation will not blink the lamp.

For a normal operation, turn off the power and turn it back on. After the above operation, the product will not receive a remote control signal normally.

After clearing the troubleshooting data, turn off the power. (If you do not turn off the power, the product will become unresponsive to remote control signals.)


# SELF-DIAGNOSIS LIGHTING MODE

MODEL RAC-25/35FXB

**⚠ DANGER (DC350V)**

● CUT THE POWER SOURCE AND WAIT MORE THAN 10 MINUTES BEFORE SERVICE WORK.


● CONFIRM THE DC VOLTAGE AT THE MEASURING POINT SHOWN IN BELOW FIGURE MUST BE LESS THAN 10V.



## ※OTHERS CHECK POINTS

1. DIAGNOSIS IS FOR (REVERSING VALVE OPERATION ERROR) ;  
 ⇒CHECK REVERSING VALVE WIRE CONNECTION EITHER WIRE BROKEN OR NOT, IF OK CHECK 3.15A FUSE, IF BROKEN REPLACE FUSE.  
 2. WHEN DISPLAY THE COMMUNICATION ERROR OR THE OUTDOOR DO NOT RUN AT ALL,  
 ⇒PLEASE CHECK THE CONTINUITY OF THE INDOOR ↔ OUTDOOR CONNECTING CORD(F CABLE).

[OUTDOOR FAN MOTOR CHECK]DIAGNOSIS METHOD  
 1. PUT THE POWER OFF.  
 2. REMOVE THE OUTDOOR FAN MOTOR'S CONNECTOR FROM CN24.  
 3. ROTATE THE FAN MOTOR BY HAND AND CHECK WHETHER THE FAN MOTOR IS LOCKED OR NOT.  
 4. MEASURE THE RESISTANCE BETWEEN EACH TERMINAL OF THE FAN MOTOR CONNECTOR. NORMAL RESISTANCE BETWEEN EACH TERMINAL: 20~50Ω  
 ※INSERT THE FAN MOTOR'S CONNECTOR AFTER FINISHING STEPS 1 TO 4.



DURING STOP	
LD301	CONTENTS
LIGHT	NORMAL OPERATION
2 SEC LIGHTING AND 0.3 SEC LIGHTS OFF REPEITION	OVERLOAD OPERATION (NORMAL OPERATION)

IN CASE OF DIFFICULT TO JUDGE THE ABNORMAL WITH ODU CONTROLLER OR THE COMP. BLINKING IN 2, 3, 4 OR 5 TIMES AT SELF-DIAGNOSIS IN THE STOPPING STATUS, PLEASE PERFORM THE MEGA CHECK AND CONFIRM THE INSULATION WITH THE COMPRESSOR AS THERE IS NOT ABNORMAL FOR THE INSULATION WITH COMPRESSOR, PLEASE PERFORM [SELF-CHECK].

## [SELF-CHECK]DIAGNOSIS METHOD

1. PUT THE POWER OFF.
  2. CUTTING (JW001)BY NIPPER OR BEING SHORT CIRCUIT BETWEEN (JW001)AND(JW002) (FASTEN TOGETHER WITH A CLIP ).
  3. PUT THE POWER ON AND OPERATE INDOOR UNIT WITH VENTILATION MODE.
  4. PRESS TEST/SERVICE SWITCH FOR 1 SECOND OR MORE (WITHIN 3 MINUTES).
  5. SELF-CHECK RESULT WILL DISPLAY AT LD301,SEE THE ABOVE TABLE ([SELF-CHECK]DIAGNOSIS RESULT) FOR THE DETAIL.
  6. PUT THE POWER OFF, THEN RELEASE BACK JW001 AND JW002 TO ORIGINAL CONDITION (NO SHORT CIRCUIT CONDITION).
- \*IF FORGET TO RELEASE BACK JW001 AND JW002, THE TIMER LAMP OF THE INDOOR UNIT BLINKS 12 TIMES.

## [SELF-CHECK]DIAGNOSIS RESULT

SELF-DIAGNOSIS BLINKING MODE		HOW TO REPAIR
LD301	SELF-DIAGNOSIS CONTENTS	HOW TO REPAIR
ONCE	NOT CONTROLLER DEFECTIVE	•CHANGE THE COMPRESSOR
2 TIMES	FOUND PEAK CURRENT	•CHANGE ODU CONTROLLER
7 TIMES	COMPRESSOR CURRENT ABNORMAL	•CHECK THE COMPRESSOR CONNECTOR AND CONNECT IT PROPERLY •IF ABOVE ARE OK CHANGE THE ODU CONTROLLER
10 TIMES	ABNORMAL DC VOLTAGE	•REACTOR IS DISCONNECTION, •CHECK THE REACTOR •CHECK THE FAN MOTOR VOLTAGE •LOWER STANDARD VOLTAGE BY INPUT STANDARD AC VOLTAGE •IF AC VOLTAGE INPUT IS NORMAL (WITHIN±10%)→CHANGE P, N, B
13 TIMES	EEPROM ERROR	•CHANGE ODU CONTROLLER

RIGHT SIDE ARROW INDICATE THE POSITION OF TEST SWITCH LEVER ON THE SIDE PANEL (SHOWN IN LEFT FIGURE.)



## DURING STOP

SELF-DIAGNOSIS BLINKING MODE			BLINK	OFF
LD301	DIAGNOSIS (RED) CONTENTS	MAIN CHECK POINT	HOW TO REPAIR	
□	NORMAL STOP (STOPPED BY INDOOR THERMOSTAT OR MAIN OPERATION OFF)	1. NO NEED TO CHECK	1. NOT ANY MALFUNCTION	
○	FAN MODE OPERATION, RESET STOP	1. INDOOR AIR CLEAN OPERATION	1. NOT ANY MALFUNCTION	
○	ONCE PEAK CURRENT CUT	2. OTHER CAUSE	2. CHANGE ODU CONTROLLER	
○	2 TIMES	1. ODU CONTROLLER DEFECTIVE	1. CHANGE ODU CONTROLLER	
○	3 TIMES	2. COMPRESSOR ABNORMAL LOAD	2. CHECK THE COMPRESSOR	
○	4 TIMES	1. COMPRESSOR CONNECTOR OPEN	1. INSERT THE CONNECTOR	
○	5 TIMES	2. COMPRESSOR ABNORMAL LOAD	2. CHECK THE COMPRESSOR	
○	6 TIMES	3. ODU CONTROLLER DEFECTIVE	3. CHANGE ODU CONTROLLER	
○	7 TIMES	1. OBSTACLE SUPROUND THE ODU MAY CAUSE	1. REMOVE THE OBSTRUCTION	
○	8 TIMES	2. OTHER CAUSE	2. CHECK CYCLE PIPE	
○	9 TIMES	1. THERMISTOR TEMPERATURE RISE	1. INSERT THE CONNECTOR	
○	10 TIMES	2. LEAKAGE OF REFRIGERANT	2. CHECK THE CYCLE PIPE AND RECHARGE THE REFRIGERANT	
○	11 TIMES	3. OTHER CAUSE	3. CHANGE ODU CONTROLLER	
○	12 TIMES	1. THERMISTOR ABNORMAL	1. INSERT PROPERLY	
○	13 TIMES	2. OPEN CIRCUIT/SHORT CIRCUIT OF THERMISTOR WIRE	2. CHANGE THE THERMISTOR	
○	14 TIMES	3. ODU CONTROLLER DEFECTIVE	3. CHANGE ODU CONTROLLER	
○	15 TIMES	COMMUNICATIONS ERROR	1. F CABLE MISS CONNECTION	
○	16 TIMES	ABNORMAL POWER SOURCE	2. F CABLE DISCONNECTION	
○	17 TIMES	ODU FAN STOP BY STRONG REVERSE WIND	3. CHANGE ODU CONTROLLER	
○	18 TIMES	OUTDOOR FAN LOCK ERROR	1. REACTOR IS UNCONNECTED	
○	19 TIMES	EEPROM READ ERROR	2. ABNORMAL AC INPUT	
○	20 TIMES	ACTIVE VOLTAGE ABNORMAL	3. AC INPUT IS NORMAL	
○	21 TIMES	HIGH LOAD STOP	1. IT WILL RE-START AFTER STRONG REVERSE WIND	
○	22 TIMES	EEPROM READ ERROR	1. AUTOMATICALLY RE-START AFTER WIND BECOME WEAK	
○	23 TIMES	ACTIVE VOLTAGE ABNORMAL	2. PROPPELLER FAN LOCK	
○	24 TIMES	HIGH LOAD STOP	3. OUTDOOR FAN MOTOR LOCK	
○	25 TIMES	EEPROM READ ERROR	4. OUTDOOR FAN MOTOR OK	
○	26 TIMES	ACTIVE VOLTAGE ABNORMAL	•CHANGE OUTDOOR UNIT CONTROLLER	
○	27 TIMES	HIGH LOAD STOP	1. ABNORMAL OUTDOOR CONTROLLER	
○	28 TIMES	EEPROM READ ERROR	2. ABNORMAL COMPRESSOR LOAD	
○	29 TIMES	ACTIVE VOLTAGE ABNORMAL	1. SERVICE VALVE CLOSE	
○	30 TIMES	HIGH LOAD STOP	2. OBSTACLE SUPROUND THE ODU UNIT MAY CAUSE	
○	31 TIMES	EEPROM READ ERROR	3. CLOGGED FILTER IN INDOOR UNIT CAUSE.	




# SELF-DIAGNOSIS LIGHTING MODE

MODEL RAC-50FXB

**⚠ DANGER (DC350V)**

- CUT THE POWER SOURCE AND WAIT MORE THAN 10 MINUTES BEFORE SERVICE WORK.
- CONFIRM THE DC VOLTAGE AT THE MEASURING POINT SHOWN IN BELOW FIGURE MUST BE LESS THAN 10V.



DURING STOP	
LD301	CONTENTS
LIGHT	NORMAL OPERATION
2 SEC LIGHTING AND 0.3 SEC LIGHTS OUT REPETITION	OVERLOAD OPERATION(NORMAL OPERATION)

DURING STOP			
SELF-DIAGNOSIS BLINKING MODE			☑:BLINK ☐:OFF
LD301 (RED)	SELF DIAGNOSIS CONTENTS	MAIN CHECK POINT	HOW TO REPAIR
☐ OFF	NORMAL STOP (STOPPED BY INDOOR THERMO-STAT OR MAIN OPERATION OFF)	1. NO NEED TO CHECK	1. NOT ANY MALFUNCTION
☑ ONCE	FAN MODE OPERATION, RESET STOP	1. INDOOR AIR CLEAN OPERATION	1. NOT ANY MALFUNCTION
☑ 2 TIMES	PEAK CURRENT CUT	2. OTHER CAUSE 1. ODU CONTROLLER DEFECTIVE 2. COMPRESSOR ABNORMAL LOAD	2. CHANGE ODU CONTROLLER 2. CHECK THE COMPRESSOR
☑ 3 TIMES	ABNORMAL LOW SPEED ROTATION	1. ODU CONTROLLER DEFECTIVE 2. COMPRESSOR ABNORMAL LOAD	1. CHANGE ODU CONTROLLER 2. CHECK THE COMPRESSOR
☑ 4 TIMES	SWITCHING FAILURE	1. COMPRESSOR CONNECTOR OPEN 2. COMPRESSOR ABNORMAL LOAD 3. ODU CONTROLLER DEFECTIVE	1. INSERT THE CONNECTOR 2. CHECK THE COMPRESSOR 3. CHANGE ODU CONTROLLER
☑ 5 TIMES	OVERLOAD LOWER LIMIT CUT	1. OBSTACLE SURROUND THE ODU MAY CAUSE 2. OTHER CAUSE	1. REMOVE THE OBSTRUCTION 2. CHECK CYCLE PIPE
☑ 6 TIMES	OH THERMISTOR TEMPERATURE RISE	1. DUE TO OPEN CONNECTOR 2. LEAKAGE OF REFRIGERANT 3. OTHER CAUSE	1. INSERT THE CONNECTOR 2. CHECK THE CYCLE PIPE AND RECHARGE THE REFRIGERANT 3. CHANGE ODU CONTROLLER
☑ 7 TIMES	THERMISTOR ABNORMAL	1. CONNECTOR INSERT MISS 2. OPEN CIRCUIT/SHORT CIRCUIT OF THERMISTOR WIRE 3. ODU CONTROLLER DEFECTIVE	1. INSERT PROPERLY 2. CHANGE THE THERMISTOR 3. CHANGE ODU CONTROLLER
☑ 9 TIMES	COMMUNICATIONS ERROR	1. F CABLE MISS CONNECTION 2. F CABLE DISCONNECTION 3. ODU CONTROLLER DEFECTIVE	1. F CABLE CONNECT PROPERLY 2. CHANGE THE F CABLE 3. CHANGE ODU CONTROLLER
☑ 10 TIMES	ABNORMAL POWER SOURCE	1. REACTOR IS UNCONNECTED 2. ABNORMAL AC INPUT: OUT OF THE RANGE (230±10%) 3. AC INPUT IS NORMAL	1. CONNECT REACTOR PROPERLY 2. CONNECT TO NORMAL AC POWER SOURCE 3. CHANGE ODU CONTROLLER
☑ 11 TIMES	ODU FAN STOP BY STRONG REVERSE WIND	1. OUTDOOR FAN STOP BY STRONG REVERSE WIND	1. IT WILL RE-START AFTER THE WIND BECOME WEAK
☑ 12 TIMES	OUTDOOR FAN LOCK ERROR	1. OUTDOOR FAN STOP BY STRONG REVERSE WIND 2. PROPELLER FAN LOCK 3. OUTDOOR FAN MOTOR LOCK 4. OUTDOOR FAN MOTOR OK	1. AUTOMATICALLY RE-START AFTER WIND BECOME WEAK 2. REMOVE THE OBSTRUCTION 3. CHANGE THE FAN MOTOR 4. CHANGE ODU CONTROLLER
☑ 13 TIMES	EEPROM READ ERROR	-	-CHANGE OUTDOOR UNIT CONTROLLER
☑ 14 TIMES	ACTIVE VOLTAGE ABNORMAL	1. ABNORMAL OUTDOOR CONTROLLER 2. ABNORMAL COMPRESSOR LOAD	1. CHANGE ODU CONTROLLER 2. CHECK THE COMPRESSOR
☑ 15 TIMES	CIRCUIT ABNORMAL	-	-CHANGE OUTDOOR UNIT CONTROLLER
☑ 16 TIMES	HIGH LORD STOP	1. SERVICE VALVE CLOSE 2. OBSTACLE SURROUND THE ODU UNIT MAY CAUSE 3. CLOGGED FILTER IN INDOOR UNIT CAUSE.	1. CHECK SERVICE VALVE 2. REMOVE THE OBSTRUCTION 3. CHECK FILTER

※EXAMPLE OF BLINKING (5TIMES) ( ■ 0.25 SEC AT INTERVAL OF 0.25 SEC. ) ODU:OUTDOOR UNIT

※OTHERS CHECK POINTS  
1. DIAGNOSIS FOR [REVERSING VALVE OPERATION ERROR] ;  
→CHECK REVERSING VALVE WIRE CONNECTION EITHER WIRE BROKEN OR NOT, IF OK CHECK 3.15A FUSE, IF BROKEN REPLACE FUSE  
2. [WHEN DISPLAY THE COMMUNICATION ERROR OR THE OUTDOOR DO NOT RUN AT ALL].  
→PLEASE CHECK THE CONTINUITY OF THE INDOOR ↔ OUTDOOR CONNECTING CORD(F CABLE).

IN CASE OF DIFFICULT TO JUDGE THE ABNORMAL WITH ODU CONTROLLER OR THE COMP., BLINKING IN 2, 3, 4 OR 5 TIMES AT SELF-DIAGNOSIS IN THE STOPPING STATUS, PLEASE PERFORM THE MEGA CHECK AND CONFIRM THE INSULATION WITH THE COMPRESSOR, AS THERE IS NOT ABNORMAL FOR THE INSULATION WITH COMPRESSOR, PLEASE PERFORM [SELF-CHECK].

**[SELF-CHECK] DIAGNOSIS METHOD**

1. PUT THE POWER OFF.
2. REMOVE THE SELF-CHECK CONNECTOR\*CN27\*.
3. PUT THE POWER ON.
- (LD301:4 SEC LIGHTING AND 2 SEC LIGHTS OUT).
4. PUSH [TEST SWITCH] DURING 1 SEC OR MORE.
5. [SELF-CHECK] DIAGNOSIS RESULT WILL DISPLAY AT LD301. SEE THE BELOW TABLE FOR THE DETAIL.
6. PUT THE POWER OFF AND CONNECT THE SELF-CHECK CONNECTOR\*CN27\*.

※IF FORGET TO CONNECTING THE \*CN27\*, THE TIMER LAMP OF THE INDOOR UNIT BLINKS 12 TIMES.

[SELF-CHECK] DIAGNOSIS RESULT		
SELF-DIAGNOSIS BLINKING MODE ☑:BLINK		
LD301 (RED)	SELF-DIAGNOSIS CONTENTS	HOW TO REPAIR
☑ ONCE	NOT CONTROLLER DEFECTIVE	•CHANGE THE COMPRESSOR
☑ 2 TIMES	FOUND PEAK CURRENT ERROR	•CHANGE ODU CONTROLLER
☑ 7 TIMES	COMPRESSOR CURRENT ABNORMAL	•CHECK THE COMPRESSOR CONNECTOR AND CONNECT IT PROPERLY •IF ABOVE ARE OK CHANGE THE ODU CONTROLLER
☑ 10 TIMES	ABNORMAL DC VOLTAGE	•REACTOR IS DISCONNECTION, →CONNECT IT PROPERLY •IF AC VOLTAGE INPUT ABNORMAL (OVER STANDARD VOLTAGE±10%) →FOLLOW STANDARD AC VOLTAGE INPUT •IF AC VOLTAGE INPUT IS NORMAL (WITHIN±10%)→CHANGE P, W, B
☑ 13 TIMES	EEPROM READING ERROR	•CHANGE ODU CONTROLLER

**SURVICE OPERATION**

PROCEDURE OF COLLECTING REFRIGERANT PUMP DOWN OR INDEPENDENT OPERATION OF OUTDOOR UNIT.

1. CUT OFF THE POWER SOURCE ONCE THEN ON AGAIN.
2. WAIT 1 MINUTE AT LEAST.
3. PRESS THE TEST SWITCH (WHICH IS ON THE P, W, B) MORE THAN 1 SECOND, SERVICE OPERATION WILL BE STARTED. TO STOP THIS OPERATION, PRESS THE TEST SWITCH AGAIN (MORE THAN 1 SECOND).

TO RESUME TO NORMAL OPERATION, CUT THE POWER SOURCE ONCE THEN ON AGAIN. IN ORDER TO PROTECT THE DAMAGE OF COMPRESSOR, DO NOT OPERATE MORE THAN 5 MINUTES WITH SERVICE VALVE CLOSE.


**[OUTDOOR FAN MOTOR CHECK] DIAGNOSIS METHOD**

1. PUT THE POWER OFF.
2. REMOVE THE OUTDOOR FAN MOTOR'S CONNECTOR FROM\*CN24\*.
3. ROTATE THE FAN MOTOR BY HAND AND CHECK WHETHER THE FAN MOTOR IS LOCKED OR NOT.
4. MEASURE THE RESISTANCE BETWEEN EACH TERMINAL OF THE FAN MOTOR CONNECTOR. NORMAL RESISTANCE BETWEEN EACH TERMINAL:20~50Ω

※INSERT THE FAN MOTOR'S CONNECTOR AFTER FINISHING STEPS 1 TO 4.

## Diagnosis and troubleshooting of indoor electric parts, outdoor electric parts and refrigerating cycle

### Initiating troubleshooting



### < Troubleshooting by using the self-diagnosis memory function >

- By using the self-diagnosis memory function, you can check the failure mode (※1) occurring in the outdoor electrical parts on the indoor unit side.

- Steps
1. Clear the troubleshooting data.
  2. Run the product for several minutes under the conditions where the compressor runs.
  3. Redisplay and check the data written in the self-diagnosis memory.

- The self-diagnosis memory function can also be used to catch sporadic failure phenomena.

- Steps
1. Clear the troubleshooting data.
  2. Have the user use the product as usual until a failure phenomenon occurs.  
(The period depends on the incidence of the phenomenon.)
  3. At a later date, redisplay and check the data written in the self-diagnosis memory.


- For the outdoor self-diagnosis display (OH thermistor heat-up, overload lower limit cut) stemming from the freezing cycle or operating condition, the time lag is long from operation startup to the emergence of the phenomenon. Moreover, it is affected by the temperature, sunshine, operating hours, and other factors of the day, so that the phenomenon may not be able to be identified at the time of a repair service visit. In that case too, use the self-diagnosis memory function (※2).
- The outdoor self-diagnosis display "overload lower limit cut" and "OH thermistor heat-up" can be identified only when you are using the self-diagnosis lamp of the outdoor unit and the self-diagnosis memory function of the indoor unit. Note that this will not be automatically displayed on the indoor unit side.

## Checking the indoor unit electrical parts

### Introduction

First check the failure phenomenon and status, and then move on to elaborate diagnosis.

#### Initiating troubleshooting



Turn off the power, wait at least 5 seconds, turn it back on, and observe the way the horizontal vanes move for about 30 seconds.

Check 1: Have the horizontal vanes moved? (Yes/No)



Set the remote control unit to cooling mode, temperature setting 16°C (summer), heating mode, temperature setting 32°C (winter) and operate the product.

Check 2: Has the product received the remote control signal and has the "operation lamp" gone on? (Yes/No)

If you responded "Yes" to Check 2:

Check 3: Is the compressor of the outdoor unit running? (Yes/No)

If you responded "No" to Check 2:

Check 4: Does the "emergency operation switch" work? (Yes/No)

#### Check results and next check items

Check 1	Check 2	Check 3	Check 4	Next check item
No	No	—	No	Go on to "The power will not become turned on".
Yes	No	—	Yes	Go on to "The product will not receive the remote control signal".
Yes	Yes	No	—	Go on to "The compressor will not run".

# 1. Failure phenomenon: The power will not become turned on.

[ Situation ] Neither initialization, remote control, nor any other step works on the vane position at power-on.


[ Estimated failure locations ]	<ul style="list-style-type: none"> <li>· 3.15 A fuse blown out</li> <li>· Control power circuit</li> <li>· Connector loose, wire break</li> </ul>	Estimated cause of fuse blowout · Abnormally high voltage applied to the power supply · Indoor fan motor out of order · Power circuit out of order
---------------------------------	---	--

[ Cautions ]

- Before work, check the power supply voltage. An abnormal voltage may be being supplied in some rare occasions due to a defect in the indoor wiring (a wire break in the neutral wire of the single-phase 3-wire power supply).
- If the 3.15 A fuse has blown out, eliminate the cause of the fuse blowout. Otherwise, there will occur another fuse blowout.
- If the 3.15 A fuse has blown out due to an abnormally high voltage to the power supply, the varistor (VA001) will deteriorate and become destroyed as well.
- On a repair service visit due to the failure phenomenon of "The power will not become turned on", take a "3.15 A fuse" and a "varistor" with you.

## [ Diagnosis flow ]

### Initiating troubleshooting




## 2.Failure phenomenon: The product will not receive a remote control signal.

- [Situation ] The product does not receive a remote control signal. It is not very responsive.  
(The product does run normally in response to the emergency operation switch.)
- [Estimated failure locations ]
- Remote control failure, remote control low battery level, remote control poorly set
  - Remote control light-receiving unit
  - Connector loose, wire break
  - Normal product (external factors: the remote control units for lighting equipment and other equipment, electrical noise, etc.)
- [Cautions ]
- Even if the product is trouble-free, a factor coming from outside the product may hamper the reception of signals from the remote control unit.
  - Batteries may decline in capacity at low temperatures. Old batteries decline particularly much in voltage in the morning and evening of winter, resulting in the poor arrival of remote control signals. Instruct your users to use new alkaline batteries.

### [Diagnosis flow ]

#### Initiating troubleshooting



[Cautions in replacing the indicating P.W.B] Be sure to replace the indicating P.W.B. components.

## How to identify sources of jamming in the reception of remote control signals



[ Situation ] The product may become poorly responsive to remote control signals due to external factors even though the product itself is trouble-free.


[ Estimating sources of jamming ] Identify the installation status of the air-conditioner and the indoor and outdoor environments to identify possible causes of the jamming.

- Indoor lighting equipment (quantity, type, location)
- Remote control units of other electrical products and equipment
- Is the grounding for the air-conditioner shared with other equipment?
- Are the surroundings of the air-conditioner clear of wireless antenna?
- Is the remote control light-receiving unit protected from direct sunlight?

[ Checking and actions ]

<p>Effects of lighting equipment (fluorescent lamps)</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Turn on and off the lighting equipment and check for its effects on the reception of remote control signals.</li> <li>· When cold, the fluorescent lamp tends to emit infrared rays with wavelengths close to those used in remote control.</li> </ul> <p>If you cannot detect the phenomenon about which your user is complaining at the time of your visit, such as "the product sometimes fails to receive remote control signals" and "the product fails to receive remote control signals in the morning alone", then turn off the lighting for about 20-30 minutes and wait for the fluorescent lamps to cool down before conducting another check.</p> <p>There are even cases where the product fails to receive remote control signals for 1 to 2 minutes only after the lighting equipment is turned on.</p> <ul style="list-style-type: none"> <li>· The noise status may vary with the dimming of the lighting equipment. In the case of lighting equipment with a dimmer, therefore, conduct a check with all the light intensities.</li> <li>· If the lighting equipment is the source of the jamming, the remote control light-receiving unit output usually shows a noise waveform as shown in the right-hand figure. In the case of slight jamming, this kind of waveform will not cause practical problems. However, intense degrees of jamming will disable the reception of remote control signals.</li> <li>· When the fluorescent lamp is old and is flickering, it may cause disorders in the reception of remote control signals.</li> </ul> <p><u>Actions proposed</u></p> <ol style="list-style-type: none"> <li>1. Make it hard for light of the lighting equipment to enter the remote control light-receiving unit. <ul style="list-style-type: none"> <li>· Separate the lighting equipment from the indoor unit.</li> <li>· Raise the lighting equipment.</li> <li>· Cover the upper half of the light-receiving panel from its rear side with aluminum tape or black vinyl tape.</li> </ul> <p>( This will also affect the reception of remote control signals. Therefore, set the range to be covered with tape to a range that is problem-free in practice, while checking the reception status. )</p> </li> <li>2. Add an interference filter to the front panel of the remote control light-receiving unit. <ul style="list-style-type: none"> <li>※ Lighting equipment that produces strong jamming exists although rarely. Some problems may therefore be unsolvable by managing the air-conditioner side alone.</li> </ul> </li> </ol>
<p>Effects of the remote control units of other equipment</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· If, on the remote control unit of a TV or audio equipment, its sound volume key or something similar is left pressed, infrared signals become continuously sent, thereby jamming the reception of remote control signals.</li> <li>· Check how the remote control unit and related components are stored, thereby checking if there is any possibility that a button may be inadvertently left pressed on the remote control unit of other equipment.</li> </ul> <p><u>Actions proposed</u></p> <p>If there is any such possibility, give explanations to your users to that effect and instruct them to exercise caution.</p>





<p>Effects of other electrical products</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Check the effects of light and power noises coming from other electrical products.</li> <li>· Turn on and off the electrical products, turn off the power and turn on the power, and check their effects on the reception of remote control signals.</li> <li>· For products whose operating states change, check the effects of each state.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Change the location relationship between the air-conditioner and the target products.</li> <li>· Use a different wall outlet for the target products.</li> </ul>
<p>Sharing a grounding</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Check for effects of electrical noises coming into the air-conditioner through grounding wires.</li> <li>· Check if the grounding works is for the air-conditioner alone or shared with other equipment. If there is any equipment that shares it, turn on and off that equipment and detach and reattach the power plugs and examine their effects on the reception of remote control signals.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Establish an independent grounding for the air-conditioner.</li> </ul>  <p>The diagram shows a cross-section of a house with a gabled roof. An 'Air-conditioner' is mounted on the left wall, and 'Other equipment' is on the right wall. Both are connected to a single horizontal line representing a shared grounding system. This line leads to a vertical line labeled 'Grounding' at the bottom center, which is connected to a ground symbol (three horizontal lines of decreasing width). This illustrates a shared grounding path for both devices.</p>
<p>Effects of radio waves</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Using a wireless transmitter near the air-conditioner may affect the reception of remote control signals.</li> <li>· Have your users try sending signals with a wireless transmitter and examine their effects on the reception of remote control signals.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Add a ferrite core to the power cord and F cable.</li> <li>· Add a ferrite core to the internal wiring of the indoor unit.</li> <li>· Move the wireless antenna.</li> </ul>
<p>Effects of direct sunlight</p>	<p><u>Checking points</u></p> <ul style="list-style-type: none"> <li>· Direct sunlight and other intense light make the remote control light-receiving unit less sensitive.</li> <li>· Check for any time zone where the remote control light-receiving unit of the indoor unit is affected by direct sunlight depending on the location of the sun and mirror reflection.</li> </ul> <p><u>Actions proposed</u></p> <ul style="list-style-type: none"> <li>· Block the sunlight to protect against direct sunlight.</li> </ul>

### 3. Failure phenomenon: The compressor will not run.

[ Situation ] The compressor will not run (the same state as the thermometer turned off), the product receives remote control signals normally. The self-diagnosis lamp (LD301) of the outdoor unit blinks once or becomes turned off.

- [ Estimated failure locations ]
- Room temperature thermistor, heat exchanger thermistor
  - Microcomputer peripheral circuit

[ Diagnosis flow ]  
Initiating troubleshooting





#### 4. Failure phenomenon: The fan motor will not stop.


[Situation ] I have conducted the stop operation on the product by remote control, but the indoor fan motor will not stop.  
(It stopped about 10 minutes later.)

[Estimated failure locations ]

- Indoor fan motor
- Fan motor drive circuit

[Diagnosis flow ]

Initiating troubleshooting



### 5. Timer lamp blinking: blinking once

[Situation] The timer lamp blinks one time and the product will not operate.  
(This is not a sign of a breakdown.)

- [Estimated failure locations]
- Reversing valve defective.
  - The refrigerating cycle block gas leak.

### 6. Timer lamp blinking: blinking twice

[Situation] The product is giving a display to indicate that it is performing forcible cooling.  
(This is not a sign of a breakdown.)

### 7. Timer lamp blinking: blinking three times


[Situation] The timer lamp blinks three times and the product will not operate.

- [Estimated failure locations]
- Meltdown of the terminal board temperature fuse (the terminal board poorly inserted into the F cable)
  - Outdoor communication circuit out of order

- [Cautions]
- If a terminal board is replaced to counter the meltdown of the terminal board temperature fuse, ensure that the F cable to be inserted into the terminal board has the appropriate dimension for peeling the insulation sheathing and that the insertion region is unbent before inserting it into the terminal board securely.

[Diagnosis flow]

Initiating troubleshooting



### 8. Timer lamp blinking: blinking four times

[Situation] The timer lamp blinks four times and the product will not operate.

- [Estimated failure locations]
- Outdoor unit error.
  - Please confirm the times of the LD301 blinking, and then see the outdoor selfcheck lable.

### 9. Timer lamp blinking: blinking 9 times



[Situation] The timer lamp blinks 9 times and the product will not run.

[Estimated failure location] · Loose connector, wire break, or short-circuit in the room temperature thermistor, heat exchanger thermistor.

[Cautions] · Starting the product by remote control will initiate failure detection.  
(Merely turning on the power will not activate the failure detection function.)

#### [Diagnosis flow]

##### Initiating troubleshooting




## 10. Timer lamp blinking: blinking 10 times

[Situation] The timer lamp blinks 10 times and the product will not run.

- [Estimated failure locations]
- Loose connector or wire break in the indoor fan motor
  - Indoor fan motor mechanically locked
  - Indoor fan motor
  - Indoor fan motor drive circuit

[Diagnosis flow]

Initiating troubleshooting



## 11. Timer lamp blinking: blinking 12 times


[Situation] The timer blinks 12 times and the product will not run.

- [Estimated failure locations]
- Erroneous connection in the indoor-outdoor connection line (F cable)
  - Forget to connect CN27 of outdoor P.W.B
  - Wire break or poor insertion of the indoor-outdoor connection line (F cable)
  - Electrical parts in the outdoor unit (communication circuit, power circuit error)
  - Communication error due to noise in other home electronics
- ※This does not constitute a failure in the air-conditioner

[Cautions] • When lines 1 and 2 of F cable are erroneously connected (crossed), the product may not enter self-diagnosis display mode. If the self-diagnosis memory stores data about "timer lamp blinked 12 times", then, just in case, check if the F cable is not erroneously connected.

[Diagnosis flow]

Initiating troubleshooting



## 12. Timer lamp blinking: blinking 13 times


[Situation] The timer lamp blinks 13 times and the product will not run.

[Estimated failure location] • EEPROM, microcomputer


[Diagnosis flow]

Replace the "indoor control P.W.B".


# Checking the electrical parts of the outdoor unit




\* This page is for RAC-25/35FXB





\* This page is only for RAC-50FXB











# CHECKING THE REFRIGERATING CYCLE

(JUDGING BETWEEN GAS LEAKAGE AND COMPRESSOR DEFECTIVE)

## 1. Troubleshooting procedure (No operation, No heating, No cooling)

Connect U,V,W phase leads to the power module again and operate the air conditioner.



Is the self-diagnosis lamp mode as shown on the right?

Lighting mode Self-diagnosis lamp	Blinks 2 times	Blinks 3 times	Blinks 4 times	Blinks 5 times	Blinks 6 times	Blinks 8 times
	LD301					
Time until the lamp lights	Approx. 10 seconds			Approx. 10 seconds	Within Approx. 30 seconds	Approx. 10 seconds
Possible malfunctioning part	Compressor				Gas leakage	Compressor

Blinking off

Outdoor air temperature (°C)	Charge port pressure MPa(G) {kgf/cm <sup>2</sup> (G)}	
	50	2.96
45	2.62	{26.72}
40	2.31	{23.58}
35	2.03	{20.73}
30	1.78	{18.14}
25	1.55	{15.79}
20	1.34	{13.66}
15	1.15	{11.74}
10	0.98	{10.02}
5	0.83	{ 8.48}
0	0.70	{ 7.10}
-5	0.58	{ 5.89}
-10	0.47	{ 4.81}


(R410 A)  
The values above are the theoretical ones.

YES



Stop to operate and check the gas pressure in balancing mode.

Normal



• Checking the IPM (main P.W.B.)

Error (Gas leaking)




Gas leaks. Repair and seal refrigerant.

When the self-diagnosis lamp lights in the same condition as above.



The compressor is defective. Replace it and seal refrigerant.  
( If the compressor checker for an inverter type air conditioner is available, re-check using it. )



Perform a final check of operation.

## Forced cooling operation (Only single connection)

The cooling operation can be forcibly performed for collecting refrigerant and inspecting failures. Do not perform the forced cooling operation continuously for long hours, because the compressor continues to be in operational status, regardless of room temperature.

### <How to start the operation>

- The operation of the unit should be stopped.
- Open the front panel of the indoor unit and press and hold the "Temporary operation SW" shown in the right figure for 5 sec.


### <How to stop the operation>

- Press and hold the "Temporary operation SW" again. Or stop the operation using the remote controller.

※During the forced cooling operation, the "Timer indicator" blinks twice.

### Temporary operation switch

When performing the forced cooling operation, turn the power off once. If you press and hold the switch for 5 sec or longer, the forced cooling operation starts. To stop the forced cooling operation, press the switch once again or stop the operation using the remote controller.



### When you want to operate the outdoor unit because the indoor unit electrical part has broken down


1. Confirm that the "LD301" blinks once from the terminal side of the outdoor unit. Afterwards (when about 30 sec elapses after the power turns on), confirm that the "LD301" changes to blinking 9 times (communication error).
2. When the "LD301" is blinks 9 times, if you press the test switch, the "LD301" lights up.

If you release your finger from the test switch within 1 sec to 5 sec after pressing the switch, the forced cooling operation starts.

※(If you press the test switch for 5 sec or longer, the self-check diagnosis starts. In this case, turn the power off and start the procedure from 1 again.)

※(For the initialization of the expansion valve, it may take 1 min until the operation starts.)

3. When you press the test switch again for 1 sec or longer, the unit stops the operation.



### ※Cautions

1. If power is directly supplied to the outdoor unit, the stress is applied to the outdoor unit due to inrush current. Therefore, unless the indoor unit has broken down, do not use the method.
2. Never operate the unit for 5 min or longer.

※Cautions

1. Applying power directly to the outdoor unit will cause a rush current to stress the outdoor unit. Therefore, if the indoor unit is not out of order, do not use the method described in 2).
2. Before making the connections, be sure to turn off the breaker.
3. Do not under any circumstances run the product for more than 5 minutes.
4. Doing work with the compressor connector removed will cause the LD301 to blink 4 times. It will not start.
5. For another test run, turn off the breaker and turn it back on. (The test switch is accepted only once after power-on. After operation by remote control, it is not accepted.)
6. When the operation with the test switch is over, turn off the breaker and set the connectors back.


## HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY

### RAC-25/35FXB

1. Connect the large dia. pipe side and small dia. pipe side service valve using a pipe.

Connect the small diameter service valve and the large diameter service valve using the reducing union and copper pipe as shown on the right.

Charge refrigerant of 300g after vacuuming (※1)



#### Parts to be prepared

- (1) Reducing union  
2/8" (6.35 mm)  
3/8" (9.52 mm)
- (2) Copper pipe (2/8" and 3/8")

Do not operate for more than 5 minutes

The operation method is the same as "How to operate using the connector to servicing the outdoor unit".


※1 The charging amount of 300g is equivalent to the load in normal operation.

### RAC-50FXB

1. Connect the large dia. pipe side and small dia. pipe side service valves using a pipe.

Connect the small diameter service valve and the large diameter service valve using the reducing union and copper pipe as shown on the right.

Charge refrigerant of 300g after vacuuming (※1)



#### Parts to be prepared

- (1) Reducing union  
2/8" (6.35mm)  
1/2" (12.7mm)
- (2) Copper pipe (2/8" and 1/2")
- (3) Shorting leads  
2 leads approx. 10 cm long  
with alligator clip or IC clip

Do not operate for 5 minutes or more.

The operation method is the same as "How to operate using the connector to servicing the outdoor unit".

※1 The charging amount of 300g is equivalent to the load in normal operation.

## HOW TO CHANGE THE SHIFT VALUE SETTING TEMPERATURE

The shift value setting temperature for Cooling and Heating mode operation can be change using remote controller. (This procedure shall be implemented strictly by service personnel only.)

(For initial shift value temperature setting for Cooling mode (SHIFTC) and Heating operation mode (SHIFTW) :  
Please refer to page 40)

### PROCEDURES


1. While pressing and holding  $\text{⓪}$  (START/STOP) button and  $\text{⓪}$  (TIMER ON) button, press RESET  $\text{⓪}$  [RESET] button on the same. Release RESET  $\text{⓪}$  [RESET] button only and make sure that all marks on the remote controller display are indicated, then release the  $\text{⓪}$  (START/STOP) button and  $\text{⓪}$  (TIMER ON) button. Remote controller now enters "Shift Value Change Mode".

2. Press the  $\text{MODE}$  (MODE) selector button so that the display indicates  $\text{FAN}$  mode.


3. Press the  $\text{⓪}$  (START/STOP) button and FAN operation will be started.

4. Set the FAN SPEED with the  $\text{FAN}$  (FAN SPEED) button according to the following FAN speed setting in order to choose the desired operation mode that is required for shift value setting temperature modification.

- To change the shift value for COOLING mode operation, select either  $\text{H}$  (HIGH) or  $\text{M}$  (MED) FAN SPEED.
- To change the shift value for HEATING mode operation, select either  $\text{L}$  (LOW) or  $\text{S}$  (SILENT) FAN SPEED.



5. Press the (TEMP  $\text{v}$  or  $\text{^}$ ) button to change the shift value.  
(The shift value changed with device beep sound.)



### NOTE :

- (1) The displayed shift value,  $\text{HEAT}$  and  $\text{COOL}$  symbol on the remote controller display will be disappear after 10 seconds.
- (2) The changed shift value will remain unchanged after turned off the power.
- (3) If "0" is displayed on the remote controller display, it indicates the shift value is now at the initial setting.

## SETTING THE PREVENTION OF MUTUAL INTERFERENCE FOR REMOTE CONTROLLER

( Applicable for Remote controller model : RAR-5E1, RAR-5E2, RAR-5E3, RAR-5E4 and RAR-5E5 )

Case : 2 sets of indoor units installed near to each other.

If both indoor units can receive the same remote controller signal, please set the remote controller as below. ( This setting will change the signal address of each remote controller.)


Initial remote controller signal address setting is A.

This procedure change the remote controller signal address from A to B.

1. The circuit breaker for the other unit shall be OFF.



2. Slide the remote controller cover to take it off.  
3. While directing the remote controller towards the receiver of the indoor unit, press 1-6 button, ON (ON TIMER) button and RESET ○ (RESET) button simultaneously. (The remote controller perform signal transmission with the device.)



Signal transmission : From A to B



4. The indoor unit beeps [Pip] to indicate that it has just received the signal from remote controller.




5. Please check the usability of each set of indoor unit using its own remote controller.

Note : If indoor unit still not receive the correct signal from the correct remote controller, setting shall be made again.

By setting again for the 2nd time, the signal address will change from B to A. Then, if repeat again for the 3rd time, the remote controller signal address will change from A to B.

Please set the DIP switch No.6 to ON accordingly (Refer to page 59).

Signal transmission : From B to A












# OPERATION MODE LOCK SETTING

If Dip switch position is set at "Heating mode only" or "Cooling mode only" as mentioned on page 59, it is required to set the remote controller into operation mode lock setting. Without setting the remote controller, it will caused unmatch signal transmission between indoor unit and remote controller.







## PROCEDURE


### 1. Heating operation mode lock setting

- (a) While pressing and holding  (ECO) button and  (POWERFUL) button, press  (RESET) button on the same time. Release  (RESET) button only and make sure that all marks on the remote controller display are indicated, then release the  (ECO) button and  (POWERFUL) button. Remote controller now enters "Heating operation mode lock".
- (b) To cancel the "Heating operation mode lock", repeat the above procedure (1(a)).








### 2. Cooling operation mode lock setting

- (a) While pressing and holding  (ECO) button and  (SILENT) button, press  (RESET) button on the same time. Release  (RESET) button only and make sure that all marks on the remote controller display are indicated, then release the  (ECO) button and  (SILENT) button. Remote controller now enters "Cooling operation mode lock".
- (b) To cancel the "Cooling operation mode lock", repeat the above procedure (2(a)).











## NOTE :


- (1) The indication of " LOCK " and (" , " , "  " or "  ") mode operation symbol on the remote controller display will disappear after 10 seconds and it will enters to OFF condition indicated by  on the display.
- (2) The OPERATION MODE LOCK setting will remain in the remote controller memory even though the remote controller is ran out of battery.



# DISPLAY OPERATION MODE SETTING


For operating indoor unit independently (without outdoor unit connection), remote controller has to be set according to below procedures before send the signal to the indoor unit. New communication format between indoor and outdoor is required to communicate with outdoor unit.

## PROCEDURE

- While pressing and holding  (INFO) button and , press  (RESET) button on the same time. Release  (RESET) button only and make sure that all marks on the LCD display are indicated, then release the  (INFO) button and  (COPY/PASTE) button. Remote controller now enters "DISPLAY OPERATION MODE" for the indoor unit to run independently. Please ensure that when pressing  (FAN) button, "" will blinking.



- Press the  (MODE) selector button to choose the desired operation mode.
- Press  (START/STOP) button. Then, the indoor unit will starts to operate independently accoring the selected operation mode.



## NOTE :

- (1) During "DISPLAY OPERATION MODE", "" blinks on LCD of remote controller.
- (2) When operation stops, "DISPLAY OPERATION MODE" is canceled.


## HOW TO CHANGE THE FAN SPEED IN COOLING MODE DURING THERMO OFF

The fan speed in Cooling mode during thermo off can be changed by the remote controller.  
 (This procedure shall be implemented strictly by service personnel only.)  
 It is possible to return it to the default setting.

### PROCEDURE

Press  [POWERFUL] button and  [TIME ^ (UP)] button simultaneously for about 5 seconds when the remote controller is OFF.

Transmission sign lights up with beep from indoor unit simultaneously.



- Beep sound pattern : 1) Default setting : Short beep  
 2) Changed setting : Double beep

	Fan speed during thermo off
Default setting	Ultra low
Changed setting	Set fan speed (When auto fan speed is set, the fan speed is low.)


### NOTE :


- (1) The selected fan speed will remain unchanged after the unit is turned off.
- (2) If Timer reservation has been set, it will be canceled.
- (3) During time setting and timer setting, this operation cannot be set.

# HOW TO CHANGE THE INTERMITTENT FAN CONTROL SETTING

The intermittent fan control during thermo off in Heating mode can be changed by the remote controller. (This procedure should be done only by service personnel.)  
It is possible to select from 3 patterns.


## PROCEDURE

- Press  [START/STOP] button,  [Mon-Sun] button and press  [RESET] button simultaneously.  
Release  [RESET] button only and make sure that all marks on the remote controller display are indicated, then release  [START/STOP] button and  [Mon-Sun] button.  
Remote controller now enters "Intermittent Fan Control Change Mode".



- Press [ROOM TEMPERATURE setting] [ $\wedge$  (UP)]/[ $\vee$  (DOWN)] buttons.  
(The intermittent pattern changed with indoor unit beep sound.)

Transmission sign lights up with beep from indoor unit simultaneously.




	Pattern 1	Pattern 2	Pattern 3
Single model	Continuous	30sec ON/210sec OFF repeatedly	50sec ON/190sec OFF repeatedly
Multi model	30sec ON/210sec OFF repeatedly	50sec ON/190sec OFF repeatedly	Continuous

## NOTE :

- The indication of the selected intermittent pattern will disappear after 10 seconds.
- The selected intermittent pattern will remain unchanged after the unit is turned off.

# PARTS LIST AND DIAGRAM


MODEL RAF-25RXB, RAF-35RXB, RAF-50RXB



MODEL RAF-25RXB, RAF-35RXB, RAF-50RXB

NO.	PARTS NO.			Q'TY/ UNIT	PARTS NAME
	RAF-25RXB	RAF-35RXB	RAF-50RXB		
3		RAF-50A2 002		1	FAN MOTOR DC 38W, 1.1kg
4		RAS-N22V 005		1	TANGENTIAL FAN
5		RAS-E40V2 041		1	FAN SUPPORT ASSEMBLY
8		RAF-50A2 028		1	FAN MOTOR SUPPORT
10		RAS-E40V2 268		1	AUTO SWEEP MOTOR
11	RAF-35RXB 902		RAF-50RXB 902	1	HEATEXCHANGER ASSEMBLY
12		RAF-50RXB 916		1	AUTO SWEEP MOTOR
13		RAS-N22V 806	RAF-50RXB 806	1	UNION (3), (4)
15	RAF-25RXB 901	RAF-35RXB 901	RAF-50RXB 901	1	P.W.B. (CONTROL)
23		RAS-LJ22W 004		1	BULB SUPPORT WITH SHEET
44		RAF-50RXB 903		1	CABINET (W)
45		RAF-50RXB 904		1	FRONT COVER ASSEMBLY (W)
46		RAF-50RXB 905		1	DRAIN HOSE
48		RAF-25QXA 903		1	REMOCON SUPPORT
49		RAF-50RXB 906		1	REMOTE CONTROL ASSEMBLY
52		RAS-S40C2 036		1	THERMISTOR ASSEMBLY
54		RAF-50FX8 913		1	P.W.B. (INDICATION)
55		RAF-50Y2 022		1	WIDE DEFLECTOR 2
56		RAMF-36CS 005		1	SENSOR (HUMIDITY)
62		RAF-50W2 038		6	DEFLECTOR SUPPORT
63		RAF-50RXB 907		1	DISCHARGE FRAME (W)
64		RAF-50Y2 805		1	UNION (2)
65		RAF-50RXB 908		1	PIPE BAND
66		RAF-50Y2 029		1	RAT PREVENTION COVER
67		RAF-50Y2 041		1	PIPE COVER
69		RAF-50RXB 909		1	ACCESSARIES ASSEMBLY
71		RAF-50RXB 910		1	FRONT PANEL (W)
73		ATI-0972B 983		1	BAND (FOR FRONT PANEL)
74		RAF-50W2 052		2	LATCH 1 (FRONT COVER)
75		RAF-50FX8 924		1	AIR CLEAN FILTER
76		RAF-50RXB 911		1	SUCTION FRAME (W)
77		RAF-50RXB 912		1	WIDE DEFLECTOR 1 (W)
79		RAF-50Y2 014		1	FAN COVER
80	RAF-25RXB 902	RAF-35RXB 902	RAF-50RXB 913	1	LABEL ASSEMBLY
81		RAF-50RXB 914		1	STAND (W)
82		RAF-36Z 019		1	MOUNTING PLATE
83		RAF-50Y2 057		1	FILTER (UP) (LEFT)
84		RAF-50Y2 058		1	FILTER (UP) (RIGHT)
85		RAF-50Y2 059		1	FILTER (LEFT)
86		RAF-50Y2 060		1	FILTER (RIGHT)
87		RAF-50Y2 006		1	SUC-DEFLECTOR MOTOR
88		RAF-50RXB 915		2	DEFLECTOR (UPPER) (W)
89		RAF-25QXA 901		1	LIGHT RECEIVING UNIT
90		RAF-50Y2 067		1	GEAR MOTOR
91		RAF-50FX8 942		1	CONNECTING ROD
92		RAF-50FX8 943		2	SCREW COVER (W)

MODEL RAC-25FXB, RAC-35FXB




MODEL RAC-25FXB, RAC-35FXB

NO.	HHAW PARTS NO.		Q'TY/ UNIT	PARTS NAME
	RAC-25FXB	RAC-35FXB		
1	HWRAC-25FXB	A01	1	BASE
2	HWRAC-25YH4	A02	1	COMPRESSOR
3	HWRAC-25YH4	A04	3	PUSH NUT
4	HWRAC-25FXA	A01	1	CONDENSER
5	HWRAC-25FXB	A02	1	REVERSING VALVE
6	HWRAC-25FXB	A03	1	2S-VALVE
7	HWRAC-25FXB	A04	1	3S-VALVE
8	HWRAC-25FXB	A05	1	SOUND PROOF COVER ASSEMBLY
9	HWRAC-18WSA	A09	1	SOUND PROOF COVER ASSEMBLY
10	HWRAC-25FXB	A06	1	SOUND PROOF COVER ASSEMBLY
11	HWRAC-E08H	A05	1	ELECTRIC EXPANSION VALVE
12	HWRAC-18WSA	A10	1	O.L.R. COVER
13	HWRAC-18WSA	A11	1	CONNECTING CORD (COMPRESSOR)
14	HWRAC-D10EX	A08	1	THERMISTOR (DEFROST)
15	HWRAC-25WX8	A02	1	THERMISTOR SUPPORT
16	HWRAC-SX10HAK	A20	1	COIL (REVERSING VALVE)
17	HWRAC-D10EX2	A07	1	COIL (EXPANSION VALVE)
18	HWRAC-25FXB	A07	1	PARTITION
19	HWRAC-18WEB	A10	1	REACTOR 1
20	HWRAC-D10EX	A11	1	FAN MOTOR SUPPORT
21	HWRAC-50NX2	A23	1	FAN MOTOR
22	HWRAC-14BH3	914	1	PROPELLER FAN
23	HWRAC-25YH4	A24	1	NUT (PROPELLER FAN)
24	HWRAC-25YH4	A25	1	SIDE COVER (L)
25	HWRAC-25YH4	A26	1	HANDLE
26	HWRAC-25FXB	A08	1	FRONT COVER
27	HWRAC-E14H3	909	1	DISCHARGE GRILL
28	HWRAC-25FXB	A09	1	ELECTRIC PARTS PLATE
29	HWRAC-35WPB	A08	1	ELECTRIC PARTS COVER
30	HWRAC-25YH4	A50	1	DRAIN PIPE
31	HWRAC-18WEB	A19	1	TERMINAL BOARD (5P)
32	HWRAC-35WPB	A09	1	HEAT SINK (REGURATOR 1)
33	HWRAC-25FXB A10	HWRAC-35FXB A11	1	P.W.B. (POWER)
34	HWRAC-35WPB	A11	1	SUPPORT (P.W.B.)
35	HWRAC-18WEB	A22	1	FUSE (15A)
36	HWRAC-10EH4	A13	1	COVER (OUT DOOR THERMISTOR)
37	HWRAC-D10EX	A17	1	THERMISTOR (OUTDOOR TEMPERATURE)
38	HWRAC-25YH5	A03	1	SIDE COVER (R)
39	HWRAC-35WPB	A12	1	TERMINAL COVER
40	HWRAC-25YH4	A46	1	TOP COVER
41	HWRAC-25YH4	A47	1	SERVICE VALVE COVER
42	HWRAC-25YH4	A48	1	BUSH ASSEMBLY
43	HWRAC-25YH4	A49	1	BUSH
44	HWRAC-25YH4	A03	3	COMPRESSOR RUBBER
45	HWRAC-E08H	A11	1	FUSE (15A)
46	HWRAC-50NX2	A52	2	FUSE (3.15A)
47	HWRAC-25FXB	A12	1	VALVE PLATE



MODEL RAC-50FXB



MODEL RAC-50FXB

NO.	HHAW PARTS NO.	Q'TY/ UNIT	PARTS NAME
1	HWRAC-50WXB A01	1	BASE
2	HWRAC-50WEA A02	1	COMPRESSOR
3	HWRAC-50WEA A03	3	COMPRESSOR RUBBER
4	HWRAC-50NX2 A04	3	PUSH NUT
5	HWRAC-50WXB A02	1	CONDENSER
6	HWRAC-50FXB A01	1	REVERSING VALVE
7	HWRAC-50WEA A05	1	SERVICE VALVE
8	HWRAC-50WEA A06	1	SERVICE VALVE
9	HWRAC-50NX2 A09	1	ELECTRIC EXPANSION VALVE
10	HWRAC-50FXB A02	1	SOUND PROOF
11	HWRAC-50FXB A03	1	SOUND PROOF
12	HWRAC-50FXB A04	1	SOUND PROOF
13	HWRAC-50FXB A05	1	SOUND PROOF
14	HWRAC-50WEA A11	1	O.L.R. COVER
15	HWRAC-50WXB A04	1	CONNECTING CORD (COMPRESSOR)
16	HWRAC-50WXB A28	1	THERMISTOR (DEFROST)
17	HWRAC-50NX2 A17	1	THERMISTOR SUPPORT
18	HWRAC-SX10HAK A20	1	COIL (REVERSING VALVE)
19	HWRAC-E08H A09	1	COIL (EXPANSION VALVE)
20	HWRAC-50WXB A05	1	PARTITION
21	HWRAC-18WSPA A06	1	REACTOR
22	HWRAC-50WXB A06	1	FAN MOTOR SUPPORT
23	HWRAC-50NX2 A23	1	FAN MOTOR
24	HWRAC-50WXB A07	1	PROPELLER FAN
25	HWRAC-25YH4 A24	1	NUT (PROPELLER FAN)
26	HWRAC-50WXB A09	1	NET LEFT
27	HWRAC-50WXB A10	1	LEFT PLATE
28	HWRAC-50FXB A06	1	FRONT COVER
29	HWRAC-50WXB A12	1	DISCHARGE GRILL
30	HWRAC-50FXB A07	2	SOUND PROOF
31	HWRAC-50WXB A14	1	THERMI-C
32	HWRAC-50WXB A15	1	SIDE COVER (R)
33	HWRAC-50WXB A16	1	TC-COVER
34	HWRAC-50WXB A17	1	PROTECTIVE NET
35	HWRAC-50WXB A18	1	TER-PLATE
36	HWRAC-50WXB A19	1	TOP COVER
37	HWRAC-50WXB A20	1	TERMINAL-COVERAS
38	HWRAC-50WXB A21	1	EV-COVER
39	HWRAC-50WXB A22	2	HANDLE
40	HWRAC-50WXB A23	1	DRAIN PIPE
41	HWRAC-50WXB A24	1	ELECTRIC PARTS PLATE
42	HWRAC-50WEB A06	1	ELECTRIC PARTS COVER
43	HWRAC-50WEB A07	2	SUPPORT (P.W.B.)
44	HWRAC-50WEB A08	1	HEAT SINK
45	HWRAC-50FXB A08	1	P.W.B. (MAIN)
46	HWRAC-50WEB A10	1	12 CORD ASSEMBLY
47	HWRAC-50WEB A11	1	CORD ASSEMBLY
48	HWRAC-18WEB A18	1	TERMINAL BOARD (5P)
49	HWRAC-50NX2 A51	1	FUSE (25A)
50	HWRAC-50NX2 A52	2	FUSE (3.15A)
51	HWRAC-50WEB A13	1	SUPPORT (P.W.B.)
52	HWRAC-50WEB A14	1	O.L.R. COVER
53	HWRAC-50WXB A26	1	FIX-PLATE
54	HWRAC-50WXB A27	4	PC-SUP
55	HWRAC-50FXB A09	1	VALVE-ZA
56	HWRAC-50FXB A10	1	S-PIPEAS

# HITACHI

---

**RAF-25RXB / RAC-25FXB**  
**RAF-35RXB / RAC-35FXB**  
**RAF-50RXB / RAC-50FXB**

**TC NO. 0842E**

Printed in Japan (HRT)