

UTY-LNHY
UTY-LNHG

INSTALLATION MANUAL

WIRELESS REMOTE CONTROLLER

For authorized service personnel only.

English

INSTALLATIONSANLEITUNG

KABELLOSE FERNBEDIENUNG

Nur für autorisiertes Fachpersonal.

Deutsch

MANUEL D'INSTALLATION

TÉLÉCOMMANDE SANS FIL

Pour le personnel d'entretien autorisé uniquement.

Français

MANUAL DE INSTALACIÓN

MANDO A DISTANCIA INALÁMBRICO

Únicamente para personal de servicio autorizado.

Español

MANUALE DI INSTALLAZIONE

UNITÀ DI CONTROLLO SENZA FILI

A uso esclusivo del personale tecnico autorizzato.

Italiano

ΕΓΧΕΙΡΙΔΙΟ ΕΓΚΑΤΑΣΤΑΣΗΣ

ΑΣΥΡΜΑΤΟ ΤΗΛΕΧΕΙΡΙΣΤΗΡΙΟ

Μόνο για εξουσιοδοτημένο τεχνικό προσωπικό.

Ελληνικά

MANUAL DE INSTALAÇÃO

CONTROLO REMOTO SEM FIOS

Apenas para pessoal de assistência autorizado.

Português

РУКОВОДСТВО ПО УСТАНОВКЕ

БЕСПРОВОДНОЙ ПУЛЬТ ДИСТАНЦИОННОГО УПРАВЛЕНИЯ

Только для авторизованного обслуживающего персонала.

Русский

KURULUM KILAVUZU

KABLOSUZ UZAKTAN KUMANDA

Yalnızca yetkili servis personeli için.

Türkçe

安装说明书

无线遥控器

仅针对授权的专业维修人员。

中文

INSTALLATION MANUAL


PART NO. 9371972046-06
WIRELESS REMOTE CONTROLLER

CONTENTS

1. SAFETY PRECAUTIONS.....	1
2. MAIN UNIT AND ACCESSORIES	1
3. TURNING ON THE POWER	2
4. INSTALLING THE REMOTE CONTROLLER.....	2
4.1. Load batteries (AAA/LR03/R03 x 2)	2
4.2. Installing the remote controller holder	2
5. ADDRESS SETTING.....	3
6. FUNCTION SETTING.....	6
7. SELECTING THE REMOTE CONTROLLER SIGNAL CODE.....	9
8. TEST RUN.....	9

1. SAFETY PRECAUTIONS

- The "SAFETY PRECAUTIONS" indicated in this manual contain important information pertaining to your safety. Be sure to observe them.
- Request the user to keep this manual on hand for future use, such as for relocating or repairing the unit.

 WARNING	This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.
Perform installation work in accordance with this manual. Request an authorized service personnel to perform installation work. Improper installation work will cause injury, electric shock, fire, etc.	
If children may approach the unit, take preventive measures so that they cannot reach the unit.	
Dispose of the packing materials safely. Tear and dispose of the plastic packing bags so that children cannot play with them. There is the danger of suffocation if children play with the original plastic bags.	
Do not install the unit in the following areas: <ul style="list-style-type: none"> Do not install the unit near a source of heat, steam, or flammable gas. Otherwise, fire could result. Area filled with mineral oil or containing a large amount of splashed oil or steam, such as a kitchen. It will deteriorate plastic parts. Area containing equipment that generates electromagnetic interference. It will cause the control system to malfunction, preventing the unit from operating normally. Install the unit in a well-ventilated place avoiding rains and direct sunlight. 	

CAUTION

This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user or damage to property.

Do not install in any place at a temperature of more than 40 °C or less than 0 °C or exposed to direct sunlight.

Do not press any control button using a sharp object. It will cause an electric shock or a malfunction.

Do not install in any place exposed to flammable gas leakage. Flammable gases accumulated around the body of the controller may cause an explosion.

Do not install in any place where acidic or alkaline solution or special spray are often used. It will cause an electric shock or malfunction.

Do not use in any special environment. Using in any place exposed to oil (including machine oil), steam and sulfuric gas may deteriorate the performance significantly or give damage to the component parts.

Do not expose this unit directly to water. It will cause trouble, electrical shock, or heating.







Do not set vessels containing a liquid on this unit. It will cause heating, fire, or electrical shock.

Do not wash with water. It will cause an electric shock or breakdown.

Do not touch any control button with wet hands. It will cause an electric shock or breakdown.

Do not install in any steamy place such a bathroom or kitchen. Avoid any place where moisture is condensed into dew. It will cause an electric shock or a malfunction.

2. MAIN UNIT AND ACCESSORIES

Name and Shape	Q'ty	Name and Shape	Q'ty
Wireless remote controller 	1	Battery [1.5V (AAA/R03)] 	2
Installation manual 	1	Remote controller holder 	1
Operating manual 	1	Screw (M3 x 12mm) 	2

3. TURNING ON THE POWER

- (1) Throw the circuit breakers for the indoor unit and outdoor unit.
- (2) Make sure that the operation indicator lamp and timer indicator lamp are slowly flashing alternately.
 - If the auto restart function has been set, the air conditioner will operate with the settings which are immediately before the power supply was turned off.
 - If an error has occurred, the lamps on the IR receiver unit will flash quickly to indicate the error code. (Refer to the installation manual of the indoor unit.)

4. INSTALLING THE REMOTE CONTROLLER

4.1. Load batteries (AAA/LR03/R03 x 2)

⚠ CAUTION

Take care to prevent infants from accidentally swallowing batteries.

When not using the Remote Controller for an extended period, remove the batteries to avoid possible leakage and damage to the unit.

Dead batteries should be removed immediately and disposed of properly, either in a battery collection receptacle or to the appropriate authority.

Do not attempt to recharge dry batteries.

Do not use rechargeable batteries.

If your skin, eyes or mouth contact the battery liquid, wash with enough water immediately, and consult your doctor.

Note:
Use batteries in accordance with specified standard only. Replace discharged batteries with new units. Check the indicated poles and insert from the minus pole.

To load the batteries, refer to the operating manual of the wireless remote controller.

4.2. Installing the remote controller holder

⚠ WARNING

Always use the accessories and specified installation work parts. Not using the specified parts will cause units to fall off, electric shock, fire, etc.

Install at a place that can withstand the weight of the unit and install positively so that the unit will not topple or fall.

When installing the controller holder take precautions to prevent access by infants. It may cause an injury.

⚠ CAUTION

Fixing of the holder cover with the screws in the standard parts may be unsuitable if the wall or ceiling material is weak. If so, prepare screws suitable for the wall or ceiling material, and fix it.

Too tight fastening of screw may cause damage to the holder when fixing the holder of this unit.


Check carefully the installation location of this unit.

- A place where the indoor unit receives signals clearly from the main unit.
- A place where direct sunshine is avoided.
- A place avoiding thermal radiation from heating devices, such as a stove.


Note:

- Use the controller holder that is provided to avoid misplacing the remote controller.
- Out of the airflow from the air conditioner (cool or warm)
- Out of the reach of small children.
- If the air conditioner unit is installed in a room in which a fluorescent light on an electronic lighting control system (i.e., inverter light) is installed, signal interference may occur.
- If there is a fluorescent light in the room in which the air conditioner is to be installed, turn it on and make sure that the signal from the remote controller can be received by the indoor unit from the intended installation location.
- When the signal receiving unit receives a signal from the remote controller, a short beeping sound will be heard.
- Install the remote controller holder to a wall, pillar, etc. with the screw.
- After installing this unit, perform the test run to confirm that the unit is operating properly.
Then, explain the operation of this unit to the customer.


(1) Mount the Holder.



(2) Set the Remote Controller.



(3) To remove the Remote Controller (when use at hand).



5. ADDRESS SETTING

Address setting method can be selected from 3 options, outdoor unit, indoor unit and remote controller. Refer to the installation manual of outdoor unit or indoor unit when set up from the outdoor unit or the indoor unit.

■ Infrared address setting

- A wireless remote controller is required to set the infrared address setting.
- This function is available in all indoor unit with infrared signal receiver.
- Infrared address setting for duct type and cassette type models can be made possible by using the optional IR receiver unit.

Note : Since Beeping sound generate from indoor unit PC board installed far away (not from IR receiver unit), sound might not be heard.


- The indoor unit's refrigerant circuit address and indoor unit address can be set performing the infrared address setting.
- When remote controller address setting is required, set by the rotary switch on the indoor unit's PC board.

■ Preparation


- (1) Set the switch on the indoor unit's PC board that is used for manual address setting is set to "00" at factory setting.

(This process is unnecessary for newly installed and not yet set the SW.)

This is an example of PC board of indoor unit
Refer to the installation manual of indoor unit when set up.




- (2) Turn on the power to the indoor unit.
 - * By turning on the power indoor units initializes EEV, so make sure the piping air-tight test and vacuuming have been conducted before turning on the power.
 - * Also check again to make sure no wiring mistakes were made before turning on the power.




■ Switching selection of address setting mode

- (3) Press and hold the "MANUAL/AUTO" button for 3 seconds.




- (4) Press and hold the "FAN" and the "SET TEMP. ▲" buttons. Whilst holding these 2 buttons, press the "RESET" button.




- The position of the "MANUAL/AUTO" button varies depending on the model. Refer to the operating manual for the position that is included with the unit.
- The error will be displayed by continuously pressing the "MANUAL/AUTO" for 10 sec or more. In this case release the button or turn off the power.
- When the address has already been set in the circuit board, the OPERATION LAMP will light up and the TIMER and FILTER LAMPS will display the number of setting address.

■ Selection and confirmation of custom code

- (5) Press the "SET TEMP. ▲" or "SET TEMP. ▼" buttons to select the custom code that matches the setting with the indoor unit. By selecting the appropriate custom code, the communication between the indoor unit and the wireless RC become possible.



- (6) Press the "TIMER MODE" button to send the code to the indoor unit.




- Custom code returns to "A" when "RESET" button is pressed.
- Custom code setting is required when set up again.


■ Address setting

Indoor unit address setting


- (7) Press the "MODE" button to access the address setting mode.




- (8) Make sure the function number is '01'. If the number is other than '01', press the "▲" or the "▼" buttons to alter.




- (9) Press the "FAN" button to access the address data setting mode. The address data will flash once this button is pressed.



- (10) Press the "▲" or the "▼" buttons to adjust the address data. The indoor unit address range is between 00 and 63. Each time the "MODE" button is pressed, it switches between the one's place and the ten's place.





- (11) Press the "START/STOP" button once to send the information. A beeping sound will be heard if the command is accepted.




- * In the following cases the setting signal is not read and a buzzer sounds.
The indoor unit address No. is set out of range (64 or more) : Pi Pi Pi Pi Pi Pi
The setting of the rotary switch on the PC board is not "00" : Pi Pi Pi Pi Pi Pi

- (12) Indoor unit will display the indoor unit address data number on "TIMER" (ORANGE) and "FILTER" (RED) light.




(Example) ADDRESS : 34


OPERATION LAMP (GREEN)



TIMER LAMP (ORANGE)




FILTER LAMP (RED)



* ADDRESS 0 setting will not indicate TIMER LAMP and FILTER LAMP.

Confirmation of address setting


- (13) Press the "TIMER set (+)" button.




Refrigerant circuit address setting

Note : The refrigerant circuit address is displayed when the following operations are performed even while indoor unit address is displayed on LED display of indoor unit.


- (14) Press the "FAN" button to select the function number.




- (15) Press the "▲" or the "▼" button to adjust function number 02.




- (16) Press the "FAN" button to access the address data setting mode. The address data will flash once this button is pressed.



- (17) Press the "▲" or the "▼" buttons to adjust the address data. The refrigerant circuit address range is between 00 and 99. Each time the "MODE" button is pressed, it switches between the one's place and the ten's place.




- (18) Press the "START/STOP" button once to send the information. A beeping sound will be heard if the command is accepted.




* In the following cases the setting signal is not read and a buzzer sounds. The setting of the rotary switch on the PC board is not "00" : Pi Pi Pi Pi Pi

- (19) Indoor unit will display the refrigerant circuit address data number on "TIMER" (ORANGE) and "FILTER" (RED) light.




(Example) ADDRESS : 25



* ADDRESS 0 setting will not indicate TIMER LAMP and FILTER LAMP.


Confirmation of address setting

- (20) Press the "TIMER set (+)" button.




Completion of address setting mode

- (21) Press and hold the "MANUAL/AUTO" button for 3 seconds.



* Each LED light brightness is darkening though the content of the display doesn't change.

- (22) Press the "RESET" button. After pressing the "RESET" button, please set the custom code again if b,c,d setting.




* The address setting signal is not received after switched address setting completion mode. (Pi Pi Pi Pi Pi)

* Press the "MANUAL/AUTO" button again for 3 sec to return to if required to return the address setting mode.


Reconfirmation of address setting

- (23) Press and hold the "FAN" and the "SET TEMP. ▲" buttons. Whilst holding these 2 buttons, press the "RESET" button.




Indoor unit address setting

- (24) Make sure the function number is "01". Refer to (8). Press the "TIMER set (-)" button.




(Example) ADDRESS : 34




Refrigerant circuit address setting

- (25) Make sure the function number is "02". Refer to (15). Press the "TIMER set (-)" button.




- Press the "RESET" button to cancel the address setting mode.

(Example) ADDRESS : 25



Setting up each indoor unit



Repeat steps (1) through to (25). Steps (1) through to (6) and (21) to (25) only need to be carried out if the custom code is different to the factory setting of "A".

Reset the power after setting up address of all indoor units

Important

- If the reset is not performed, address cannot be read in normally.
- After all the addresses have been set, the circuit breaker needs to be switched off for at least 2 minutes. After the 2 minutes has passed, power can be restored.
- The set address is stored in the PC board and will remain in memory even when the power is turned off. However setting address is effective after power reset. Record the address set in the indoor unit on a label, etc., and affix the label to the unit so it can be used for after-sales service operations.


- * Address 0 setting will not indicate TIMER LAMP and FILTER LAMP.
- * Once the "RESET" button is pressed on the remote controller, the OPERATION MODE will be set in the "AUTO MODE". Please adjust the OPERATION MODE to either "COOLING" or "HEATING" before trying to operate the air conditioner.
- * Note : If CUSTOM CODE is set to anything other than "A", the remote controller must be set accordingly to the INDOOR UNIT setting.

6. FUNCTION SETTING

- This procedure changes to the function settings used to control the indoor unit according to the installation conditions. Incorrect settings can cause the indoor unit malfunction.
- After the power is turned on, perform the "FUNCTION SETTING" according to the installation conditions using the remote controller.
- The settings may be selected between the following 2: Function Number or Setting Number.
- Settings will not be changed if invalid numbers or setting numbers are selected.


Preparation

- Turn on the power to the indoor unit.
 - * By turning on the power indoor units initialize EEV, so make sure the piping air-tight test and vacuuming have been conducted before turning on the power.
 - * Also check again to make sure no wiring mistakes were made before turning on the power.




Switching selection of function setting mode

- Press and hold the "MANUAL/AUTO" button for 3 seconds.




- Press and hold the "FAN" and the "SET TEMP. ▲" buttons. Whilst holding these 2 buttons, press the "RESET" button.




- The position of the "MANUAL/AUTO" button varies depending on the model. Refer to the operation manual for the position that is included with the unit.
- The error will be displayed by continuously pressing the "MANUAL/AUTO" for 10 sec or more. In this case, release the button or turn off the power.

Selection and confirmation of custom code

- Press the "SET TEMP. ▲" or "SET TEMP. ▼" buttons to select the custom code that matches the setting with the indoor unit. By selecting the appropriate custom code, the communication between the indoor unit and the wireless RC become possible.




- (5) Press the "TIMER MODE" button to send the code to the indoor unit.




■ **Function setting**


- (6) Press the "MODE" button to access the function setting mode.




- (7) Press the "▲" or the "▼" buttons to select the function number. Each time the "MODE" button is pressed, it switches between the one's place and the ten's place.




- (8) Press the "FAN" button to proceed to setting the number. (Press the "FAN" button again to return to the function number selection.)



- (9) Press the "▲" or the "▼" buttons to select the setting number. Each time the "MODE" button is pressed, it switches between the one's place and the ten's place.




- (10) Press the "START/STOP" button once to send the information. A beeping sound will be heard if the command is accepted.




* In the following cases the setting signal is not read and a buzzer sounds. The function setting No. is set out of range : Pi Pi Pi Pi Pi Pi

Case1 : When setting number is 1 digit.

- (11-1) Indoor unit will display the function setting number on "OPERATION" (GREEN), "TIMER" (ORANGE) and "FILTER" (RED) light.



(Example) Function number : 30, Setting number : 01




* Number 0 setting will not indicate TIMER LAMP and FILTER LAMP.

Case2 : When setting number is 2 digits.


- (11-2) Indoor unit will display the function setting number on "OPERATION" (GREEN), "TIMER" (ORANGE) and "FILTER" (RED) light.

Phase1




The display of "Phase1" and "Phase2" is alternately repeated.

Phase2




(Example) Function number : 26, Setting number : 31



* Number 0 setting will not indicate TIMER LAMP and FILTER LAMP.


Confirmation of function setting

(12) Press the "TIMER set (+)" button.




Completion of function setting mode

(13) Press and hold the "MANUAL/AUTO" button for 3 seconds.



* Each LED light brightness is darkening though the content of the display doesn't change.

(14) Press the "RESET" button. After pressing the "RESET" button, please set the custom code again if b,c,d setting.




* The function setting signal is not received after switched function setting completion mode. (Pi Pi Pi Pi Pi Pi)


* Press the "MANUAL/AUTO" button again for 3 sec to return to if required to return the function setting mode.

Reconfirmation of function setting

(15) Press and hold the "FAN" and the "SET TEMP. ▲" buttons. Whilst holding these 2 buttons, press the "RESET" button.




(16) Function number to be confirmed is displayed. Refer to (7). Press the "TIMER set (-)" "TIMER set (-)" button.




Case1 : When setting number is 1 digit.

(Example) Function number : 30, Setting number : 01




Case2 : When setting number is 2 digits.

(Example) Function number : 26, Setting number : 31



Setting up each indoor unit



Repeat steps (1) through to (16). Steps (1) through to (5) and (13) to (16) only need to be carried out if the custom code is different to the factory setting of "A".

Reset the power after setting up function of all indoor units

Important

- If the reset is not performed, function cannot be read in normally.
- After all the functions have been set, the circuit breaker needs to be switched off for at least 2 minutes. After the 2 minutes has passed, power can be restored.
- The set function is stored in the PC board and will remain in memory even when the power is turned off. However setting function is effective after power reset. Record the function set in the indoor unit on a label, etc., and affix the label to the unit so it can be used for after-sales service operations.

- * Number 0 setting will not indicate TIMER LAMP and FILTER LAMP.
- * Once the "RESET" button is pressed on the remote controller, the OPERATION MODE will be set in the "AUTO MODE". Please adjust the OPERATION MODE to either "COOLING" or "HEATING" before trying to operate the air conditioner.
- * Note : If CUSTOM CODE is set to anything other than "A", the remote control must be set accordingly to the INDOOR UNIT setting.

7. SELECTING THE REMOTE CONTROLLER SIGNAL CODE

When 2 or more air conditioners are installed in a room and the remote controller is operating an air conditioner other than the one you wish to set, change the signal code of the remote controller to operate only the air conditioner you wish to set (4 selections possible).


When 2 or more air conditioners are installed in a room, please contact your retailer to set the individual air conditioner signal codes.

- Confirm the setting of the remote controller signal code and the printed circuit board setting.
If these are not confirmed, the remote controller cannot be used to operate for the air conditioner.

Remote Controller Settings

Use the following steps to select the signal code of the remote controller. (Note that the air conditioner cannot receive a signal code if the air conditioner has not been set for the signal code.)

- (1) Press the "START/STOP" button until only the clock is displayed on the remote controller display.
- (2) Press the "MODE" button for at least 5 seconds to display the current signal code (initially set to **A**).
- (3) Press the "SET TEMP. (▲) (▼)" button to change the signal code between **A** → **b** → **c** → **d**. Match the code on the display to the air conditioner signal code.
- (4) Press the "MODE" button again to return to the clock display. The signal code will be changed.



If no buttons are pressed within 30 seconds after the signal code is displayed, the system returns to the original clock display. In this case, start again from step 1.

The air conditioner signal code is set to A prior to shipment. Contact your retailer to change the signal code.

The remote controller resets to signal code A when the batteries in the remote controller are replaced. If you use a signal code other than signal code A, reset the signal code after replacing the batteries.

If you do not know the air conditioner signal code setting, try each of the signal codes (**A** → **b** → **c** → **d**) until you find the code which operates the air conditioner.

Indoor Unit Setting (Example)

PC board and switch layout in each indoor unit are different. Refer to the installation manual of each indoor unit.




Table A

	Custom code			
	A (Factory setting)	b	c	d
DIP SW 3-1	OFF	ON	OFF	ON
DIP SW 3-2	OFF	OFF	ON	ON

Refer to the installation manual of indoor unit since settings are different depending on each indoor unit.

CAUTION


When setting the DIP switch, be careful to avoid damaging other parts of the PC board.

8. TEST RUN

CHECK ITEMS

(1) OPERATION METHOD

- For the operation method, refer to the operating manual.
- The outdoor unit may not operate depending on the room temperature. In this case, press the "Test run" button on the remote controller while the air conditioner is running. (Point the transmitter section of the remote controller toward the air conditioner and press the "Test run" button with the tip of a ball-point pen, etc.)
- To end test run, press the remote controller "START/STOP" button. (When the air conditioner is run by pressing the "Test run" button, the OPERATION indicator lamp and TIMER indicator lamp will simultaneously flash slowly.)
- If the IR receiver unit is flashing (0.1 sec ON/0.1 sec OFF), there is an error; therefore, stop the operation immediately.



(2) ABOUT FUNCTIONING OF THE REMOTE CONTROLLER

- Check the behavior of each key in accordance with the operating manual.
- Refer to the installation manual of the indoor unit since the setting methods are different for each indoor unit.