




Installer and user reference guide

Heat reclaim ventilation unit



VAM350J7VEB
VAM500J7VEB
VAM650J7VEB
VAM800J7VEB
VAM1000J7VEB
VAM1500J7VEB
VAM2000J7VEB

Installer and user reference guide
Heat reclaim ventilation unit

English

Table of contents

1	General safety precautions	3
1.1	About the documentation	3
1.1.1	Meaning of warnings and symbols	3
1.2	For the user	3
1.3	For the installer	3
1.3.1	General	3
1.3.2	Installation site	4
1.3.3	Refrigerant	4
1.3.4	Brine	5
1.3.5	Water	5
1.3.6	Electrical	5
2	About the documentation	6
2.1	About this document	6
For the installer		6
3	About the box	6
3.1	Overview: About the box	6
3.2	Heat reclaim ventilation unit	7
3.2.1	To unpack the heat reclaim ventilation unit	7
3.2.2	To remove the accessories	8
3.2.3	To handle the heat reclaim ventilation unit	8
4	About the units and options	9
4.1	Overview: About the units and options	9
4.2	Identification	9
4.2.1	Identification label: Heat reclaim ventilation unit	9
4.3	About the heat reclaim ventilation unit	9
4.4	Combining units and options	9
4.4.1	Possible options for the heat reclaim ventilation unit	9
5	Preparation	10
5.1	Overview: Preparation	10
5.2	Preparing the installation site	10
5.2.1	Installation site requirements for the heat reclaim ventilation unit	10
5.3	Preparing the unit	10
5.3.1	To install the optional adapter printed circuit board	10
5.3.2	To install the duct joints	11
5.4	Preparing the electrical wiring	11
5.4.1	Wiring connection	11
5.4.2	Component electrical specifications	12
5.4.3	Specifications for field supplied fuses and wires	12
5.5	Preparing the installation of the ducts	13
6	Installation	13
6.1	Service space: Heat reclaim ventilation unit	13
6.2	Unit orientation	13
6.3	To install the anchor bolts	14
6.4	Duct connections	14
6.5	Electrical wiring	15
6.5.1	Precautions when connecting electrical wiring	15
6.5.2	Opening the switch box	16
6.5.3	Electrical connections for possible additional field supplied damper	19
6.5.4	Power supply connection, control wire terminals and switches on the circuit board	19
6.5.5	Guidelines when connecting the electrical wiring	19
7	System configuration	20
7.1	About control systems	20
7.2	Independent system	21
7.3	Interlocked system	21
7.4	Centralised control system	22










8	Configuration	22
8.1	Operating procedure	22
8.1.1	To change the settings with BRC1E53	22
8.1.2	To change the settings with BRC301B61	23
8.2	List of settings	24
8.3	Settings for all configurations	28
8.3.1	About setting 19(29)-0-04 and 19(29)-0-05	28
8.3.2	Independent system	29
8.3.3	1-group linked-control system	29
8.3.4	Linked control with more than 2 groups	29
8.3.5	Direct duct connection	30
8.3.6	Centralised control system	30
8.4	About the user interface	32
8.4.1	User interface for VRV-system air conditioner	32
8.4.2	User interface for heat reclaim ventilation units	33
8.5	Detailed explanation of settings	34
8.5.1	To monitor the unit's operation	34
8.5.2	About the fresh-up operation	34
8.5.3	About the external damper operation	35
8.5.4	About the carbon dioxide sensor	35
8.5.5	About the nighttime free cooling operation	37
8.5.6	About the pre-cool and pre-heat function	37
8.5.7	About preventing a feeling of draft	37
8.5.8	About 24-hour ventilation	37
8.5.9	About the ultra-low setting	37
8.5.10	About the electrical heater operation	38
8.5.11	About external linkage input	38
8.5.12	About filter contamination check	38
9	Commissioning	38
9.1	Overview: Commissioning	38
9.2	Precautions when commissioning	38
9.3	Checklist before commissioning	38
9.4	Checklist during commissioning	38
9.4.1	About the test run	38
10	Hand-over to the user	39
11	Maintenance and service	39
11.1	Overview: Maintenance and service	39
11.2	Maintenance safety precautions	39
11.2.1	To prevent electrical hazards	39
11.3	Checklist for maintenance of the heat reclaim ventilation unit	39
12	Troubleshooting	39
12.1	Overview: Troubleshooting	39
12.2	Precautions when troubleshooting	40
12.3	Solving problems based on error codes	40
12.3.1	Error codes: Overview	40
13	Disposal	40
14	Technical data	40
14.1	Wiring diagram: Heat reclaim ventilation unit	40
For the user		41
15	User interface	41
16	Before operation	41
17	Energy saving and optimum operation	41
18	Maintenance and service	42
18.1	Maintenance of the air filter	42
18.2	Maintenance of the heat exchange element	43
19	Troubleshooting	43
20	Relocation	43
21	Disposal	43




1 General safety precautions

1.1 About the documentation

- The original documentation is written in English. All other languages are translations.
- The precautions described in this document cover very important topics, follow them carefully.
- The installation of the system, and all activities described in the installation manual and the installer reference guide **MUST** be performed by an authorised installer.

1.1.1 Meaning of warnings and symbols

	DANGER Indicates a situation that results in death or serious injury.
	DANGER: RISK OF ELECTROCUTION Indicates a situation that could result in electrocution.
	DANGER: RISK OF BURNING Indicates a situation that could result in burning because of extreme hot or cold temperatures.
	DANGER: RISK OF EXPLOSION Indicates a situation that could result in explosion.
	WARNING Indicates a situation that could result in death or serious injury.
	WARNING: FLAMMABLE MATERIAL
	CAUTION Indicates a situation that could result in minor or moderate injury.
	NOTICE Indicates a situation that could result in equipment or property damage.
	INFORMATION Indicates useful tips or additional information.

Symbol	Explanation
	Before installation, read the installation and operation manual, and the wiring instruction sheet.
	Before performing maintenance and service tasks, read the service manual.
	For more information, see the installer and user reference guide.

1.2 For the user

- If you are NOT sure how to operate the unit, contact your installer.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in

a safe way and understand the hazards involved. Children shall NOT play with the appliance. Cleaning and user maintenance shall NOT be made by children without supervision.



WARNING

To prevent electric shocks or fire:

- Do NOT rinse the unit.
- Do NOT operate the unit with wet hands.
- Do NOT place any objects containing water on the unit.



NOTICE

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.

- Units are marked with the following symbol:



This means that electrical and electronic products may NOT be mixed with unsorted household waste. Do NOT try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and of other parts must be done by an authorized installer and must comply with applicable legislation. Units must be treated at a specialized treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.

- Batteries are marked with the following symbol:



This means that the batteries may NOT be mixed with unsorted household waste. If a chemical symbol is printed beneath the symbol, this chemical symbol means that the battery contains a heavy metal above a certain concentration. Possible chemical symbols are: Pb: lead (>0.004%). Waste batteries must be treated at a specialized treatment facility for reuse. By ensuring waste batteries are disposed of correctly, you will help to prevent potential negative consequences for the environment and human health.

1.3 For the installer

1.3.1 General

If you are NOT sure how to install or operate the unit, contact your dealer.



NOTICE

Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Only use accessories, optional equipment and spare parts made or approved by Daikin.



WARNING

Make sure installation, testing and applied materials comply with applicable legislation (on top of the instructions described in the Daikin documentation).



CAUTION

Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.

1 General safety precautions



WARNING

Tear apart and throw away plastic packaging bags so that nobody, especially children, can play with them. Possible risk: suffocation.



DANGER: RISK OF BURNING

- Do NOT touch the refrigerant piping, water piping or internal parts during and immediately after operation. It could be too hot or too cold. Give it time to return to normal temperature. If you must touch it, wear protective gloves.
- Do NOT touch any accidental leaking refrigerant.



WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.



CAUTION

Do NOT touch the air inlet or aluminium fins of the unit.



NOTICE

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.



NOTICE

Works executed on the outdoor unit are best done under dry weather conditions to avoid water ingress.

In accordance with the applicable legislation, it might be necessary to provide a logbook with the product containing at least: information on maintenance, repair work, results of tests, stand-by periods,...

Also, at least, following information **MUST** be provided at an accessible place at the product:

- Instructions for shutting down the system in case of an emergency
- Name and address of fire department, police and hospital
- Name, address and day and night telephone numbers for obtaining service

In Europe, EN378 provides the necessary guidance for this logbook.

1.3.2 Installation site

- Provide sufficient space around the unit for servicing and air circulation.
- Make sure the installation site withstands the unit's weight and vibration.
- Make sure the area is well ventilated. Do NOT block any ventilation openings.
- Make sure the unit is level.

Do NOT install the unit in the following places:

- In potentially explosive atmospheres.
- In places where there is machinery that emits electromagnetic waves. Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
- In places where there is a risk of fire due to the leakage of flammable gases (example: thinner or gasoline), carbon fibre, ignitable dust.
- In places where corrosive gas (example: sulphurous acid gas) is produced. Corrosion of copper pipes or soldered parts may cause the refrigerant to leak.

1.3.3 Refrigerant

If applicable. See the installation manual or installer reference guide of your application for more information.



NOTICE

Make sure refrigerant piping installation complies with applicable legislation. In Europe, EN378 is the applicable standard.



NOTICE

Make sure the field piping and connections are NOT subjected to stress.



WARNING

During tests, NEVER pressurize the product with a pressure higher than the maximum allowable pressure (as indicated on the nameplate of the unit).



WARNING

Take sufficient precautions in case of refrigerant leakage. If refrigerant gas leaks, ventilate the area immediately. Possible risks:

- Excessive refrigerant concentrations in a closed room can lead to oxygen deficiency.
- Toxic gas may be produced if refrigerant gas comes into contact with fire.



DANGER: RISK OF EXPLOSION

Pump down – Refrigerant leakage. If you want to pump down the system, and there is a leakage in the refrigerant circuit:

- Do NOT use the unit's automatic pump down function, with which you can collect all refrigerant from the system into the outdoor unit. **Possible consequence:** Self-combustion and explosion of the compressor because of air going into the operating compressor.
- Use a separate recovery system so that the unit's compressor does NOT have to operate.



WARNING

ALWAYS recover the refrigerant. Do NOT release them directly into the environment. Use a vacuum pump to evacuate the installation.



NOTICE

After all the piping has been connected, make sure there is no gas leak. Use nitrogen to perform a gas leak detection.



NOTICE

- To avoid compressor breakdown, do NOT charge more than the specified amount of refrigerant.
- When the refrigerant system is to be opened, refrigerant **MUST** be treated according to the applicable legislation.





WARNING

Make sure there is no oxygen in the system. Refrigerant may only be charged after performing the leak test and the vacuum drying.

- In case re-charge is required, refer to the nameplate of the unit. It states the type of refrigerant and necessary amount.
- The unit is factory charged with refrigerant and depending on pipe sizes and pipe lengths some systems require additional charging of refrigerant.

- Only use tools exclusively for the refrigerant type used in the system, this to ensure pressure resistance and prevent foreign materials from entering into the system.
- Charge the liquid refrigerant as follows:

If	Then
A siphon tube is present (i.e., the cylinder is marked with "Liquid filling siphon attached")	Charge with the cylinder upright. 
A siphon tube is NOT present	Charge with the cylinder upside down. 

- Open refrigerant cylinders slowly.
- Charge the refrigerant in liquid form. Adding it in gas form may prevent normal operation.



CAUTION

When the refrigerant charging procedure is done or when pausing, close the valve of the refrigerant tank immediately. If the valve is NOT closed immediately, remaining pressure might charge additional refrigerant.
Possible consequence: Incorrect refrigerant amount.

1.3.4 Brine

If applicable. See the installation manual or installer reference guide of your application for more information.



WARNING

The selection of the brine MUST be in accordance with the applicable legislation.



WARNING

Take sufficient precautions in case of brine leakage. If brine leaks, ventilate the area immediately and contact your local dealer.



WARNING

The ambient temperature inside the unit can get much higher than that of the room, e.g. 70°C. In case of a brine leak, hot parts inside the unit can create a hazardous situation.



WARNING

The use and installation of the application MUST comply with the safety and environmental precautions specified in the applicable legislation.

1.3.5 Water

If applicable. See the installation manual or installer reference guide of your application for more information.



NOTICE

Make sure water quality complies with EU directive 98/83 EC.

1.3.6 Electrical



DANGER: RISK OF ELECTROCUTION

- Turn OFF all power supply before removing the switch box cover, connecting electrical wiring or touching electrical parts.
- Disconnect the power supply for more than 1 minute, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage MUST be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.
- Do NOT touch electrical components with wet hands.
- Do NOT leave the unit unattended when the service cover is removed.



WARNING

If NOT factory installed, a main switch or other means for disconnection, having a contact separation in all poles providing full disconnection under overvoltage category III condition, MUST be installed in the fixed wiring.



WARNING

- ONLY use copper wires.
- Make sure the field wiring complies with the applicable legislation.
- All field wiring MUST be performed in accordance with the wiring diagram supplied with the product.
- NEVER squeeze bundled cables and make sure they do NOT come in contact with the piping and sharp edges. Make sure no external pressure is applied to the terminal connections.
- Make sure to install earth wiring. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earth may cause electrical shock.
- Make sure to use a dedicated power circuit. NEVER use a power supply shared by another appliance.
- Make sure to install the required fuses or circuit breakers.
- Make sure to install an earth leakage protector. Failure to do so may cause electric shock or fire.
- When installing the earth leakage protector, make sure it is compatible with the inverter (resistant to high frequency electric noise) to avoid unnecessary opening of the earth leakage protector.

2 About the documentation



NOTICE

Precautions when laying power wiring:



- Do NOT connect wiring of different thicknesses to the power terminal block (slack in the power wiring may cause abnormal heat).
- When connecting wiring which is the same thickness, do as shown in the figure above.
- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will damage the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.



WARNING

- After finishing the electrical work, confirm that each electrical component and terminal inside the electrical components box is connected securely.
- Make sure all covers are closed before starting up the unit.



NOTICE

Only applicable if the power supply is three-phase, and the compressor has an ON/OFF starting method.

If there exists the possibility of reversed phase after a momentary black out and the power goes on and off while the product is operating, attach a reversed phase protection circuit locally. Running the product in reversed phase can break the compressor and other parts.

Target audience

Authorised installers + end users



INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
 - Safety instructions that you **MUST** read before installing
 - Format: Paper (in the accessory bag of the heat reclaim ventilation unit)
- **Heat reclaim ventilation unit installation and operation manual:**
 - Installation and operation instructions
 - Format: Paper (in the accessory bag of the heat reclaim ventilation unit)
- **Installer and user reference guide:**
 - Preparation of the installation, good practices, reference data,...
 - Detailed step-by-step instructions and background information for basic and advanced usage
 - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

2 About the documentation

2.1 About this document



INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

For the installer

3 About the box

3.1 Overview: About the box

This chapter describes what you have to do after the box with the heat reclaim ventilation unit is delivered on-site.

It contains information about:

- Unpacking and handling the units
- Removing the accessories from the units

Keep the following in mind:

- At delivery, the unit **MUST** be checked for damage. Any damage **MUST** be reported immediately to the carrier's claims agent.
- Bring the packed unit as close as possible to its final installation position to prevent damage during transport.
- When handling the unit, take into account the following:



Fragile, handle the unit with care.




Keep the unit upright in order to avoid damage.

- Prepare the path along which you want to bring the unit inside in advance.


3.2 Heat reclaim ventilation unit

3.2.1 To unpack the heat reclaim ventilation unit




VAM350+VAM500



VAM650~1000




VAM1500+VAM2000




3 About the box

3.2.2 To remove the accessories



VAM350+VAM500



VAM650~1000



VAM1500+VAM2000



- a Wire
- b General safety precautions
- c Installation and operation manual
- d Duct joints, VAM350~1000 4×, VAM1500+VAM2000 8×

- e Screws, VAM350+VAM500 16×, VAM650~1000 24×, VAM1500+VAM2000 48×

3.2.3 To handle the heat reclaim ventilation unit



NOTICE

When removing the heat reclaim ventilation unit from the packing, do NOT place the suction or discharge side of the unit on the floor. **Possible consequence:** Deformation of the suction or discharge openings and damaged expanded polystyrene.




CAUTION

To avoid injury, do NOT touch the air inlet, the air outlet, or the fans of the unit.



With packing.

In case of VAM350+VAM500, do NOT use slings or a forklift.
In case of VAM650~2000, use a forklift.





Without packing.

Carry VAM350~1000 slowly as shown:



Carry VAM1500+VAM2000 slowly as shown:



4 About the units and options

4.1 Overview: About the units and options

This chapter contains information about:

- Identifying the unit
- Combining the unit with options

4.2 Identification




NOTICE

When installing or servicing several units at the same time, make sure NOT to switch the service panels between different models.

4.2.1 Identification label: Heat reclaim ventilation unit

Location



Model identification

Example: V A M 500 J 7 VE B [*]

Code	Explanation
V	Ventilation
A	Air
M	Mounted type
500	Nominal air flow rate (m³/h)
J	Major design category (Design category for EC application)
7	Minor design category
VE	Power supply: 1~, 50 Hz 220~240 V Power supply: 1~, 60 Hz 220 V
B	European market
[*]	Minor model change indication

4.3 About the heat reclaim ventilation unit

The heat reclaim ventilation unit is intended for indoor installation.



NOTICE

ALWAYS use the air filter. If the air filter is NOT used, the heat exchange elements can get clogged, possibly causing poor performance and subsequent failure.

Operation range	Temperature	-10°C DB~46°C DB
Outdoor air + return air	Relative Humidity	≤80%

Operation range	Temperature	0°C DB~40°C DB
Unit location	Relative Humidity	≤80%

It is possible that, due to condensation, the paper heat exchanger deteriorates when the unit operates in conditions with high indoor humidity combined with low outdoor temperature. If such combined conditions occur for an extended period of time, the necessary precautions have to be taken to prevent condensation. Example: install a pre-heater to heat up the outdoor air.

When the heat reclaim ventilation unit is installed upside down, the minimum allowed outdoor air temperature is 5°C. If this CANNOT be guaranteed, you MUST install a heater to heat up the outdoor air to 5°C.

4.4 Combining units and options

4.4.1 Possible options for the heat reclaim ventilation unit

Adapter printed circuit board

Options BRP4A50A and KRP2A51.

At temperatures below -10°C, it is mandatory to use an electrical heater. This is connected with option PCB BRP4A50A.



CAUTION

If an electrical heater is installed, use nonflammable duct. For safety, be sure to keep 2 m or more between the heater and the heat reclaim ventilation unit.

If you install any of these options on the VAM650, you have to prepare the mounting plate (EKMP65VAM).

If you install any of these options on the VAM1500 or VAM2000, you have to prepare the mounting plate (EKMPVAM).

If you install KRP2A51, you have to prepare the fixing box (KRP1BA101).

Filter

When. This option might be mandatory. Check the local legislation. It is recommended in places with poor outside air quality.

Where. Install the filter behind the heat exchange element either at the side of air supply or air exhaust. Keep the standard filter in place. ONLY replace the standard filter when an option filter is put in front of and behind the heat exchange element.

How. For installation instructions, see the installation manual of the filter kit.

Pressure drop over the filter. See the databook for pressure drop curves for each capacity class of unit and each class of filter.

Model	Filter class	VAM350+500	VAM650	VAM800~2000
EKAFFVJ50F6	M6	○	—	—
EKAFFVJ50F7	F7	○	—	—
EKAFFVJ50F8	F8	○	—	—
EKAFFVJ65F6	M6	—	○	—
EKAFFVJ65F7	F7	—	○	—
EKAFFVJ65F8	F8	—	○	—
EKAFFVJ100F6	M6	—	—	○
EKAFFVJ100F7	F7	—	—	○
EKAFFVJ100F8	F8	—	—	○

Plenum (EKPLEN200)

When. The plenum is an option for VAM1500+VAM2000. This option can be used to ease the installation of the heat reclaim ventilation unit.

5 Preparation

Where. Replace the 2 duct joints of Ø250 mm with the plenum and a duct joint of Ø350 mm.

How. For installation instructions, see the installation manual of the plenum kit.

CO₂ sensor (BRYMA*)

When. The CO₂ sensor is optional. This option can be used to have a ventilation rate in function of the CO₂ concentration.

Where. Install the CO₂ sensor in the heat reclaim ventilation unit. For VAM1500+VAM2000, install the CO₂ sensor in the upper unit of the heat reclaim ventilation unit.

How. For installation instructions, see ["8.5.4 About the carbon dioxide sensor" on page 35](#).

5 Preparation

5.1 Overview: Preparation

This chapter describes what you have to do and know before going on-site.

It contains information about:

- Preparing the installation site
- Preparing the unit
- Preparing the electrical wiring
- Preparing the installation of the ducts

5.2 Preparing the installation site

Do NOT install the unit in places often used as work place. In case of construction works (e.g. grinding works) where a lot of dust is created, the unit MUST be covered.

Choose an installation location with sufficient space for carrying the unit in and out of the site.

Do NOT install a heat reclaim ventilation unit or air suction/discharge grille in the following places:

- Places, such as machinery plants and chemical plants, where noxious gases or corrosive components of materials such as acid, alkali, organic solvent and paint are present.
- Places, such as bathrooms, subject to moisture. Moisture can cause electric shock, electric leakage and other failures.
- Places subject to high temperature or direct flames.
- Places subject to much carbon black. Carbon black attaches to air filter and heat exchange elements, disabling them.

5.2.1 Installation site requirements for the heat reclaim ventilation unit



INFORMATION

Also read the general installation site requirements. See the "General safety precautions" chapter.



CAUTION

- The appliance is designed to be a built-in appliance. It must NOT be accessible to the general public. Adequate measures have to be taken to prevent access by other than qualified persons.
- Check if the installation location can support the unit's weight. Poor installation is hazardous. It can also cause vibrations or unusual operating noise.
- Provide sufficient service space and inspection holes. Inspection holes are needed for the air filters, the heat exchange elements and the fans.
- Do NOT install the unit so that it is in contact with a ceiling or wall, this may cause vibration.



CAUTION

Appliance NOT accessible to the general public, install it in a secured area, protected from easy access.

This unit is suitable for installation in a commercial and light industrial environment.

For VAM800~2000



NOTICE

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.


Service space

See ["6.1 Service space: Heat reclaim ventilation unit" on page 13](#).

5.3 Preparing the unit

5.3.1 To install the optional adapter printed circuit board

For models 350-500-800-1000




- a BRP4A50A (optional accessory)
- b KRP2A51 (optional accessory)
- c KRP1BA101 (Fixing box)
- f Screw
- g Screw (supplied with the fixing box)

- 1 Remove the screws from the unit.
- 2 Attach the optional adapter printed circuit board (KRP2A51) in the fixing box (KRP1BA101).
- 3 Follow the installation instructions provided with the option kits (BRP4A50A, KRP2A51 and KRP1BA101).


- 4 Guide the circuit board wire through the dedicated holes and attach it as instructed in "6.5.2 Opening the switch box" on page 16.
- 5 Attach the options to the unit, as shown in the figure.
- 6 After the wires are connected, fasten the switch box cover.

For model 650



- 1 Remove the screws from the unit.
- 2 Attach the optional mounting plate (EKMP65VAM) to the unit.
- 3 Attach the optional adapter printed circuit board (KRP2A51) in the fixing box (KRP1BA101).
- 4 Follow the installation instructions provided with the option kits (BRP4A50A, KRP2A51 and KRP1BA101).
- 5 Guide the circuit board wire through the dedicated holes and attach it as instructed in "6.5.2 Opening the switch box" on page 16.
- 6 Attach the options to the optional mounting plate, as shown in the figure.
- 7 After the wires are connected, fasten the switch box cover.

For models 1500+2000




- e EKMPVAM (Mounting plate)
f Screw
g Screw (supplied with the fixing box)

- 1 Remove the screws that are in the middle of the casing fixing plate.
- 2 Attach the optional mounting plate (EKMPVAM) on top of the casing fixing plate.
- 3 Attach the optional adapter printed circuit board (KRP2A51) in the fixing box (KRP1BA101).
- 4 Follow the installation instructions provided with the option kits (BRP4A50A, KRP2A51 and KRP1BA101).
- 5 Guide the circuit board wire through the dedicated holes and attach it as instructed in "6.5.2 Opening the switch box" on page 16.
- 6 Attach the options to the optional mounting plate, as shown in the figure.
- 7 After the wires are connected, fasten the switch box cover.

5.3.2 To install the duct joints

- 1 Position the duct joints over the duct holes.
- 2 Secure the duct joints with the provided screws (accessories).



Models	Number of provided screws	Number of provided duct joints
VAM350	16	4× Ø200 mm
VAM500	16	4× Ø200 mm
VAM650	24	4× Ø250 mm
VAM800	24	4× Ø250 mm
VAM1000	24	4× Ø250 mm
VAM1500	48	8× Ø250 mm
VAM2000	48	8× Ø250 mm

5.4 Preparing the electrical wiring

5.4.1 Wiring connection



WARNING


A main switch or other means for disconnection, having a contact separation in all poles, **MUST** be incorporated in the fixed wiring in accordance with the applicable legislation.

You can use a single switch to supply power to units on the same system. However, branch switches and branch circuit breakers **MUST** be selected carefully.

Fit the power supply wiring of each unit with a switch and fuse as shown in the drawing below.

5 Preparation

Complete system example



5.4.2 Component electrical specifications

Model	350	500	650	800	1000	1500	2000
Power supply							
50 Hz	198~264 V						
60 Hz	198~242 V						
MCA (A)	1.56	2.08	2.80	4.39	4.90	8.78	9.80
MFA (A)	16	16	16	16	16	16	16
Fan motor							
P (kW)	0.08× 2	0.08× 2	0.106 ×2	0.21× 2	0.21× 2	0.21× 4	0.21× 4
FLA (A)	0.62× 2	0.83× 2	1.12× 2	1.76× 2	1.96× 2	1.76× 4	1.96× 4

MCA Minimum Circuit Amps

MFA Maximum Fuse Amps

P Motor Rated Load

FLA Full Load Amps



NOTICE

When using residual current operated circuit breakers, make sure to use a high speed type 300 mA rated residual operating current.



NOTICE

The power supply **MUST** be protected with the required safety devices, i.e. a main switch, a slow blow fuse on each phase and an earth leakage protector in accordance with the applicable legislation.



NOTICE

See the engineering data book for details.

5.4.3 Specifications for field supplied fuses and wires

Power supply wiring	
Field supplied fuses	16 A
Wire	H05VV-U3G
Size	Wire size MUST comply with the applicable legislation.
Transmission wiring	
Wiring	Shielded wire (2 wire)
Size	0.75~1.25 mm ²

Precautions

When connecting more than one wire to the power supply wiring, use a 2 mm² (Ø1.6 mm) gauge wire.


When using 2 power wires of a gauge greater than 2 mm² (Ø1.6 mm), branch the line outside the terminal board of the unit, in accordance with electrical equipment standards. The branch **MUST** be sheathed to provide a degree of insulation equal to or greater than the power supply wiring itself.

Keep the total current of crossover wiring between indoor units to less than 12 A.

Do **NOT** connect wires of different gauge to the same grounding terminal. Loose connections may diminish the protection.

For the user interface wiring, refer to the installation manual of the user interface delivered with the user interface.

Wiring example



- All transmission wiring, except for the user interface wires, is polarised and **MUST** match the terminal symbol.

- Use shielded cable for the transmission wiring. Ground the shield of the shielded cable to ⊕ at the grounding screw, with the C-cup washer.

5.5 Preparing the installation of the ducts



INFORMATION

- Flexible ducting with sound insulation is effective to reduce blowing noises.
- When you select installation materials, consider the required volume of air flow and the acceptable level of noise for that particular installation.
- When the return air infiltrates into the ceiling and the temperature and humidity in the ceiling become too high, insulate the metal parts of the unit.
- ONLY use the service hole to access the inside of the unit.
- The sound pressure level is less than 70 dBA.




CAUTION

- For safety reasons, the required minimum length of the ducting is 1.5 m. If the ducting is shorter, or if no ducting is installed, then you MUST install grilles in the duct openings or the openings of the unit.
- Make sure no wind can blow in the ducting.

6 Installation

6.1 Service space: Heat reclaim ventilation unit






(mm)

a Service space

6.2 Unit orientation


The following illustration helps you to install the heat reclaim ventilation unit in the correct position:

6 Installation




Installation tips:

- Installing the unit upside down allows for common use of the inspection hole, reducing the required maintenance space. For example, if 2 units are installed closely together, ONLY 1 inspection hole is required for maintaining or replacing filters, heat exchange elements,...



- a Control box
- b Maintenance cover
- c Inspection hole

- When the heat reclaim ventilation unit is installed upside down, the minimum allowed outdoor air temperature is 5°C. If this CANNOT be guaranteed, you MUST install a heater to heat up the outdoor air to 5°C.
- Keep in mind that the ceiling hooks have to be reinstalled when the heat reclaim ventilation unit is installed upside down. They have to be rotated 180°, so that they are upside down (see the illustration).




- a Ceiling hook
- b Maintenance cover

6.3 To install the anchor bolts


Prerequisite: Before you install the anchor bolt, check if foreign objects such as vinyl and paper are still inside the fan housing. If so, remove them.

- 1 Install the anchor bolt (M10 to M12).
- 2 Pass the metal suspension bracket through the anchor bolt.
- 3 Secure the anchor bolt with washer and nut.

For VAM350~1000:



For VAM1500+VAM2000:



- a Ceiling hook
- b Nut
- c Washer
- d Double nuts




NOTICE


Always hang up the unit by its suspension brackets.

6.4 Duct connections


Do NOT connect the ducts as follows:



Extreme bend. Do NOT bend the duct over 90°.




Multi bend




Reduced diameter. Do NOT reduce the duct diameter.

- The minimum bend radius for flexible ducts is as follows:
($\text{Øduct}/2$) \times 1.5
- To prevent air leakage, wind aluminium tape around the section where the duct joints and the ducts are connected.
- Install the opening of the supply air as far as possible from the opening of the return air.
- Use ducts with a diameter that fit the unit model. See the data book.
- Install the two outdoor ducts with down slope (slope ratio of 1 in 50 or more) to prevent entry of rain water. Also provide insulation for both ducts, to prevent dew formation. (Material: 25 mm thick glass wool)
- If the level of temperature and humidity inside the ceiling is always high, install ventilation inside the ceiling.
- Insulate the duct and the wall electrically when a metal duct has to penetrate the metal lattice and wire lattice or the metal lining of a wooden structure wall.
- Install the ducts in a manner that the wind CANNOT blow inside the ducting.

VAM350~1000



VAM1500+VAM2000



- a Aluminium tape (field supply)
- b Insulation material (field supply)
- c Duct joint (accessories)
- d Slope over 1/50
- e Supply air
- f Return air

6.5 Electrical wiring



INFORMATION

Also read the precautions and requirements in the "General safety precautions" chapter.



WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the applicable legislation.
- Make electrical connections to the fixed wiring.
- All components procured on the site and all electrical construction MUST comply with the applicable legislation.

6.5.1 Precautions when connecting electrical wiring



DANGER: RISK OF ELECTROCUTION



WARNING

If NOT factory installed, a main switch or other means for disconnection, having a contact separation in all poles providing full disconnection under overvoltage category III condition, MUST be installed in the fixed wiring.



WARNING

- ONLY use copper wires.
- Make sure the field wiring complies with the applicable legislation.
- All field wiring MUST be performed in accordance with the wiring diagram supplied with the product.
- NEVER squeeze bundled cables and make sure they do NOT come in contact with the piping and sharp edges. Make sure no external pressure is applied to the terminal connections.
- Make sure to install earth wiring. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earth may cause electrical shock.
- Make sure to use a dedicated power circuit. NEVER use a power supply shared by another appliance.
- Make sure to install the required fuses or circuit breakers.
- Make sure to install an earth leakage protector. Failure to do so may cause electric shock or fire.
- When installing the earth leakage protector, make sure it is compatible with the inverter (resistant to high frequency electric noise) to avoid unnecessary opening of the earth leakage protector.

6 Installation



WARNING

- After finishing the electrical work, confirm that each electrical component and terminal inside the electrical components box is connected securely.
- Make sure all covers are closed before starting up the unit.



NOTICE

If the power supply has a missing or wrong N-phase, equipment will break down.



NOTICE

Do NOT install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.

6.5.2 Opening the switch box






CAUTION

Before opening the cover, be sure to turn off the power switches of the main units and other devices connected to the main units.




- Remove the screw that secures the cover and open the switch box.
- Secure the power supply control wires with the clamp, as shown in the figures.

VAM350~650






- a Switch box
- b Printed circuit board
- c Switch box cover
- d Securing screw and washer
- e Grounding terminal
- f Terminal board
- g Transmission wiring terminal board (P1, P2, F1, F2)
- h Transmission wiring (to optional user interface)
- i Power supply cable
- j Wires for connection of additional external damper (supplied accessory)
- k Insulated splices-closed barrel connector (0.75 mm²) (field supply)
- l Double or reinforced insulated flexible cable (0.75 mm²) to external damper (field supply)
- m Tie wrap (field supply)
- n BRP4A50A (optional accessory)
- o KRP2A51 (optional accessory)
- p CO₂ sensor (optional accessory)
- q Tapping screw
- r Wires for fresh-up operation

VAM800+VAM1000



6 Installation

VAM1500+VAM2000




- a Switch box
- b Printed circuit board
- c Switch box cover
- d Securing screw and washer
- e Grounding terminal

- f Terminal board
- g Transmission wiring terminal board (P1, P2, F1, F2)
- h Transmission wiring (to optional user interface)
- i Power supply cable
- j Wires for connection of additional external damper (supplied accessory)
- k Insulated splices-closed barrel connector (0.75 mm²) (field supply)
- l Double or reinforced insulated flexible cable (0.75 mm²) to external damper (field supply)
- m Tie wrap (field supply)
- n BRP4A50A (optional accessory)
- o KRP2A51 (optional accessory)
- p CO₂ sensor (optional accessory)
- q Tapping screw
- r Wires for fresh-up operation

6.5.3 Electrical connections for possible additional field supplied damper

The external damper prevents the intake of outdoor air if the heat reclaim ventilation unit is switched off.

The heat reclaim ventilation's main unit PCB operates the heat reclaim ventilation and provides a contact for the external damper.



CAUTION

Follow the instructions below carefully.

Required electrical connections

Connect one end of the accessory wire to the X24A connector on the PCB and the other end to the wire leading to the external damper via an insulated splices-closed barrel connector (0.75 mm²).


Make sure that the wire is NOT taut. The electrical circuit requires a current protection of 3 A and a maximum voltage of 250 V.

X24A will close the contact when the heat reclaim ventilation fan starts operating and it will open the contact when the fan is stopped.

6.5.4 Power supply connection, control wire terminals and switches on the circuit board

To connect the power supply

- 1 Connect the power supply to the L and N terminals.
- 2 Secure the power supply with the power supply clamp, as shown in "6.5.2 Opening the switch box" on page 16.
- 3 Be sure to connect the earth wire.



- a Power supply
- b Terminals
- c Damper
- d Damper (only VAM1500+VAM2000 bottom unit)
- e External damper (field supply)
- f Fan communications
- g KRP2A51 (option)
- h User interface
- i Centralised control
- j External input
- k Outdoor air thermistor
- l Indoor air thermistor
- m Damper (only VAM1500+VAM2000 bottom unit)
- n Damper
- o BRP4A50A (optional accessory)
- p CO₂ sensor
- q Factory setting (No operation if setting is changed)




NOTICE

Factory settings: Do NOT change the switch settings when a user interface is connected. SS1 is a setting switch to operate without user interface. Changing the settings when a user interface is connected, will stop the unit from operating normally. Keep the switch on the PCB at the factory setting.

6.5.5 Guidelines when connecting the electrical wiring

Keep the following in mind:


- If stranded conductor wires are used, install a round crimp-style terminal on the end of the wire. Place the round crimp-style terminal on the wire up to the covered part and fasten the terminal with the appropriate tool.




- a Stranded conductor wire
- b Round crimp-style terminal

- Use the following methods for installing wires:




7 System configuration

Wire type	Installation method
Single-core wire	 <p>a Curled single-core wire b Screw c Flat washer</p>





Wire type	Installation method
Stranded conductor wire with round crimp-style terminal	 <p>a Terminal b Screw c Flat washer O Allowed X NOT allowed</p>

7 System configuration




7.1 About control systems

Purposes and applications	Description of the system	Controller					
		Central user interface	Unified ON/OFF controller	Schedule timer	User interface for heat reclaim ventilation unit	User interface for indoor unit	Operation/stop
Independent system control system							
Basic method to operate the heat reclaim ventilation unit		—	—	—	○	○	○
Available functions in case of an independent control system: <ul style="list-style-type: none">• Ventilation mode changeover: automatic or manual• Air flow rate changeover: high/low• Air flow rate mode changeover: normal mode/fresh-up mode• Malfunction display							
Interlocked operation control system							
<ul style="list-style-type: none">• Interlocked operation with indoor unit by user interface for indoor unit. Maximum 16 units.• The heat reclaim ventilation unit can also be operated independently by the user interface for indoor unit, even if the indoor unit is NOT in operation. The heat reclaim ventilation unit CANNOT be operated independently when the duct is directly connected to the indoor unit.		—	—	—	—	○	○
Available functions in case of an interlocked operation control system: <ul style="list-style-type: none">• Ventilation mode changeover: automatic or manual• Air flow rate changeover: high/low• Air flow rate mode changeover: normal mode/fresh-up mode: initial setting required• Pre-cool/pre-heat operation: initial setting required• Nighttime free cooling operation: initial setting required• Malfunction display							
For an overview of settings, see "8.2 List of settings" on page 24.							
Centralised control system							
<ul style="list-style-type: none">• Unified ON/OFF controller: Maximum 16 groups of units.• Schedule timer: 1 schedule timer can control the weekly schedule of 128 units.• Central user interface: Up to 64 groups of units can be controlled individually by 1 central user interface.		○	○	○	○	○	○







Purposes and applications		Description of the system	Controller				
			Central user interface	Unified ON/OFF controller	Schedule timer	User interface for heat reclaim ventilation unit	User interface for indoor unit
Available functions in case of a centralised control system: <ul style="list-style-type: none">• Ventilation mode changeover: automatic or manual• Air flow rate changeover: high/low• Air flow rate mode changeover: normal mode/fresh-up mode (field setting required when user interface for heat reclaim ventilation unit is NOT used)• Air flow rate mode changeover: normal mode/fresh-up mode (when user interface for heat reclaim ventilation unit is installed)• Pre-cool/pre-heat operation: initial setting required• Nighttime free cooling operation: initial setting required• Malfunction display							
For an overview of settings, see "8.2 List of settings" on page 24 .							

- a** Unified ON/OFF controller, Schedule timer, Central user interface
 Heat reclaim ventilation unit
 Indoor unit
 User interface
 User interface

7.2 Independent system



System	Standard method	Related items in electric wiring
	<ul style="list-style-type: none"> Up to 16 units can be controlled with the user interface (a system with 2 remote controls can be created in the master/slave switching). All heat reclaim ventilation unit operations can be used and indicated. Remote control cord should be procured locally (cord length: up to 500 m). 	See "8.3.2 Independent system" on page 29
 Heat reclaim ventilation unit  User interface		





7.3 Interlocked system

System	Standard method	Related items in electric wiring
Combined operation system with VRV systems and Sky-air series   	<ul style="list-style-type: none"> A combined total of up to 16 air conditioners and the heat reclaim ventilation unit can be controlled. The ventilation mode can be operated independently when air conditioners are NOT used. Using the local setting of the user interface for air conditioners, various settings such as pre-cool/pre-heat reservation on/off, ventilation flow rate, ventilation mode, etc can be chosen. Since all VRV units are connected to a single line in view of installation, all VRV units are subjects for operation. If there are problems operating all VRV units, do NOT use this system. Up to 64 groups of the units can be controlled. The central control transmission line can be extended up to 1000 m. A direct duct connection is NOT possible. Set ON for collective zone interlock setting. Adapter PCB for remote control: KRP2A51 (One adapter PCB should be installed in either the heat reclaim ventilation unit or the indoor unit). The heat reclaim ventilation unit will operate ONLY when the air conditioner fan is on. Other specifications are the same as those of the standard system. 	See "8.3.3 1-group linked-control system" on page 29 See "8.3.4 Linked control with more than 2 groups" on page 29 See "8.3.5 Direct duct connection" on page 30
a Adapter printed circuit board for remote control  Heat reclaim ventilation unit  Indoor unit  User interface		

8 Configuration

7.4 Centralised control system

System	Standard method	Related items in electric wiring
All/individual control system 	<ul style="list-style-type: none"> Unified on/off controller: DCS301B(A)51. Up to 16 groups can be controlled (ON/OFF) by 1 controller and up to 4 controllers can be installed in 1 system. Schedule timer: DST301B(A)51. One schedule timer can control the weekly schedule of up to 128 units. Adapter PCB for remote control: KRP2A51 (NOT possible to use together with another central controller). 1 adapter PCB can control up to 64 groups collectively. One of the controllers has to be installed connected to the indoor unit. (However, ONLY KRP2A51 can be installed connected to a heat reclaim ventilation unit.). 	See "8.3.6 Centralised control system" on page 30
Zone control system 	<ul style="list-style-type: none"> Use of the centralised controller enables zone control via the centralised control line (up to 64 zones). Central user interface DCS302C(A)51, intelligent touch controller DCS601C51, or intelligent touch manager DCM601A51. Central user interface can control the independent operation of the heat reclaim ventilation units in each zone. 	See "8.3.6 Centralised control system" on page 30

- a Controller
 Heat reclaim ventilation unit
 Indoor unit
 User interface
 User interface

8 Configuration

The settings (format: XX(XX)-X-XX), for example 19(29)-1-02, that are used in this chapter are composed of 3 parts, divided by "-":

- Mode number: for example, 19(29), where 19 is the mode number for group settings and 29 is the mode number for individual settings.
- Switch number: for example, 1
- Position number: for example, 02

8.1 Operating procedure

You can use either the user interface of the heat reclaim ventilation units or of the air conditioner to adjust the heat reclaim ventilation unit settings.

Initial settings

- Mode numbers 17, 18, and 19: group control of heat reclaim ventilation units.
- Mode numbers 27, 28, and 29: individual control.

8.1.1 To change the settings with BRC1E53

Make sure that the switch box lids on the heat reclaim ventilation unit are closed.

- Shortly press a button to turn on the screen light.
- Press and hold the Cancel button (a) for at least 4 seconds to enter the Service Settings menu.

- Go to Field Settings with the Up/Down buttons and press the Menu/Enter button (b).
- Press the Left/Right buttons to highlight the number under Mode.
- Press the Up/Down buttons to select the required mode number.
Result: Depending on the mode number that you select, starting at 20, you will also have to select a unit number, for the individual control.
- Use the Left/Right buttons to highlight the number under Unit No.
- Use the Up/Down buttons to select an indoor unit number. Selecting a unit number is NOT necessary when you are configuring the entire group.
- Use the Left/Right buttons to select a position number (0 to 15) for the switch number that you want to change.

In case of individual settings:


Field Settings			
Unit No.	Mode		
0	20		
0-11	1-00	2-00	3-00
4	5	6	7
8	9	10	11
12	13	14	15
Return Setting			

In case of group settings:



Field Settings			
Mode			
10			
0-11	1-*	2-*	3-*
4	5	6	7
8	9	10	11
12	13	14	15
Return Setting			

- Use the Up/Down buttons to select the required position number.

- 10 Press the Menu/Enter (b) button and confirm the selection with Yes.



- 11 After you have completed all the changes, press the Cancel button (a) twice to return to the normal mode.



NOTICE

Setting 18(28)-11 CANNOT be selected with this user interface.

8.1.2 To change the settings with BRC301B61

Make sure that the switch box lids on the heat reclaim ventilation unit are closed.

- 1 With the unit in normal mode, press the Inspection/Trial button (a) for more than 4 seconds to enter the local setting mode.
- 2 Use the Ventilation mode button (up - b) and the Airflow rate button (down - b) to select a mode number.

Result: The code display is blinking.

- 3 To configure settings for individual units under group control, press the Timer setting on/off button (c) and select the number of the unit that you want to configure.
- 4 To select the setting switch number, press the top section of the Timer button (d). To select the setting position number, press the lower section of the Timer button (e).

- 5 Press the Program/Cancel button (f) once, to enter the setting.

Result: The code display stops blinking and lights up.

- 6 Press the Inspection/Trial button (a) to return to normal mode.

8.2 List of settings

Setting mode	Setting switch no.	Setting description	Setting position no.														
			01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
17(27)	0	Filter cleaning time setting	Approx. 2500 hours	±1250 hours	—	—	—	—	—	—	—	—	—	—	—	—	—
	1	Nighttime free cooling timer (after stop)	Off	On after 2 hours	On after 4 hours	On after 6 hours	On after 8 hours	—	—	—	—	—	—	—	—	—	—
	2	Pre-cool/pre-heat	Off	On	—	—	—	—	—	—	—	—	—	—	—	—	—
	3	Pre-cool/pre-heat duration	30 minutes	45 minutes	60 minutes	—	—	—	—	—	—	—	—	—	—	—	—
	4	Initial fan speed	High	Ultra-high	—	—	—	—	—	—	—	—	—	—	—	—	—
17(27)	5	Yes/No setting for duct connection with VRV system	Without duct	With duct	Without duct	With duct	—	—	—	—	—	—	—	—	—	—	—
		Setting for cold areas (fan operation when heater thermostat is off)	—	—	Stop	Low	Stop	Low	—	—	—	—	—	—	—	—	—
	6	Nighttime free cooling (fan settings)	High	Ultra-high	—	—	—	—	—	—	—	—	—	—	—	—	—
	7	Target temperature for independent nighttime free cooling	18°C	19°C	20°C	21°C	22°C	23°C	24°C	25°C	26°C	27°C	28°C	29°C	30°C	—	—
	8	Centralised zone interlock setting	No	Yes	—	—	—	—	—	—	—	—	—	—	—	—	—
	9	Pre-heat time extension setting	0 minutes	30 minutes	60 minutes	90 minutes	—	—	—	—	—	—	—	—	—	—	—

Setting mode	Setting switch no.	Setting description	Setting position no.														
			01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
18(28)	0	External signal JC/J2	Last command	Priority on external input	Priority on operation	Disable nighttime free cooling / Forced stop	—	24 hours ventilation On/Off	—	—	—	—	—	—	—	—	—
	1	Setting for direct Power ON	Off	On	—	—	—	—	—	—	—	—	—	—	—	—	—
	2	Auto restart setting	Off	On	—	—	—	—	—	—	—	—	—	—	—	—	—
	3	Output signal to external damper (X24A)	—	—	Damper output (fan operation)	Damper output (fan operation)	—	—	—	—	—	—	—	—	—	—	—
	4	Indication of ventilation mode	On	Off	—	—	—	—	—	—	—	—	—	—	—	—	—
18(28)	6	Automatic ventilation air flow mode	Linear	—	Fixed A	Fixed B	—	—	—	—	—	—	—	—	—	—	—
	7	Fresh-up mode	No indication supply	No indication exhaust	Indication supply	Indication exhaust	—	—	—	—	—	—	—	—	—	—	—
	8	External input terminal function selection (between J1 and JC)	Fresh-up	Error output	Error output stop operation	Forced off	Fan forced off	Air-flow up	—	—	—	—	—	—	—	—	—
18(28)	9	BRP4A50A output switching selection (between X3 and X4)	Heater output	Error output	Fan output (Low/High/Ultra-high)	Fan output (High/Ultra-high)	Fan output (Low/High/Ultra-high)	24-hour ventilation and operation output	24-hour ventilation output	—	—	—	—	—	—	—	
			Operation output (between X1 and X2)	Operation output	Operation output	—	—			—	—	—	—	—	—		
18(28)	11	Filter contamination check**	No action	Reset filter check	Force filter check	—	—	—	—	—	—	—	—	—	—	—	—

8 Configuration

Setting mode	Setting switch no.	Setting description	Setting position no.														
			01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
19(29)	0	Filter contamination inspection setting	Filter contamination check with fan step 1-15	Filter contamination check with new fan step	Timer based check	Target detection filter with fan step 1-15	Auto ESP selection + target detection filter with new fan step	—	—	—	—	—	—	—	—	—	
	1	Low tap setting	Off	Run 1/15 (28 min. off/2 min. on)	Run 1/10 (27 min. off/3 min. on)	Run 1/6 (25 min. off/5 min. on)	Run 1/4 (22.5 min. off/7.5 min. on)	Run 1/3 (20 min. off/10 min. on)	Run 1/2 (15 min. off/15 min. on)	Continuous operation							
	2	Supply fan step setting*	Step1	Step2	Step3	Step4	Step5	Step6	Step7	Step8	Step9	Step10	Step11	Step12	Step13	Step14	Step15
	3	Exhaust fan step setting*	Step1	Step2	Step3	Step4	Step5	Step6	Step7	Step8	Step9	Step10	Step11	Step12	Step13	Step14	Step15
	4	24-hour ventilation setting	Off	Run 1/15 (28 min. off/2 min. on)	Run 1/10 (27 min. off/3 min. on)	Run 1/6 (25 min. off/5 min. on)	Run 1/4 (22.5 min. off/7.5 min. on)	Run 1/3 (20 min. off/10 min. on)	Run 1/2 (15 min. off/15 min. on)	Continuous operation							
19(29)	7	Reference concentration shift for ventilation air flow control (ppm)	0	+200	+400	+600	−200	−400	−600	—	—	—	—	—	—	—	—
	8	Stop ventilation by automatic ventilation air flow control	Allowed	NOT allowed	Allowed	NOT allowed	—	—	—	—	—	—	—	—	—	—	—
		Fan residual operation	Off	Off	Heater operation	Heater operation	—	—	—	—	—	—	—	—	—	—	—
1A	9	Normal ventilation tap on automatic ventilation air flow control	—	—	—	—	Control by CO ₂ sensor	—	—	—	—	—	—	—	—	—	—
	0	Fresh-up operation **	Off	On	—	—	—	—	—	—	—	—	—	—	—	—	—

**INFORMATION**

- Factory settings are marked with grey backgrounds.
- (*) See the technical data book for pressure drop curves and selection of fan curves (step 1 to 15).
- (**) This setting CANNOT be done with BRC301B61.
- The setting modes are mentioned as group settings. Between parentheses are the setting modes for individual unit control.
- Group number setting for centralised controller

Mode No. 00: Group controller

Mode No. 30: Individual controller

Regarding the setting procedure, see the section "Group number setting for centralised control" in the operating manual of either the on/off controller or the central controller.


Example

To adjust the auto restart setting to 'on' in the group setting mode, enter mode No. "18", setting switch No. "2" and position No. "02".

8 Configuration

8.3 Settings for all configurations

Setting 17(27)-4: First choose the fan speed. Set it to high or ultra-high.



8.3.1 About setting 19(29)-0-04 and 19(29)-0-05

- When you have configured setting 19(29)-0-04 successfully, the system automatically changes it to setting 19(29)-0-01.

- When you have configured setting 19(29)-0-05 successfully, the system automatically changes it to setting 19(29)-0-02.



NOTICE

If you change the ducting, then install clean filters and reconfigure setting 19(29)-0-04 or 19(29)-0-05, otherwise the signal to clean the filters will come too soon. Do NOT adjust the dampers when setting 19(29)-0-04 or 05 is activated.

- If the user interface is switched off while you are activating setting 19(29)-0-04 or 19(29)-0-05, the configuration is aborted. When you switch the user interface back on, the function starts from the beginning.
- Setting 19(29)-0-04 takes between 1 and 6 minutes to complete. You can check if the setting was completed successfully by checking if the field setting is changed to 0-01.
- Setting 19(29)-0-05 takes between 3 and 35 minutes to complete. You can check if the setting was completed successfully by checking if the field setting is changed to 0-02.




NOTICE

While activating setting 19(29)-0-04 and 19(29)-0-05, the unit is set to heat recovery and the fan is on high or ultra high. After the configuration, the unit is set back to what it was before the configuration.

- You can ONLY activate these settings with clean filters.
- For VAM1500+VAM2000, make sure that the ducting pressure drop of the top and bottom units is balanced.
- The function starts as soon as it is selected and the user interface is on.
- Setting 19(29)-0-04 CANNOT be configured if the outside temperature is $\leq -10^{\circ}\text{C}$, which is out of the operation range.
- Setting 19(29)-0-05 CANNOT be configured if the outside temperature is $\leq 5^{\circ}\text{C}$. In this case error 65-03 is shown and the unit stops working. Change the setting to 19(29)-0-04.
- The setting CANNOT be configured if there are alerts or errors present.
- If booster fans are used, you can ONLY configure setting 19(29)-0-03.
- You can configure settings 19(29)-0-04 and 19(29)-0-05 for multiple units with 1 user interface.

8.3.2 Independent system



- a Master user interface for heat reclaim ventilation unit
- b Slave user interface for heat reclaim ventilation unit
- c Switch position: Master
- d Switch position: Slave
- e Maximum length of connection line: 500 m




NOTICE

Factory settings: Do NOT change the switch settings when a user interface is connected. SS1 is a setting switch to operate without user interface. Changing the settings when a user interface is connected, will stop the unit from operating normally. Keep the switch on the PCB at the factory setting.

8.3.3 1-group linked-control system

- You can use the air conditioner's user interface to control up to 16 units, a combination of indoor air conditioner units and heat reclaim ventilation units.
- You can configure initial settings for the functions of the heat reclaim ventilation units. These functions are pre-cool/pre-heat, ventilation air flow, ventilation mode, and fresh-up. Use the air conditioner's user interface to configure the initial settings for the heat reclaim ventilation units. See "8.2 List of settings" on page 24.




- a User interface for air conditioner
- b User interface for air conditioner
- c Maximum length of connection line: 500 m

8.3.4 Linked control with more than 2 groups

To change the settings, P1/P2 MUST be connected to the heat reclaim ventilation units. That means that you have to connect a user interface to the unit. You can remove the user interface after you have changed the settings.

If the unit is supposed to operate without user interface, do NOT switch it on with the user interface connected. Otherwise, the unit will give an error once the controller is removed, because it will keep on searching for the user interface signal. To resolve the error, perform a power reset without the user interface connected.

- You need the optional adapter printed circuit board (KRP2A51) connected to 1 unit that is part of the F1/F2 loop. The unit can be an indoor unit or a heat reclaim ventilation unit.
- You can connect up to 64 units, a combination of air conditioners and heat reclaim ventilation units, to the F1 and F2 terminals.
- KRP2A51 ONLY has ON/OFF control. If the heat reclaim ventilation units run in automatic mode, they have a fixed set point. If P1/P2 is NOT connected, the set point of the indoor unit is unknown.
- Use the air conditioner's user interface to configure the initial settings.




8 Configuration

- a User interface for air conditioner
- b Maximum length of connection line: 1000 m
- c Optional distant control adapter (KRP2A51)

Activate setting 17-8-02 to set the collective zone interlock to ON. No further settings are required.

8.3.5 Direct duct connection

The line connections are the same as for the 1-group linked-control system.



- a User interface for air conditioner
- b User interface for air conditioner
- c Maximum length of connection line: 500 m

Initial settings

Activate below setting for direct duct connection. This direct duct configuration ONLY works if P1/P2 is connected.

- Mode number: 17
- Switch number: 5
- Position number: 02

Other functions


As in 1-group linked-control system, you can also configure other heat reclaim ventilation unit functions.

8.3.6 Centralised control system

To change the settings, P1/P2 MUST be connected to the heat reclaim ventilation units. That means that you have to connect a user interface to the unit. You can remove the user interface after you have changed the settings.

If the unit is supposed to operate without user interface, do NOT switch it on with the user interface connected. Otherwise, the unit will give an error once the controller is removed, because it will keep on searching for the user interface signal. To resolve the error, perform a power reset without the user interface connected.

All control




- a User interface for air conditioner
- b Maximum length of connection line: 1000 m
- c Schedule timer (DST301B51)
- d Adapter printed circuit board for remote control (KRP2A51)
- e On/Off signal

If you use the adapter printed circuit board (KRP2A51) or schedule timer (DST301B51), the following is valid:

- You can connect up to 64 units, a combination of air conditioners and heat reclaim ventilation units, to the F1 and F2 terminals.
- This system does NOT require group number setting for centralised control (auto-address system). The centralised group number is automatically assigned if the adapter printed circuit board (KRP2A51) or schedule timer (DST301B51) is connected.
- The adapter printed circuit board and the schedule timer CANNOT be used together. The adapter printed circuit board allows on/off control. The schedule timer allows on/off control with a weekly schedule.
- You can connect the adapter printed circuit board to the electric component mounting base of either the heat reclaim ventilation unit or the air conditioner.

All/individual control



If you use the On/Off controller (DCS301B51), the following is valid:

- You can connect up to 64 units, a combination of air conditioners and units, to the F1 and F2 terminals.
- You can connect up to 4 On/Off controllers.
- You have to assign a central control group number to each heat reclaim ventilation unit and air conditioner. Regarding the setting of the group number, see "The centralised control group number setting" in the operating instructions of the On/Off controller.
- Use the air conditioner's user interface to configure the initial settings.

Example


Setting the centralised group number 2-05 to 1:

Use the local setting on the user interface to set the central control group number.

Mode number: 00

Central control group number: 2-05

Zone control



- You can connect up to 64 units, a combination of air conditioners and units, to the F1 and F2 terminals.
- With the centralised controller zone 1 and 2 can be controlled independently.

Zone 2

The heat reclaim ventilation units operate in the zone-linked mode, as described in ["8.3.4 Linked control with more than 2 groups" on page 29](#).

Initial settings:


- You have to assign a central control group number to each unit and air conditioner. Regarding the setting of the group number, see "The centralised control group number setting" in ["All/individual control" on page 31](#).
- For the ventilation air flow setting, follow the procedure described in ["All control" on page 30](#).
- For the zone setting from the centralised controller, see the operating instructions of the centralised controller.
- You can use the centralised controller to control individual units in the zone for ventilation.

8 Configuration

8.4 About the user interface


8.4.1 User interface for VRV-system air conditioner

Please read the manual supplied with the user interface (BRC1E53) for more detailed instructions.




To change the ventilation rate


- 1 Press the Menu/Enter button to display the main menu.
- 2 Press the Up/Down buttons to select Ventilation and press the Menu/Enter button.



- 3 Press the Up/Down buttons to select Ventilation Rate and press the Menu/Enter button.




- 4 Press the Up/Down buttons to change the setting to Low or High and press the Menu/Enter button to confirm.



To select ventilation mode


Ventilation mode is used when cooling or heating is unnecessary, so only the heat reclaim ventilation units are operating.

- 1 Press the Operation Mode Selector button several times, until the ventilation mode is selected.




To change the ventilation mode


- 1 Press the Menu/Enter button to display the main menu.
- 2 Press the Up/Down buttons to select Ventilation and press the Menu/Enter button.



- 3 Press the Up/Down buttons to select Ventilation mode and press the Menu/Enter button.



- 4 Press the Up/Down buttons to select the required ventilation mode. For more information about ventilation modes, see "Ventilation modes" on page 32.





Ventilation modes

You can change the ventilation mode in the main menu.

Mode	Description
Auto mode	Using information from the air conditioner (cooling, heating, fan, and set temperature) and heat reclaim ventilation unit (indoor and outdoor temperatures), this mode automatically changes between Energy Reclaim Ventilation and Bypass mode.
Energy Reclaim Ventilation mode	The outdoor air is supplied to the room after passing through a heat exchange element, where heat is exchanged with the return air.
Bypass mode	The outdoor air bypasses the heat exchange element. This means that outdoor air is supplied to the room without heat exchange with the return air.

Time to clean filter indication



When it is time to clean the filters, the following message or icon shows at the bottom of the basic screen: Time to clean filter or . Clean the filters. For more information, see "11 Maintenance and service" on page 39.



To remove the Time to clean filter indication


- 1 Press the Menu/Enter button.
- 2 Press the Up/Down buttons to select Reset Filter Indicator.
- 3 Press the Menu/Enter button.

Result: You return to the basic screen. The Time to clean filter indication is no longer displayed.




About error indications

If an error occurs, there is an error icon in the basic screen and the operation lamp blinks. If a warning occurs, ONLY the error icon blinks and the operation lamp does NOT. Press the Menu/Enter button to display the error code or warning and contact information.




The error code blinks and the contact address and model name appear as shown below. In this case, notify your Daikin dealer about the error code.



8.4.2 User interface for heat reclaim ventilation units

For non-independent systems, starting, stopping and setting a timer is NOT possible with this user interface (BRC301B61). In such cases, use the air conditioner user interface (BRC1E53) or the centralised controller.



- 1 Operation lamp
This red pilot lamp lights up while the unit is in operation.
- 2 Operation/Stop button
Press this button once and the unit starts to operate. Press this button again and the unit stops.
- 3 Air flow rate changeover button
Use this button to change the air flow to "Low", "High", "FRESH UP" Low Fresh-up, or "FRESH UP" High Fresh-up mode.



For "FRESH UP" operation

When this indication does NOT show, the volume of outdoor air supplied into the room is larger than that of the return air exhausted outdoors is equal.

For "FRESH UP" operation

- If the Fresh-up setting is set to "Fresh up air supply": The volume of outdoor air supplied into the room is larger than that of return air exhausted outdoors. This prevents odours and moisture from kitchens and toilets from flowing into the room. This is the factory setting.
- If the Fresh-up setting is set to "Fresh up air exhaust": The volume of return air exhausted outdoors is larger than that of outdoor air supplied into the room. This prevents hospital odours and airborne microorganisms from flowing out of the room into the corridors.

To change this setting, see "8.2 List of settings" on page 24.

- 4 Ventilation mode changeover button:

"(A)" Automatic mode

The unit's temperature sensor automatically changes the operation mode of the unit to Bypass mode and Heat Exchange mode.

"(B)" Heat Exchange mode

In this mode, the air passes through the heat exchange element to effect Total Heat Exchanging ventilation.

"(C)" Bypass mode

In this mode, the air does NOT pass through the heat exchange element but bypasses it to effect Bypass ventilation.

- 5 Indication of operation control method:

8 Configuration

When the operation of heat reclaim ventilation units is linked to the air conditioners, this indication may be displayed. While this indication is displayed, the heat reclaim ventilation units CANNOT be turned on or off with the user interface of the heat reclaim ventilation.

6 Indication of operation standby:

This icon indicates that the unit is precooling/preheating. The unit's start-up is delayed until after precooling/preheating is finished.

Precooling/preheating means that the heat reclaim ventilation units are NOT started while linked air conditioners are starting up, for example, before office hours.


During this period, the cooling or heating load is reduced to bring the room temperature to the set temperature in a short time.

7 Indication of centralised control:

When a user interface for air conditioners or devices for centralised control are connected to the heat reclaim ventilation units, this icon may be displayed.

While this indication is displayed, you may NOT be able to turn the heat reclaim ventilation units on or off, or use the timer function with the user interface of the heat reclaim ventilation unit.

8 Indication of air filter cleaning

When the display shows "", clean the air filter.

9 Filter signal reset button

10 Inspection button

ONLY use this button if the unit is being serviced.

11 Schedule timer button:

This button enables or disables the schedule timer.

12 Time adjust button:

Time adjust button:

13 Programming button:

Programming button:

To set the timer


- 1 Press the Schedule timer button.
- 2 Press the time adjust button to set the time.
- 3 Press the programming button to save the setting.

8.5 Detailed explanation of settings

8.5.1 To monitor the unit's operation

Prerequisite: Connect the adapter printed circuit board BRP4A50A to monitor the operation.

- 1 Connect the terminal strip on the adapter printed circuit board BRP4A50A.



If X1 and X2 are connected like in the figure, then, depending on setting 18(28)-09, an output is given when the unit is ON and/or when it is in 24-hour ventilation.

If X3 and X4 are also connected to BRP4A50A, then, depending on setting 18(28)-09, a second output can be given about fan operation or when the unit is in error. If a heater is connected, then the output is given to the heater.

8.5.2 About the fresh-up operation

Purpose

When combined with a local ventilating fan, such as the ones in bathrooms or kitchens, the air flow rate of the heat reclaim ventilation unit is balanced by either fan operation or exhaust operation. However, a circuit with voltage and low current (16 V, 10 mA) is formed between the JC and J1, so you MUST use a relay with low-load contact.


Function

The unit performs overcharged operation to prevent odour flowing back.


Necessary parts

Operation contact of exhaust ventilating fan (field supply)

Example of control wiring:




System description:



You can select either excessive supply mode or excessive exhaust mode. This function creates a more comfortable environment.

	Supply Fresh-up (Excessive outdoor air supply)	Exhaust Fresh-up (Excessive exhaust air supply)
Detail	Supply air volume can be set at a higher level than the exhaust air by the user interface.	Exhaust air volume can be set at a higher level than the supply air by the user interface.
Major effects	<ul style="list-style-type: none"> Prevents inflow of toilet odours. Prevents inflow of outdoor air in winter. 	<ul style="list-style-type: none"> Prevents outflow of airborne infectants from hospital rooms. Prevents outflow of odours from rooms in a nursing home.
Application	Offices, etc.	Hospitals, nursing homes, etc.



- a Portion of fresh-up operation
- b Air exhaust
- c Air supply
- d Heat reclaim ventilation unit (VAM)
- e Normal ventilation fan
- f Portion of exhaust operation
- g Air exhaust
- h Sick room
- i Floor area

If an external fan is connected to J1 and JC, take the following into account:

- Setting 19(29)-0-03 MUST be set, otherwise the filter cleaning indication will be displayed at the wrong time.
- Make sure that setting 18(28)-8 is still set for number 01, indicating fresh-up.
- With setting 18(28)-7 you can choose if there is exhaust air or supply air fresh-up and if the user interface indicates that fresh-up is going on.
- The following table describes the unit's operation based on setting 1A-0 and J1, JC:

Setting	Description of setting (See "8.2 List of settings" on page 24)	"J1", "JC" Normal open	"J1", "JC" Normal closed
1A-0-01	Fresh-up "OFF" (Factory setting)	Normal	Fresh-up
1A-0-02	Fresh-up "ON"	Fresh-up	Fresh-up

The unit's fresh-up operation corresponds with the following fan operation:


Type	Air supply Fresh-up		Exhaust Fresh-up	
Ventilation amount	Air supply	Exhaust	Air supply	Exhaust
Weak	High	Low	Low	High
Strong	Ultra high	High	High	Ultra high

8.5.3 About the external damper operation

Functions

Intake of outdoor air when the heat reclaim ventilation unit is off can be prevented if an external damper is incorporated in the system.

The heat reclaim ventilation's main unit printed circuit board operates the heat reclaim ventilation and provides a signal for the external damper.



The required setting changes for switchover to X24A output (see below for details).

Essential wiring

See "6.5.2 Opening the switch box" on page 16.

X24A gives an output when the supply air or exhaust air fan is running. Put setting 18(28)-3 for number 03 or 04.

8.5.4 About the carbon dioxide sensor

With the CO₂ (carbon dioxide) sensor installed, you can adjust the ventilation volume in function of measured CO₂ concentration. The measured concentration value is compared to programmed trigger values. Make sure that ventilation mode and air flow rate are set to automatic.

See "8.2 List of settings" on page 24 for the field setting overview.

- Use setting 19(29)-9-05 to give control to the CO₂ sensor.
- Use setting 19(29)-7 to shift the trigger values.
- Use setting 18(28)-6 to switch between linear and fixed control.

8 Configuration

	Linear control	Fixed control
Initialising	20 minutes in high	20 minutes in high
Measuring	Every 5 minutes	Every 20 minutes
Judgement	Every 30 minutes (average of 6 measurements)	Every 20 minutes

Trigger value CO ₂ ppm (1)	Linear control (minutes)			Fixed control	
	UH	H	L	Mode A	Mode B
≥1450	30	—	—	UH	UH
1300~1450	20	10	—	UH	UH
1150~1300	10	20	—	H	H
1000~1150	—	30	—	H	H
850~1000	—	20	10	H	L
700~850	—	10	20	L	L
550~700	—	—	30	L	L
400~550	—	—	20	L	stop
0~400	—	—	10	L	stop

(1) CO₂ parts per million
UH Ultra high
H High
L Low



Example

When the sensor measures 900 ppm in linear control, the unit runs in high mode for 20 minutes and the next 10 minutes in low mode, then measures again.

Essential wiring

See "6.5.2 Opening the switch box" on page 16 and the installation manual that is delivered with the CO₂ sensor.

To remove the components



- b Service cover
- c Heat exchange element
- d Air filter
- e Heat exchange element rail
- f Screw 1
- g Screw 2


- 1 Open the service cover hinge.
- 2 Remove the service cover.
- 3 Remove the 2 heat exchange elements and the 4 air filters.
- 4 Remove the screw from the right heat exchange element rail.
- 5 Remove the heat exchange element rail.
- 6 Loosen screw 2, and remove screw 1.



INFORMATION

Use a crosshead screwdriver, that has a shank larger than 65 mm and a total length of less than 120 mm.

To install the carbon dioxide sensor



- a Screw 1
- b Screw 2
- c Damper motor wire
- d Clamp


- 1 Use the 2 screws to install the CO₂ sensor. See "To remove the components" on page 36 for details.



NOTICE

Make sure that the damper motor wire is NOT trapped under the kit.

To route the wiring of the carbon dioxide sensor



- c Sealing material
- d Bush
- e Switch box
- f X14A connector
- g Screw

- 1 Remove the screws of the switch box cover.
- 2 Open the switch box.
- 3 Follow the same path with the CO₂ sensor wire as the damper switch (red) and thermistor (black) wires: through the bush inside the unit and through the left bush in the switch box.
- 4 Firmly insert the CO₂ sensor wire into the X14A connector.
- 5 Clamp the CO₂ sensor wire together with the damper switch (red) and thermistor (black) wires inside the switch box.
- 6 Cut the accompanying sealing material by following the slit. Stick each piece on top of the sealing material that is attached to the bushing, in order to seal the gap around the CO₂ sensor wire.
- 7 Bundle the excess CO₂ sensor wire together with the damper switch (red) and thermistor (black) wires from the inside of the unit with the accompanying clamp.
- 8 Cut off the excess edge of the clamp.

**NOTICE**

To install the heat exchanger rail correctly, the wire **MUST** be clamped.

**NOTICE**

When bundling the wires, make sure to open the control box completely.


To install the components

- 1 Close the switch box cover.
- 2 Install the components. Follow the reverse procedure of "[To remove the components](#)" on page 36.

8.5.5 About the nighttime free cooling operation

Nighttime free cooling function

The nighttime free cooling function is an energy-conserving function that works at night, when the air conditioner is off. This reduces the cooling load in the morning, when the air conditioner is switched on. This is mainly for rooms that contain office equipment that raises the room temperature.



- a Outside temperature
- b Indoor temperature
- c Set temperature
- d Operating state of air conditioner
- e Operating state of heat reclaim ventilation unit
- f Nighttime free cooling operation

Explanation

The unit compares the indoor and outdoor temperatures after the air conditioning stops running for the night. If the conditions below are met, nighttime free cooling starts. When the indoor temperature reaches the air conditioning setting, nighttime free cooling stops.

Conditions

- The indoor temperature is higher than the air conditioning setting.
- The outdoor temperature is lower than the indoor temperature.

If the above conditions are NOT met, reevaluation takes place every 60 minutes.

**NOTICE**

The nighttime free cooling operation works when the heat reclaim ventilation unit is off. Therefore, it is NOT possible to stop the nighttime free cooling function.

With setting 17(27)-1 you can set the number of hours that have to pass before the conditions for the free cooling function are checked.

With setting 17(27)-6 you can set if the fan runs in high or ultra high mode during the free cooling.

With setting 17(27)-7 you can set a temperature.

**NOTICE**

This function is NOT possible when the heat reclaim ventilation unit is NOT linked to an air conditioner.

8.5.6 About the pre-cool and pre-heat function

When the pre-cool/pre-heat function is set, the heat reclaim ventilation unit switches on at the configured time (30, 45, or 60 minutes) after the air conditioner starts cooling or heating. By default, this function is off. To use this function, you have to set it with the user interface of the air conditioner.

If the air conditioner is restarted within 2 hours after it has been stopped, this function is NOT started.

You can enable this function with setting 17(27)-2.

With setting 17(27)-3 and setting 17(27)-9 you can set for how long the start of the heat reclaim ventilation unit is delayed.

**NOTICE**

This function is NOT possible when there is direct duct connection or when the heat reclaim ventilation unit is NOT linked to an air conditioner.

8.5.7 About preventing a feeling of draft

When the heating is on in a setup with air conditioner and the fan is turned off while the defrost operation is running, the fan of the heat reclaim ventilation unit is set to low mode or even stopped to prevent a feeling of draft.

You can set the mode of the fan with setting 17(27)-5.

**NOTICE**

This function is NOT possible when the heat reclaim ventilation unit is NOT linked to an air conditioner.

8.5.8 About 24-hour ventilation

When the user interface is switched off, 24-hour ventilation starts. You can enable this function with setting 19(29)-4. With that same setting, you can set the fan speed.

8.5.9 About the ultra-low setting

If the amount of ventilation is too high, even in low mode, you can have the fans work intermittently or at a very low speed with setting 19(29)-1.

9 Commissioning



NOTICE

This function is NOT possible when there is direct duct connection.

8.5.10 About the electrical heater operation

If the electrical heater is used, put setting 19(29)-8 on 03 or 04 and setting 18(28)-9 on 01. For more details, see the printed circuit board heater manual.

8.5.11 About external linkage input

Terminals J2 and JC function as contact signal input to switch the heat reclaim ventilation unit on or off.

8.5.12 About filter contamination check

The filter contamination check can ONLY be done in the same conditions as 19(29)-0-04 or 05. For example if the unit is working in bypass it CANNOT be checked. In this case a timer is counting the hours. After a target value is reached, the conditions are changed for a short time to be able to do the filter contamination check.

With setting 18(28)-11-02: this timer can be set to 0.

With setting 18(28)-11-03: it can be chosen to do the filter contamination check at this moment.

After finishing 18(28)-11-02 and 03, the setting is put back automatically to 18(28)-11-01 and the unit operation is continued as before. The setting can ONLY be done when setting 19(29)-0-01 or 02 is used.



INFORMATION

This function is NOT possible in case of errors.

9 Commissioning

9.1 Overview: Commissioning

After installation and once the field settings are defined, the installer is obliged to verify correct operation. Therefore a test run MUST be performed according to the procedures described below.

This chapter describes what you have to do and know to commission the system after it is configured.

Commissioning typically consists of the following stages:

- 1 Checking the "Checklist before commissioning".
- 2 Performing a test run.
- 3 If necessary, correcting errors after abnormal completion of the test run.
- 4 Operating the system.

9.2 Precautions when commissioning



DANGER: RISK OF ELECTROCUTION



CAUTION

Do NOT perform the test operation while working on the indoor units, the outdoor unit or the heat reclaim ventilation units.

When performing the test operation, NOT only the unit to which the user interface is connected will operate, but all the units that are linked to this one as well. Working on an indoor unit or the heat reclaim ventilation unit while performing a test operation is dangerous.



CAUTION

Do NOT insert fingers, rods or other objects into the air inlet or outlet. When the fan is rotating at high speed, it will cause injury.

9.3 Checklist before commissioning

After the installation of the unit, first check the following items. Once all below checks are fulfilled, the unit MUST be closed, ONLY then can the unit be powered up.

<input type="checkbox"/>	You read the complete installation and operation instructions, as described in the installer and user reference guide .
<input type="checkbox"/>	Installation Check that the unit is properly installed, to avoid abnormal noises and vibrations when starting up the unit.
<input type="checkbox"/>	Field wiring Be sure that the field wiring has been carried out according to the instructions described in the chapter "6.5 Electrical wiring" on page 15 , according to the wiring diagrams and according to the applicable legislation.
<input type="checkbox"/>	Power supply voltage Check the power supply voltage on the local supply panel. The voltage MUST correspond to the voltage on the identification label of the unit.
<input type="checkbox"/>	Earth wiring Be sure that the earth wires have been connected properly and that the earth terminals are tightened.
<input type="checkbox"/>	Insulation test of the main power circuit Using a megatester for 500 V, check that the insulation resistance of 2 MΩ or more is attained by applying a voltage of 500 V DC between power terminals and earth. NEVER use the megatester for the transmission wiring.
<input type="checkbox"/>	Fuses, circuit breakers, or protection devices Check that the fuses, circuit breakers, or the locally installed protection devices are of the size and type specified in the chapter "5.4 Preparing the electrical wiring" on page 11 . Be sure that neither a fuse nor a protection device has been bypassed.
<input type="checkbox"/>	Internal wiring Visually check the electrical component box and the inside of the unit on loose connections or damaged electrical components.
<input type="checkbox"/>	Air inlet/outlet Check that the air inlet and outlet of the unit is NOT obstructed by paper sheets, cardboard, or any other material.
<input type="checkbox"/>	Installation date and field setting Be sure to keep record of the installation date on the sticker on the rear of the front panel according to EN60335-2-40 and keep record of the contents of the field setting(s).

9.4 Checklist during commissioning

<input type="checkbox"/>	To perform a test run .
--------------------------	--------------------------------

9.4.1 About the test run

After completing the installation of the system, turn on the power of the heat reclaim ventilation units. Refer to the manual of the user interface of each unit (user interface for air conditioner, central control unit, etc.) for conducting a trial operation.

10 Hand-over to the user

Once the test run is finished and the unit operates properly, please make sure the following is clear for the user:

- Make sure that the user has the printed documentation and ask him/her to keep it for future reference. Inform the user that he can find the complete documentation on the url as earlier described in this manual.
- Explain the user how to properly operate the system and what to do in case of problems.
- Show the user what to do in relation to maintaining the unit.
- Explain the user about energy saving tips as described in the operation manual.

11 Maintenance and service



NOTICE

Maintenance **MUST** be done by an authorized installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



NOTICE

We recommend to clean at least once every 2 years (for general office use). If necessary, shorter maintenance intervals might be required.



CAUTION

Before accessing, make sure to turn off the operation switch and disconnect the power.



CAUTION

During operation, **NEVER** check or clean the unit. It may cause electrical shock. Do **NOT** touch the rotating parts, it will cause injury.

11.1 Overview: Maintenance and service

This chapter contains information about:

- Preventing electrical hazards when maintaining and servicing the system
- The maintenance of the heat reclaim ventilation unit.

11.2 Maintenance safety precautions



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING



NOTICE: Risk of electrostatic discharge

Before performing any maintenance or service work, touch a metal part of the unit in order to eliminate static electricity and to protect the PCB.


11.2.1 To prevent electrical hazards

When performing service to inverter equipment:


- 1 Do **NOT** open the electrical component box cover for 10 minutes after the power supply is turned off.

- 2 Measure the voltage between terminals on the terminal block for power supply with a tester and confirm that the power supply is shut off. In addition, measure points as shown in the figure, with a tester and confirm that the voltage of the capacitor in the main circuit is less than 50 V DC.

VAM350~650



VAM800~2000



For details refer to the wiring diagram labelled on the outside of the service cover.

11.3 Checklist for maintenance of the heat reclaim ventilation unit

- Check the following at least once a year: Air filters.
The air filters can get blocked due to dust, dirt, leaves, etc. It is recommended to clean the air filters yearly. A blocked air filter can lead to too high pressure leading to worse performance. See "[Maintenance of the air filter](#)" on page 42.
- Check the following at least once every 2 years: Heat exchange element.
The heat exchange element can get blocked due to dust, dirt, etc. It is recommended to clean the heat exchange element once every 2 years. A blocked heat exchange element can lead to too high pressure leading to worse performance. See "[Maintenance of the heat exchange element](#)" on page 43.

12 Troubleshooting

12.1 Overview: Troubleshooting

This chapter describes what you have to do in case of problems.

It contains information about solving problems based on error codes.

Before troubleshooting

Carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring.

13 Disposal

12.2 Precautions when troubleshooting



WARNING

- When carrying out an inspection on the switch box of the unit, ALWAYS make sure that the unit is disconnected from the mains. Turn off the respective circuit breaker.
- When a safety device was activated, stop the unit and find out why the safety device was activated before resetting it. NEVER bridge safety devices or change their values to a value other than the factory default setting. If you are unable to find the cause of the problem, call your dealer.



DANGER: RISK OF ELECTROCUTION



WARNING


Prevent hazards due to inadvertent resetting of the thermal cut-out: this appliance MUST NOT be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly turned ON and OFF by the utility.

12.3 Solving problems based on error codes

In case of a displayed malfunction code, consult the dealer where the unit was purchased.

12.3.1 Error codes: Overview

Malfunction code	Particular code	Description
R1		EEPROM failure
R6		Locked rotor
R6	22	Unstable fan rpm: failure of filter contamination check or failure of function 19(29)-0-04/-05
R8		Power supply malfunction
RJ		Capacity setting malfunction
C1		Fan communication error
C6		Malfunction of fan motor sensor or fan control driver
CH		CO ₂ sensor warning
US		Transmission error between the unit and user interface
UB		Transmission error between main user interface and sub user interface
UR		Wrong user interface installed
UC		Repeated central address
UE		Transmission error between the unit and centralised controller
ED		External protection device activated
E4	01	Indoor air thermistor (R1T) malfunction
E4	02	Indoor air thermistor (R1T) out of operation range
E5	01	Outdoor air thermistor (R2T) malfunction
E5	02	Outdoor air thermistor (R2T) out of operation range
E5	03	Functions 19(29)-0-04/-05 not possible due to low outdoor temperature operation
ER		Damper-related malfunction
ER		Damper-related malfunction+thermistor

 In case of malfunction with the code on grey background, the unit still operates. However, make sure to have it inspected and repaired as soon as possible.

13 Disposal



NOTICE

Do NOT try to dismantle the system yourself: the dismantling of the system MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

14 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

14.1 Wiring diagram: Heat reclaim ventilation unit

The wiring diagram is delivered with the unit, located on the outside of the service cover.

Legend for wiring diagrams:

A1P	Printed circuit board
A2P~A5P	Printed circuit board assy (fan)
C7	Capacitor (M1F)
F1U	Fuse (250 V, 6.3 A, T) (A1P)
HAP	Pilot lamp (service monitor - green)
K1R	Magnetic relay (A1P)
K2R	Magnetic relay (A1P)
L1R~L4R	Reactor
M1D	Motor (damper)
PS	Switching power supply

Q1DI	Field earth leak detector (≤ 300 mA)
R1T	Thermistor (indoor air)
R2T	Thermistor (outdoor air)
R3T	Thermistor (PTC)
S1C	Limit switch damper motor
V1R	Diode bridge
X1M	Terminal (A1P)
X2M	Terminal (outside input) (A1P)
X3M	Terminal (power supply)
Z1C	Noise filter (ferrite core)
Z1F	Noise filter

User interface

SS1	Selector switch
-----	-----------------

Connector for option

X14A	Connector (CO ₂ sensor)
X24A	Connector (outside damper)
X33A	Connector (contact PCB)
X35A	Connector (power supply adapter PCB)

For VAM350~650

C1	Capacitor (A2P)
F2U	Fuse (250 V, 5 A, T) (A2P)
F4U	Fuse (250 V, 6.3 A, T) (A2P)
K1R	Magnetic relay (A2P)
M1F	Motor (supply air fan)
M2F	Motor (exhaust air fan)
Z2C	Noise filter (ferrite core)

For VAM800+VAM1000

F3U	Fuse (250 V, 6.3 A, T) (A2P+A3P)
-----	----------------------------------

M1F	Motor (exhaust air fan)
M2F	Motor (supply air fan)

For VAM1500+VAM2000

F3U	Fuse (250 V, 6.3 A, T) (A2P~A5P)
K5R	Magnetic relay (A1P)
M2D	Motor (damper)
M1F	Motor (exhaust air fan) (bottom)
M2F	Motor (supply air fan) (bottom)
M3F	Motor (exhaust air fan) (top)
M4F	Motor (supply air fan) (top)
S2C	Limit switch damper motor

Symbols:

	Field wiring
	Terminals
	Connectors
	Protective earth
	Noiseless earth

Colours:

BLK	Black
BLU	Blue
BRN	Brown
GRN	Green
ORG	Orange
RED	Red
WHT	White
YLW	Yellow

For the user**15 User interface****CAUTION**

NEVER touch the internal parts of the controller.

Do NOT remove the front panel. Some parts inside are dangerous to touch and appliance problems may happen. For checking and adjusting the internal parts, contact your dealer.

Detailed information on required actions to achieve certain functions can be found in the dedicated installation and operation manual of the indoor unit.

Refer to the operation manual of the installed user interface.

16 Before operation**WARNING**

This unit contains electrical parts.

**WARNING**

Before operating the unit, be sure the installation has been carried out correctly by an installer.

**CAUTION**

Do NOT operate the system when using a room fumigation-type insecticide. Chemicals could collect in the unit, and endanger the health of people who are hypersensitive to chemicals.

Operation modes:


- Heat exchange mode.
- Bypass mode.

17 Energy saving and optimum operation

Observe the following precautions to ensure the system operates properly.

- Adjust the air outlet properly and avoid direct air flow to room inhabitants.
- NEVER place objects near the air inlet or the air outlet of the unit. Doing so may cause a reduced heating/cooling effect or stop operation.

18 Maintenance and service

- When the display shows  (time to clean the air filter), ask a qualified service person to clean the filters. Refer to "18 Maintenance and service" on page 42.
- Keep the heat reclaim ventilation unit and user interface at least 1 m away from televisions, radios, stereos, and other similar equipment. Failing to do so may cause static or distorted pictures.
- Do NOT place items under the indoor unit, as they may be damaged by water.
- Condensation may form if the humidity is above 80%.

If the heat reclaim ventilation unit is used in an interlocked system or in a centralised control system, then energy saving functionality is available. Refer to "8.5 Detailed explanation of settings" on page 34.

Contact your installer or dealer for advice or to modify the parameters to the needs of your building.

Detailed information is given for the installer in the installation manual.

18 Maintenance and service



NOTICE

Maintenance MUST be done by an authorized installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



NOTICE

We recommend to clean at least once every 2 years (for general office use). If necessary, shorter maintenance intervals might be required.



CAUTION

Before accessing, make sure to turn off the operation switch and disconnect the power.



CAUTION

During operation, NEVER check or clean the unit. It may cause electrical shock. Do NOT touch the rotating parts, it will cause injury.

18.1 Maintenance of the air filter





CAUTION

- Do NOT wash the air filter in hot water.
- Do NOT dry the air filter over a fire.
- Do NOT subject the air filter to direct sunlight.
- Do NOT use organic solvent such as gasoline and thinner on the air filter.
- Make sure to install the air filter after servicing (missing air filter causes clogged heat exchange element). Replacement air filters are available.



To clean the air filters

- Go into the ceiling through the inspection hole, loosen the screw of the hinge mechanism (on the left side) to open the maintenance cover. Take the maintenance cover off by rotating it around the vertical axis of the hanging metal.




- a Maintenance cover
- b Hinge mechanism
- c Hanging metal
- A Models VAM350~1000
- B Models VAM1500+VAM2000

- Take out the air filters from the unit body.




- a Heat exchange element
- b Handle
- c Rail
- d Air filter
- A Models VAM350~1000
- B Models VAM1500+VAM2000

- To clean the air filters, lightly pat it manually or remove dust with a vacuum cleaner. If excessively dirty, wash it in water.



- If the air filters are washed, remove water completely and allow to dry for 20 to 30 minutes in the shade.
- When dried completely, install the air filters back in place after the installation of the heat exchange elements. Make sure the air filters are orientated correctly, as shown in the figure.



- 6 Install the maintenance cover securely in place.

18.2 Maintenance of the heat exchange element




CAUTION

- NEVER wash the heat exchange element with water.
- NEVER touch the heat exchange paper because it can be damaged if it is forced.
- Do NOT crush the heat exchange element.

To clean the heat exchange element

- 1 Take out the heat exchange elements. Refer to ["18.1 Maintenance of the air filter" on page 42](#).
- 2 Equip a vacuum cleaner with a brush on the tip of the suction nozzle.
- 3 Use the vacuum cleaner and lightly contact the brush on the surface of the heat exchange element to remove dust.



- 4 Put the heat exchange element on the rail and insert it securely in place.
- 5 Install the air filters securely in place.
- 6 Install the maintenance cover securely in place.

19 Troubleshooting

If one of the following malfunctions occur, take the measures shown below and contact your dealer.



WARNING

Stop operation and shut off the power if anything unusual occurs (burning smells etc.).

Leaving the unit running under such circumstances may cause breakage, electric shock or fire. Contact your dealer.

If the system does NOT properly operate, investigate the system according to the following procedures.

Malfunction	Measure
If the system does NOT operate at all.	<ul style="list-style-type: none"> ▪ Check if there is no power failure. Wait until power is restored and restart operation. ▪ Check if no fuse has blown or breaker is activated. Change the fuse or reset the breaker if necessary. ▪ Check if the indication of operation control method on the user interface is shown. This is normal. Operate the unit using the air conditioner remote control or centralised controller. Refer to "8 Configuration" on page 22. ▪ Check if the indication of operation standby on the user interface is shown. It indicates the pre-cooling/pre-heating operation. This unit is at stop and will start operation after the precooling/preheating operation is over. Refer to "8 Configuration" on page 22.
The amount of discharged air is small and the discharging sound is high.	<ul style="list-style-type: none"> ▪ Check if the air filter and heat exchange element are NOT clogged. Refer to "18 Maintenance and service" on page 42.
The amount of discharged air is large and the discharging sound is high.	<ul style="list-style-type: none"> ▪ Check if the air filter and heat exchange element are installed. Refer to "18 Maintenance and service" on page 42.



INFORMATION

The unit may not operate as requested due to a filter contamination check.

If after checking all above items, it is impossible to fix the problem yourself, contact your installer and state the symptoms, the complete model name of the unit (with manufacturing number if possible) and the installation date (possibly listed on the warranty card).

In case a malfunction code appears on the indoor unit user interface display, contact your installer and inform the malfunction code, the unit type, and serial number (you can find this information on the nameplate of the unit).

For your reference, a list with malfunction codes is provided. Refer to ["Error codes: Overview" on page 40](#). You can, depending on the level of the malfunction code, reset the code by pushing the ON/OFF button. If NOT, ask your installer for advice.

20 Relocation

Contact your dealer for removing and reinstalling the total unit. Moving units requires technical expertise.

21 Disposal



NOTICE

Do NOT try to dismantle the system yourself: the dismantling of the system MUST comply with applicable legislation. Units MUST be treated at a specialised treatment facility for reuse, recycling and recovery.

22 Glossary

Dealer

Sales distributor for the product.

22 Glossary

Authorized installer

Technical skilled person who is qualified to install the product.

User

Person who is owner of the product and/or operates the product.

Applicable legislation

All international, European, national and local directives, laws, regulations and/or codes that are relevant and applicable for a certain product or domain.

Service company

Qualified company which can perform or coordinate the required service to the product.

Installation manual

Instruction manual specified for a certain product or application, explaining how to install, configure and maintain it.

Operation manual

Instruction manual specified for a certain product or application, explaining how to operate it.

Maintenance instructions

Instruction manual specified for a certain product or application, which explains (if relevant) how to install, configure, operate and/or maintain the product or application.

Accessories




Labels, manuals, information sheets and equipment that are delivered with the product and that need to be installed according to the instructions in the accompanying documentation.




Optional equipment




Equipment made or approved by Daikin that can be combined with the product according to the instructions in the accompanying documentation.

Field supply

Equipment NOT made by Daikin that can be combined with the product according to the instructions in the accompanying documentation.







DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

4P487293-1 2017.08