










Ref No.	Description	Part No.	Ref No.	Description	Part No.
1	FAN GUARD	9378498006	67	HEATSINK THERMISTOR	9900518004
2	BELL MOUTH	9379709002	68	EMI FILTER	0400230113
3	RIGHT PANEL ASSY	9378920002	69	HEAT SINK G	9378511064
4	LEFT PANEL ASSY	9378919006			
5	SIDE PILLER ASSY	9379202008			
6	REAR PILLER	9378472006	100	ACCUMULATOR ASSY	9379221023
7	MAIN PILLER	9378468009	101	OIL SEPARATOR ASSY	9379677011
8	NET RIGHT ASSY	9378927001	102	COMPRESSOR(INV) ASSY	9380804017
9	NET LEFT ASSY	9378928008	103	COMP BOLT	9378474017
10	CONDUIT PLATE	9378493018	104	WASHER(RUBBER)I	9379179003
11	PROPELLER FAN	9378488007	105	CLAMP 19	9379459006
12	MOTOR,DC BRUSHLESS	9603212018	106	JNT PIPE(SUB COOL HEX)A	9374381036
13	MOTOR BRKT ASSY	9378925014	107	VALVE(4-WAY)A ASSY	9379052030
14	LABEL(FUJITSU)	9380477006	108	VALVE(4-WAY)B ASSY	9379052047
	LABEL(GENERAL)	9378949003	109	BYPASS VALVE A ASSY	9378744059
15	LABEL(AIRSTAGE)	9380479000	110	UNION JOINT	9970091018
16	TOP PANEL S	9378491014	111	SOLENOID 4WV A	9970113031
17	REAR PANEL S ASSY	9378921030	112	SOLENOID 4WV B	9970113048
18	NET REAR S ASSY	9378926011	113	OIL RETURN VALVE A ASSY	9378745032
19	BASE FOOT RS ASSY	9378856035	114	DISCHARGE PIPE B ASSY	9378889033
20	BASE FOOT FS ASSY	9378856011	115	SUCTION PIPE B ASSY	9378741072
21	FRONT PANEL S	9378480018	116	OIL RETURN VALVE B ASSY	9378747128
22	S PANEL TOP S	9380231011	117	SOLENOID SV1	9970044052
23	S PANEL BTM S	9380232018	118	SOLENOID SV2	9900189198
24	CONDENSER S ASSY	9379053044	119	SOLENOID SV3	9900189204
25	ACCESSORY PIPE A (108)	9379200028	120	SOLENOID SV4	9970126000
	ACCESSORY PIPE A (90/ 72)	9379200011	121	COIL(EXPANSION VALVE 1)	9970114014
26	ACCESSORY PIPE B (108)	9379200004	122	COIL(EXPANSION VALVE 2)	9970114021
	ACCESSORY PIPE B (90/ 72)	9379200035	123	COIL(EXPANSION VALVE 3)	9970101076
27	ACCESSORY PIPE C (108)	9379200042	124	LOW PRESSURE SENSOR	9900505035
	ACCESSORY PIPE C (90)	9379200066	125	HIGH PRESSURE SENSOR	9900505028
	ACCESSORY PIPE C (72)	9379200073	126	PRESSURE SW (INV COMP)	9900504038
28	ACCESSORY PIPE D (108/ 90)	9379200059	127	3WAY VALVE ASSY(Suction gas pipe)	9379039048
			128	3WAY VALVE ASSY(Liquid pipe)	9379039031
50	HEAT SINK H	9378511071	129	3WAY VALVE ASSY(Discharge gas pipe)	9379039055
51	HEAT SINK C	9378511026	130	SUB COOL HEX ASSY	9378749054
52	THERMO HOLDER	9378510005	131	EXPANSION VALVE ASSY	9378750067
53	MAIN PCB ASSY	9709270011	132	JOINT PIPE OILSEPARATOR A ASSY	9378737099
54	INVERTER PCB ASSY	9709077016	133	SUCTION PIPE D ASSY	9378742079
	INVERTER PCB ASSY (*AJT108)	9708991016	134	JOINT PIPE A ASSY	9378739024
55	FILTER PCB(INV) ASSY	9709084014	135	2-WAY VALVE ASSY	9365504079
56	FILTER PCB(MAIN) ASSY	9709082027	136	JOINT PIPE(OIL SEP)	9379693035
57	FAN DRIVER PCB ASSY	9709080016	137	RECEIVER TANK ASSY	9380825005
58	TERMINAL	9900251031	138	CRANK CASE HEATER 1 (INV COMP)	9361140332
59	MAGNETIC RELAY	9900566005	139	CRANK CASE HEATER 2 (INV COMP)	9361140318
60	REACTOR ASSY	9900748005	140	CLAMP 31 SA	9379432009
61	CAPACITOR	9704268037	-	THERMISTOR (TH8,10) ASSY	9900752002
62	RESISTOR,CEMENT	0200441016	-	THERMISTOR (TH3) ASSY	9900753009
63	RESISTOR,CEMENT	0200444017	-	THERMISTOR (TH1,11) ASSY	9900749002
64	OUTDOOR TEMP THERMISTOR(TH2)	9900747008	-	THERMISTOR (TH4,5,6) ASSY	9900750008
65	COMMUNICATION PCB	9707774023	-	THERMISTOR (TH7,9) ASSY	9900751005
66	DIODE BRIDGE	0001237023			

* AJT108: Australian Model

	Description
TH 1	Discharge temp. thermistor 1
TH 3	Suction temp. thermistor
TH 4	Sub-cool heat ex.(inlet liquid) thermistor
TH 5	Sub-cool heat ex.(outlet liquid) thermistor
TH 6	Sub-cool heat ex.(outlet gas) thermistor

	Description
TH 7	Heat ex. 1 (gas) thermistor
TH 8	Heat ex. 2 (gas) thermistor
TH 9	Heat ex. 1 (liquid) thermistor
TH10	Heat ex. 2 (liquid) thermistor
TH11	Compressor shell temp. thermistor