

PANEL SPACER INSTALLATION MANUAL

For authorized service personnel only.

UTG-BGYA-W

⚠ WARNING

When installing Panel spacer, please thoroughly read this installation manual.

Turn off the power until installation is complete. It will cause electric shock.

When installing Panel spacer, please refer to the operating manual and installation manual supplied with the indoor unit.

⚠ CAUTION


Panel spacer is used by assembling it with a Cassette type room air conditioner. Panel spacer cannot be used alone.

Handle Panel spacer carefully. Dropping it onto the floor or subjecting it to strong shock will cause erroneous operation or accidents.

Let the customer keep this installation manual because it is used when the air conditioner is serviced or moved.

STANDARD PARTS


The following installation parts are furnished. Check them before starting installation work.

Name and Shape	Qty	Name and Shape	Qty
	4	Screw (short)	8
		Panel spacer holder	8

1 PREPARATION BEFORE INSTALLATION


• Be careful when handling the decoration panel.

- (1) Do not place the panel facing down, standing upright or on top of any protruding objects. (This may cause dents and scratches to the surface and damage the flap.)
- (2) Remove the suction grille on the decoration panel. (For details on how to remove, refer to the decoration panel instruction manual.)
- (3) Place a piece of cardboard on the floor. Then place the decoration panel on its back onto the cardboard so as not to scratch the surface of the panel.



2 ADJUSTING POSITION OF INSTALLATION FOR INDOOR UNIT

Adjust the height of installation for the indoor unit as shown in the diagram below.




※There are two sets of dimensions for different models.

Model	※ 1 (mm(in.))
18/24L	199 (7-27/32)
30/36/45/54L	241 (9-1/2)

Please refer more detail to the instructions on supplied. "Indoor unit installation manual."


3 INSTALLING THE Panel spacer

(1) Assemble Panel spacer



(2) Secure the Panel spacer to the Decoration panel

- Install 8 Panel spacer holders.
- Tighten the screws at 8 positions.



4 INSTALLING DECORATION PANEL and Panel spacer TO INDOOR UNIT


⚠ CAUTION

- ① Use only supplied screws to install the decoration panel.
- ② Install so that there is no gap between the decoration panel and the air conditioner body.
- ③ If there is a gap, an error will occur as shown in the diagram below. Tighten the screw securely so that there will not be a gap.




- ① Please refer more detail to the instructions on supplied. "Decoration panel installation manual."
- ② Align the stamped marks on the decoration panel against the pipe and the drain of the indoor unit.
- ③ Temporarily tighten at 2 positions with metal fittings.

• Install with 4 Hexagon screws.



When there is a gap between the ceiling and the decoration panel even when the screw is tightened, readjust the height of the main indoor unit.

As long as it does not affect the levelness of the main indoor unit and the drain piping, you may adjust the height of the main indoor unit from the hole at the corner of the decoration panel, with the decoration panel still attached to the main indoor unit.



Tighten the screw until the seal material between the decoration panel and the main indoor unit is compressed to a thickness of 5-7mm (0.197 - 0.276 in.).

